McDATA®

Mobilizing the World's Data™

E/OS

E/OS Command Line Interface User Manual

P/N 620-000134-780
REV A

Simplifying Storage Network Management

McDATA Corporation
11802 Ridge Parkway, Broomfield, CO 80021
Corporate Headquarters: 800-545-5773
Sales E-mail: sales@mcdata.com *Web:* www.mcdata.com



Record of Revisions and Updates

Revision	Date	Description
620-000134-000	11/2001	Initial release of Manual
620-000134-100	05/2002	Updates for E/OS 2.0
620-000134-200	08/2002	Updates for E/OS 3.0
620-000134-300	09/2002	Updates for E/OS 4.0
620-000134-400	10/2002	Updates for E/OS 4.1
620-000134-500	10/2002	Updates for E/OS 4.1 CD-ROM final
620-000134-600	2/2003	Updates for E/OS 5.1 and EFCM 7.1
620-000134-601	7/2003	Updates for E/OS 5.5
620-000134-700	10/2003	Updates for E/OS 6.0
620-000134-710	12/2003	Updates for E/OS 6.1
620-000134-720	6/2004	Updates for E/OS 6.2
620-000134-730	12/2004	Updates for E/OS 7.0
620-000134-740	6/2005	Updates for E/OS 8.0
620-000134-750	9/2005	Corrections to manual
620-000134-760	4/2006	Updates for E/OS 8.2
620-000134-770	5/2006	Updates for E/OS 9.0
620-000134-780	9/2006	Updates for E/OS 9.1

Copyright © 2001 - 2006 McDATA Corporation. All rights reserved.

Printed September 2006

17th Edition

With the exception of downloading a copy of this publication for the customer's own use, no part of this publication may be reproduced or distributed except as authorized under the terms of the "McDATA Corporation License to Copy Machine Readable Documentation."

The information contained in this document is subject to change without notice. McDATA Corporation assumes no responsibility for any errors that may appear.

All computer software programs, including but not limited to microcode, described in this document are furnished under a license, and may be used or copied only in accordance with the terms of such license. McDATA either owns or has the right to license the computer software programs described in this document. In addition, McDATA Corporation retains all rights, title and interest in the computer software programs.

Contents

Preface xv

Chapter 1 Introduction

Command Line Interface Overview 1-2
Entering Command Line Interface Commands 1-2
- Documentation Conventions 1-2
- Navigation Conventions 1-3
- Command Tree 1-4
- Navigation of the CLI Command Tree 1-14
- Parameters 1-15
- Output 1-16

Logging In and Logging Out 1-16
- Types of Users 1-16
- Passwords and Secrets 1-16
- Globally available commands 1-17
- login 1-17
- logout 1-18
- Using the commaDelim Command 1-19
- commaDelim 1-19
- Handling CLI Errors 1-19
- Using CLI Help 1-20

Commenting Scripts 1-21
ED-5000 Director 1-22
Telnet Session 1-23
- Ethernet Connection Loss 1-23

Chapter 2 CLI Commands

Command Overview 2-2

New and Changed Commands 2-2
New Commands 2-2
config 2-3
config.alias 2-3
config.alias.activatePending 2-4
config.alias.add 2-5
config.alias.clearPending 2-5
config.alias.delete 2-5
config.alias.replacePending 2-6
config.alias.setCLIState 2-6
config.alias.setWebState 2-6
config.alias.showActive 2-7
config.alias.showPending 2-8
config.enterpriseFabMode.setState 2-8
config.features.enterpriseFabMode 2-9
config.features.ficonMS 2-10
config.features.installKey 2-10
config.features.NPIV 2-11
config.features.openSysMS 2-11
config.features.openTrunking 2-12
config.features.show 2-12
config.fencing 2-13
config.fencing.addPolicy 2-14
config.fencing.addPort 2-14
config.fencing.deletePolicy 2-16
config.fencing.removePort 2-16
config.fencing.setParams 2-17
config.fencing.setState 2-18
config.fencing.show 2-18
config.fencing.showTypeTable 2-20
config.ficonCUPZoning 2-20
config.ficonCUPZoning.addControlHost 2-20
config.ficonCUPZoning.deleteControlHost 2-21
config.ficonCUPZoning.setState 2-21
config.ficonCUPZoning.show 2-22
config.ficonMS.setMIHPTO 2-22
config.ficonMS.setState 2-23
config.ficonMS.show 2-23
config.ip.ethernet 2-24
config.ip.lineSpeed 2-24
config.ip.show 2-25
config.NPIV 2-25
config.NPIV.maxPortIDs 2-26

config.NPIV.setState 2-27
config.NPIV.show 2-27
config.NSTools 2-28
config.NSTools.clearSnapshot 2-28
config.NSTools.saveSnapshot 2-28
config.NSTools.showSnapDiff 2-29
config.NSTools.showSnapshot 2-29
config.openSysMS.setHostCtrlState 2-30
config.openSysMS.setState 2-30
config.port.blocked 2-31
config.port.fan 2-32
config.port.name 2-32
config.port.rxCredits 2-33
config.port.show 2-34
config.port.showPortAddr 2-36
config.port.showCredits 2-37
config.port.speed 2-38
config.port.swapPortByAddr 2-40
config.port.swapPortByNum 2-40
config.port.type 2-40
config.security 2-42
config.security.authentication.interface 2-42
config.security.authentication.interface.api.outgoing 2-43
config.security.authentication.interface.api.sequence 2-43
config.security.authentication.interface.cli.sequence 2-44
config.security.authentication.interface.eport.outgoing ... 2-44
config.security.authentication.interface.eport.sequence ... 2-45
config.security.authentication.interface.nport.outgoing ... 2-45
config.security.authentication.interface.nport.sequence ... 2-46
config.security.authentication.interface.osms.outgoing ... 2-47
config.security.authentication.interface.osms.setKey 2-47
config.security.authentication.interface.serial.enhancedAuth 2-48
config.security.authentication.interface.show 2-48
config.security.authentication.interface.web.sequence 2-49
config.security.authentication.port.override 2-50
config.security.authentication.port.show 2-51
config.security.authentication.RADIUS 2-51
config.security.authentication.RADIUS.attempts 2-51
config.security.authentication.RADIUS.deadtime 2-52
config.security.authentication.RADIUS.deleteServer 2-52
config.security.authentication.RADIUS.server 2-53
config.security.authentication.RADIUS.show 2-54

config.security.authentication.RADIUS.timeout 2-54
config.security.authentication.switch.setSecret 2-55
config.security.authentication.user 2-56
config.security.authentication.user.add 2-56
config.security.authentication.user.delete 2-57
config.security.authentication.user.modify 2-58
config.security.authentication.user.passExpTime 2-59
config.security.authentication.user.role 2-60
config.security.authentication.user.show 2-60
config.security.fabricBinding 2-61
config.security.fabricBinding.activatePending 2-63
config.security.fabricbinding.addAttachedMembers 2-64
config.security.fabricBinding.addMember 2-64
config.security.fabricBinding.clearMemList 2-65
config.security.fabricbinding.deactivateFabBind 2-65
config.security.fabricBinding.deleteMember 2-65
config.security.fabricBinding.replacePending 2-66
config.security.fabricBinding.showActive 2-66
config.security.fabricBinding.showPending 2-67
config.security.portBinding 2-68
config.security.portBinding.bound 2-68
config.security.portBinding.show 2-69
config.security.portBinding.wwn 2-70
config.security.ssh 2-71
config.security.ssh.resetKeys 2-72
config.security.ssh.setRenegotiationMB 2-72
config.security.ssh.setState 2-72
config.security.ssh.show 2-73
config.security.switchAcl 2-74
config.security.switchAcl.addRange 2-74
config.security.switchAcl.deleteRange 2-75
config.security.switchAcl.setState 2-75
config.security.switchAcl.show 2-75
config.security.switchBinding 2-76
config.security.switchBinding.addMember 2-77
config.security.switchBinding.deleteMember 2-77
config.security.switchBinding.setState 2-78
config.security.switchBinding.show 2-78
config.security.ssl 2-79
config.security.ssl.generateKeys 2-79
config.security.ssl.resetKeys 2-80
config.security.ssl.setRenegotiationMB 2-81
config.security.ssl.setWebState 2-81

config.security.ssl.setAPIState 2-82
config.security.ssl.show 2-82
config.snmp 2-84
config.snmp.addAccessEntry 2-85
config.snmp.addAccessViews 2-86
config.snmp.addCommunity 2-86
config.snmp.addTargetParams 2-87
config.snmp.addUserEntry 2-88
config.snmp.addV3Group 2-89
config.snmp.addV1Target 2-90
config.snmp.addV2Target 2-91
config.snmp.addV3Target 2-92
config.snmp.authTraps 2-93
config.snmp.deleteAccessEntry 2-93
config.snmp.deleteCommunity 2-93
config.snmp.deleteUserEntry 2-94
config.snmp.deleteTargetEntry 2-94
config.snmp.deleteV3Group 2-94
config.snmp.sendTestTrap 2-95
config.snmp.setSNMPv3State 2-95
config.snmp.setFaMibVersion 2-95
config.snmp.setState 2-96
config.snmp.show 2-96
config.snmp.showAccessTable 2-97
config.snmp.showTargetTable 2-98
config.snmp.showUserTable 2-100
config.snmp.showV3GroupTable 2-101
config.snmp.showViewTable 2-101
config.snmp.validateUser 2-102
config.switch 2-103
config.switch.apiState 2-104
config.switch.banner 2-104
config.switch.banner.bannerText 2-104
config.switch.banner.setCLIState 2-105
config.switch.banner.setWebState 2-105
config.switch.banner.show 2-106
config.switch.domainIDOffset 2-106
config.switch.domainRSCN 2-107
config.switch.edTOV 2-108
config.switch.haMode 2-108
config.switch.insistDomainId 2-108
config.switch.interopMode 2-109
config.switch.islFSPFCost 2-109

config.switch.ltdFabRSCN 2-110
config.switch.prefDomainId 2-110
config.switch.priority 2-111
config.switch.raTOV 2-112
config.switch.rerouteDelay 2-112
config.switch.RSCNZoneIsolation 2-113
config.switch.safeZoning 2-113
config.switch.speed 2-114
config.switch.show 2-114
config.switch.webState 2-116
config.switch.zoneFlexPars 2-117
config.switch.zoningRSCN 2-117
config.syslog 2-117
config.syslog.addServer 2-118
config.syslog.deleteServer 2-118
config.syslog.setLogConfig 2-118
config.syslog.setState 2-119
config.syslog.show 2-119
config.system 2-120
config.system.contact 2-120
config.system.date 2-121
config.system.description 2-121
config.system.location 2-122
config.system.name 2-122
config.system.show 2-122
config.zoning 2-123
config.zoning.activateZoneSet 2-124
config.zoning.addPortMem 2-125
config.zoning.addWwnMem 2-126
config.zoning.addZone 2-126
config.zoning.clearZone 2-127
config.zoning.clearZoneSet 2-127
config.zoning.deactivateZoneSet 2-128
config.zoning.deletePortMem 2-128
config.zoning.deleteWwnMem 2-129
config.zoning.deleteZone 2-130
config.zoning.renameZone 2-130
config.zoning.renameZoneSet 2-130
config.zoning.replaceZoneSet 2-131
config.zoning.setDefZoneState 2-131
config.zoning.showActive 2-132
config.zoning.showPending 2-133
maint 2-134

maint.port.beacon 2-134
maint.port.reset 2-135
maint.system.beacon 2-135
maint.system.clearSysError 2-136
maint.system.ipl 2-136
maint.system.resetConfig 2-136
maint.system.setOnlineState 2-137
perf 2-138
perf.AFD 2-138
perf.AFD.HDDReport 2-138
perf.AFD.POMReport 2-139
perf.AFD.show 2-139
perf.class2 2-140
perf.class3 2-141
perf.clearStats 2-142
perf.errors 2-143
perf.link 2-144
perf.openTrunking.backPressure 2-146
perf.openTrunking.congestionThresh 2-147
perf.openTrunking.lowBBCreditThresh 2-147
perf.openTrunking.setState 2-148
perf.openTrunking.show 2-149
perf.openTrunking.unresCongestion 2-150
perf.preferredPath 2-151
perf.preferredPath.clearPath 2-152
perf.preferredPath.setPath 2-153
perf.preferredPath.setState 2-154
perf.preferredPath.showPath 2-155
perf.preferredPath.showState 2-157
perf.thresholdAlerts 2-157
perf.thresholdAlerts.counter.addAlert 2-161
perf.thresholdAlerts.counter.addPort 2-162
perf.thresholdAlerts.counter.removePort 2-163
perf.thresholdAlerts.counter.setCounter 2-164
perf.thresholdAlerts.counter.setParams 2-165
perf.thresholdAlerts.counter.show 2-166
perf.thresholdAlerts.counter.showStatisticTable 2-166
perf.thresholdAlerts.deleteAlert 2-168
perf.thresholdAlerts.setState 2-168
perf.thresholdAlerts.show 2-168
perf.thresholdAlerts.throughput.addAlert 2-170
perf.thresholdAlerts.throughput.addPort 2-171
perf.thresholdAlerts.throughput.removePort 2-172

perf.thresholdAlerts.throughput.setUtilType 2-173
perf.thresholdAlerts.throughput.setUtilPercentage 2-174
perf.thresholdAlerts.throughput.setParams 2-175
perf.thresholdAlerts.throughput.show 2-175
perf.thresholdAlerts.throughput.showUtilTypeTable 2-176
perf.traffic 2-177
show 2-179
show.activeAlias 2-179
show.all 2-180
show.auditLog 2-181
show.epFrameLog.config 2-182
show.epFrameLog.disableTrigger 2-183
show.epFrameLog.filterClassFFrames 2-183
show.epFrameLog.noWrap 2-183
show.epFrameLog.removeFilterPort 2-185
show.epFrameLog.setFilterPort 2-185
show.epFrameLog.setTrigger 2-186
show.epFrameLog.wrap 2-187
show.eventLog 2-189
show.fabricLog.noWrap 2-190
show.fabricLog.wrap 2-191
show.fabric.nodes 2-192
show.fabric.ping 2-192
show.fabric.principal 2-193
show.fabric.showRouteTable 2-194
show.fabric.topology 2-195
show.fabric.traceRoute 2-196
show.features 2-199
show.fencing.policies 2-200
show.ficonCUPZoning 2-201
show.ficonMS 2-202
show.frus 2-202
show.ip.ethernet 2-203
show.linkIncidentLog 2-204
show.loginServer 2-205
show.nameServer 2-206
show.nameServerExt 2-208
show.nameServerFC4Types 2-209
show.NPIV.config 2-210
show.openSysMS.config 2-210
show.openSysMS.platformInfo 2-211
show.openTrunking.config 2-212
show.openTrunking.rerouteLog 2-213

show.port.config 2-214
show.port.exit 2-216
show.port.info 2-218
show.port.nodes 2-219
show.port.opticData 2-221
show.port.opticEDD 2-222
show.port.opticHealth 2-223
show.port.opticInfo 2-224
show.port.profile 2-226
show.port.showPortAddr 2-229
show.port.status 2-230
show.port.technology 2-233
show.preferredPath.showPath 2-234
show.preferredPath.showState 2-236
show.security.fabricBinding 2-237
show.security.log 2-237
show.security.portBinding 2-238
show.security.switchAcl 2-239
show.security.switchBinding 2-240
show.snmp.accessTable 2-241
show.snmp.targetTable 2-242
show.snmp.userTable 2-243
show.snmp.V3GroupTable 2-244
show.snmp.viewTable 2-245
show.snmp.config 2-246
show.switch 2-247
show.system 2-250
show.syslog 2-251
show.thresholdAlerts.alerts 2-252
show.thresholdAlerts.log 2-254
show.zoning 2-256

Appendix A Error Messages

Appendix B Commands and Corresponding Releases

Glossary g-1

Index i-1

Tables

1-1 CLI Command Tree Navigation Conventions 1-3
1-2 CLI Command Tree 1-5
1-3 CLI Command Tree for the ED-5000 Director 1-22

2-1 Supported Zoning Configurations 2-124
2-2 Throughput Threshold Alerts 2-159
2-3 Alert Counters 2-159

B-1 Commands and Releases B-1

Preface

This publication is part of the documentation suite that supports the following McDATA® products:

- Sphereon™ 3016, 3032, 3216, 3232, 4300, 4400, 4500, and 4700 Fabric Switches
- Intrepid® 6064 and 6140 Directors

Who Should Use This Manual

This publication is for data center administrators or customer support personnel, who use the Command Line Interface (CLI) equipped with a Telnet Client to manage the following:

- Sphereon 3016, 3032, 3216, 3232, 4300, 4400, 4500 and 4700 Fabric Switches
- Intrepid 6064 and 6140 Directors

NOTE: A limited number of these commands are available on the ED-5000 Director.

These commands can be entered directly or combined into scripts for a host-based scripting environment. This publication assumes that the users are familiar with the following:

- Establishing and using a Telnet session
- Using the command line of a terminal
- Writing Scripts
- Networking, SAN and Zoning concepts
- McDATA's products in the managed network

The publications listed in *Related Publications* provide considerable information about both concepts and McDATA products.

Organization of This Manual

This publication is organized as follows:

- Chapter 1, *Introduction*, provides an introduction and overview of the Command Line Interface.
- Chapter 2, *CLI Commands*, describes the CLI commands, including their syntax, purpose, and parameters, as well as examples of their usage and any output that they generate.
- Appendix A, *Error Messages* lists and explains error messages that may appear while using the CLI.
- Appendix B, *Commands and Corresponding Releases* lists each command in the CLI and the release in which the command was added to the CLI.
- The *Glossary* defines terms, abbreviations, and acronyms used in this manual.
- An *Index* is also provided.

Manual Updates

Check the McDATA web site at www.mcdata.com (Resource Library-->Technical Documents-->User Manual) for possible updates or supplements to this manual.

Related Publications

Other publications that provide additional information about the products mentioned in this manual are:

- *Configuration Backup and Restore Utility Installation and User Guide (958-000370)*
- *McDATA Products in a SAN Environment - Planning Manual (620-000124)*
- *Intrepid 6064 Director Installation and Service Manual (620-000108)*
- *Intrepid 6140 and 6064 Directors Element Manager User Manual (620-000172)*
- *Intrepid 6140 Director Installation and Service Manual (620-000157)*
- *EFCM Basic User Manual (620-000240)*
- *McDATA E/OS SNMP Support Manual (620-000131)*
- *Sphereon 3016 and 3216 Fabric Switch Element Manager User Manual (620-000174)*

- *Sphereon 3016 and 3216 Fabric Switches Installation and Service Manual (620-000154)*
- *Sphereon 3032 and 3232 Fabric Switch Element Manager User Manual (620-000173)*
- *Sphereon 3032 and 3232 Fabric Switches Installation and Service Manual (620-000155)*
- *Sphereon 4300 Fabric Switch Installation and Service Manual (620-000171)*
- *Sphereon 4500 Fabric Switch Installation and Service Manual (620-000159)*
- *Sphereon 4500 Fabric Switch Element Manager User Manual (620-000175)*
- *McDATA Sphereon 4400 Switch Element Manager User Manual (620-000241)*
- *McDATA Sphereon 4700 Fabric Switch Element Manager User Manual (620-000242)*
- *McDATA Sphereon 4400 Fabric Switch Installation and Service Manual (620-000238)*
- *McDATA Sphereon 4700 Fabric Switch Installation and Service Manual (620-000239)*

Manual Conventions

The following notational conventions are used in this document:

Convention	Meaning
Bold	Keyboard keys, buttons and switches on hardware products, and screen prompts for the Command Line Interface.
Italic	Outside book references, names of user interface windows, buttons, and dialog boxes.
`Monospaced`	Command syntax, examples of commands, output.

NOTE: A note presents important information that is not hazard-related.

Where to Get Help

For technical support, McDATA end-user customers should call the phone number located on the service label attached to the front or rear of the hardware product.

McDATA's "Best in Class" Technical Support Center (TSC) and Network Operations Center (NOC) provide single points of contact for customers seeking help. These centers will research, explore, and resolve inquiries or service requests regarding McDATA products and services. The centers are staffed 24 hours a day, 7 days a week, including holidays.

McDATA Corporation

11802 Ridge Parkway

Broomfield, CO 80021

For SAN Router issues, contact the Network Operations Center (NOC) at:

(800) 752-8061 or (763) 268-6600.

For all other products, contact the Technical Support Center at:

(800) 752-4572 or (720) 558-3910.

E-mail: support@mcdata.com

To expedite warranty entitlement, please have your product serial number available.

For warranty or contract entitlement, contact (800) 545-5773.

NOTE: Customers who purchased the hardware product from a company other than McDATA should contact that company's service representative for technical support.

Forwarding Publication Comments

We sincerely appreciate any comments about this publication. Did you find this manual easy or difficult to use? Did it lack necessary information? Were there any errors? Could its organization be improved?

Please send your comments via e-mail, our home page, or FAX. Identify the manual, and provide page numbers and specific detail. Thank you.

E-mail:	pubsmgr@mcdata.com
Home Page:	http://www.mcdata.com
Fax:	Technical Communications Manager (720) 558-8999

Ordering Publications

To order a paper copy of this manual, submit a purchase order as described in Ordering McDATA Documentation Instructions, which is found on McDATA's web site at the following location:

www.mcdata.com/downloads/tpub/other/customer_ordering_instructions.pdf

To obtain documentation CD-ROMs, contact your sales representative.

Trademarks

The following terms, indicated by a registered trademark symbol (®) or trademark symbol (™) on first use in this publication, are trademarks of McDATA Corporation in the United States, other countries, or both:

Registered Trademarks	Trademarks
Fabricenter®	E/OS™
HotCAT®	Eclipse™
Intrepid®	Fibre Channel Director™
McDATA®	OPENconnectors™
OPENready®	SANvergence™
SANavigator®	Sphereon™
SANtegrity®	

All other trademarked terms, indicated by a registered trademark symbol (®) or trademark symbol (™) on first use in this publication, are trademarks of their respective owners in the United States, other countries, or both.

1 Introduction

This chapter introduces the Command Line Interface (CLI) and describes the essentials for using the CLI commands.

- *Command Line Interface Overview* 1-2
- *Entering Command Line Interface Commands* 1-2
- *Logging In and Logging Out* 1-16
- *Using the commaDelim Command* 1-19
- *Handling CLI Errors* 1-19
- *Using CLI Help* 1-20
- *Commenting Scripts* 1-21
- *ED-5000 Director* 1-22
- *Telnet Session* 1-23

Command Line Interface Overview

The Command Line Interface (CLI) is a feature that can be used to manage switches and directors. It provides an alternative to the Graphical User Interface (GUI) and web-based (HTTP) interface products.

The CLI can only be used through a Telnet client session in an out-of-band management environment, using the Ethernet port in the director, switch, or SSH. Any hardware platform that supports the Telnet client software can be used.

The primary purpose of the CLI is to automate management of a large number of switches with the use of scripts. CLI commands can also be entered directly at a command line.

Because the CLI is not an interactive interface, no prompts are displayed to guide the user through a task. If an interactive interface is needed, use the GUI-based or web-based SAN management applications instead of the CLI.

Entering Command Line Interface Commands

The CLI commands can be entered directly at the command line of a terminal or coded in a script.

Note that the output examples shown in the other sections of this publication presume that commaDelim is off. For description on commadelim, refer to *Using the commaDelim Command* on page 1-19.

NOTE: CLI commands are not case sensitive.

Documentation Conventions

Throughout this publication, periods are used to separate the components of a command name. However, the periods cannot be included when the command is actually entered at the terminal or coded in a script. (For description on how to enter commands, refer to *Navigation of the CLI Command Tree* on page 1-14.)

The periods are automatically generated by the CLI while moving through the CLI Command sequence.

```
Root> config
Config> port
Config.Port>
```

Navigation Conventions

Basic command line navigation conventions are supported. Table 1-1 includes the asynchronous commands that are recognized by the CLI.

Table 1-1 CLI Command Tree Navigation Conventions

Character Sequence	Common Name	Action or Description
<CR>	Carriage Return	Pass a completed line to the parser.
<DEL>	Delete	Backspace one character and delete the character.
<NL>	New Line	Pass a completed line to the parser.
<SP>	Space	Used to separate keywords.
#	Pound Sign	Used to designate comments in a script.
?	Question Mark	Provide help information.
“	Quotation Mark	Used to surround a single token.
^A	Control-A	Position the cursor to the start of the line.
^B	Control-B	Position the cursor left one character.
^D	Control-D	Delete the current character.
^E	Control-E	Position the cursor to the end of the line.
^F	Control-F	Position the cursor right one character.
^H	Control-H	Backspace one character and delete the character.
^I	Tab	Complete the current keyword.
^K	Control-K	Delete to the end of the line.
^L	Control-L	Redraw the line.

Table 1-1 CLI Command Tree Navigation Conventions (Continued)

Character Sequence	Common Name	Action or Description
^N	Control-N	Move down one line in the command history.
^P	Control-P	Move up one line in the command history.
^R	Control-R	Redraw the line.
^U	Control-U	Clear the input and reset the line buffer.
^X	Control-X	Clear the input and reset the line buffer.
<ESC>[A	Up Arrow	Move up one line in the command history.
<ESC>[B	Down Arrow	Move down one line in the command history.
<ESC>[C	Right Arrow	Position the cursor right one character.
<ESC>[D	Left Arrow	Position the cursor left one character.

Command Tree

The command tree of the CLI begins from the root. Table 1-2 shows the CLI command tree. For description of the commands config, maint, perf, and show, refer to Chapter 2, *New and Changed Commands*.

The following commands are not listed in the command tree, but are globally available and are documented in this chapter:

- login (see *login* on page 1-17)
- logout (see *logout* on page 1-18)
- commaDelim (see *Using the commaDelim Command* on page 1-19)

Table 1-2 shows the command tree hierarchy from the root, reading from left to right.

Table 1-2 CLI Command Tree

config----------	alias ----------	activatePending
		add
		clearPending
		delete
		replacePending
		setCLIState
		setWebState
		showActive
		showPending
	enterpriseFabMode------	setState
	features ----------	enterpriseFabMode
		ficonMS
		installKey
		NPIV
		openSysMS
		openTrunking
		show
	fencing----------	addPolicy
		addPort
		deletePolicy
		removePort
		setParams
		setState
		show
		showTypeTable
	ficonCUPZoning---------	addControlHost
		deleteControlHost
		setState
		show
	ficonMS----------	setMIHPTO
		setState
		show
	ip----------	ethernet
		lineSpeed
		show

Table 1-2 CLI Command Tree (Continued)

ip----------	setHostCtrlState				
NPIV----------	maxPortIDs				
	setState				
	show				
NSTools----------	clearSnapshot				
	saveSnapshot				
	showSnapDiff				
	showSnapshot				
openSysMS----------	setHostCtrlState				
	setState				
port ----------	blocked				
	fan				
	mode				
	name				
	rxCredits				
	show				
	showCredits				
	showPortAddr				
	speed				
	swapPortByAddr				
	swapPortByNum				
	type				
security----------	authentication----------	interface----------	api----------	outgoing	
				sequence	
			cli----------	sequence	
			eport----------	outgoing	
				sequence	
			nport----------	outging	
				sequence	
			osms----------	outgoing	
				setKey	
			serial----------	enhancedAuth	
			show		
			web----------	sequence	
		port----------	override		
			show		

Table 1-2 CLI Command Tree (Continued)

security----------	authentication----------	radius----------	attempts
			deadtime
			deleteServer
			server
			show
			timeout
		switch----------	setSecret
		user----------	add
			delete
			modify
			passExpTime
			role
			show
security ----------	fabricBinding ----------	activatePending	
		addAttachedMembers	
		addMember	
		clearMemList	
		deactivateFabBind	
		deleteMember	
		replacePending	
		showActive	
		showPending	
	portBinding ----------	bound	
		show	
		wwn	
	ssh----------	resetKeys	
		setRenegotiationMB	
		setState	
		show	
	switchAcl----------	addRange	
		deleteRange	
		setState	
		show	
	switchBinding ----------	addMember	
		deleteMember	
		setState	

Table 1-2 CLI Command Tree (Continued)

		show
	ssl ----------	generateKeys
		resetKeys
		setAPIState
		setRengotiationMB
		setWebState
		show
snmp ----------	addAccessEntry	
	addAccessViews	
	addCommunity	
	addTargetParams	
	addUserEntry	
	addV1Target	
	addV2Target	
	addV3Group	
	addV3Target	
	authTraps	
	deleteAccessEntry	
	deleteCommunity	
	deleteTargetEntry	
	deleteUserEntry	
	deleteV3Group	
	sendTestTrap	
	setFaMibVersion	
	setSNMPv3State	
	setState	
	show	
	showAccessTable	
	showTargetTable	
	showUserTable	
	showV3GroupTable	
	showViewTable	
	validateUser	
switch ----------	apiState	
	banner----------	bannerText
		setCLIState

Table 1-2 CLI Command Tree (Continued)

		setWebState
		show
	domainIDOffset	
	domainRSCN	
	edTOV	
	haMode	
	islFSPFCost	
	insistDomainId	
	interopMode	
	ltdFabRSCN	
	prefDomainId	
	priority	
	raTOV	
	rerouteDelay	
	RSCNZoneIsolation	
	safeZoning	
	speed	
	show	
	webState	
	zoneFlexPars	
	zoningRSCN	
syslog ----------	addServer	
	deleteServer	
	setLogConfig	
	setState	
	show	
system ----------	contact	
	date	
	description	
	location	
	name	
	show	
zoning ----------	activateZoneSet	
	addPortMem	
	addWwnMem	
	addZone	

Table 1-2 CLI Command Tree (Continued)

		clearZone
		clearZoneSet
		deactivateZoneSet
		deletePortMem
		deleteWwnMem
		deleteZone
		renameZone
		renameZoneSet
		replaceZoneSet
		setDefZoneState
		showPending
		showActive
maint ----------	port ----------	beacon
		reset
	system ----------	beacon
		clearSysError
		ipl
		resetConfig
		setOnlineState
perf----------	AFD ----------	HDDReport
		POMReport
		Show
	class2	
	class3	
	clearStats	
	errors	
	link	
	openTrunking ----------	backPressure
		congestionThresh
		lowBBCreditThresh
		setState
		show
		unresCongestion

Table 1-2 CLI Command Tree (Continued)

	preferredPath ----------	clearPath	
		setPath	
		setState	
		showPath	
		showState	
	thresholdAlerts --------	counter ----------	addAlert
			addPort
			removePort
			setCounter
			setParams
			show
			showStatisticTable
		deleteAlert	
		setState	
		show	
		throughput ----------	addAlert
			addPort
			removePort
			setUtilType
			setUtilPercentage
			setParams
			show
			showUtilTypeTable
	traffic		
show ----------	activeAlias		
	all		
	auditLog		
	epFrameLog----------	config	
		disableTrigger	
		filterClassFFrames	
		noWrap	
		removeFilterPort	
		setFilterPort	
		setTrigger	
		wrap	
	eventLog		

Table 1-2 CLI Command Tree (Continued)

fabric----------	nodes
	ping
	principal
	showRouteTable
	topology
	traceroute
fabricLog----------	noWrap
	wrap
features	
fencing----------	policies
ficonCUPZoning	
ficonMS	
frus	
ip ----------	ethernet
linkIncidentLog	
loginServer	
nameServer	
nameServerExt	
nameServerFC4Types	
NPIV----------	config
openSysMS----------	config
	platformInfo
openTrunking ----------	config
	rerouteLog
port ----------	config
	exit
	info
	nodes
	opticData
	opticEDD
	opticHealth
	opticInfo
	profile
	showPortAddr
	status
	technology

Table 1-2 CLI Command Tree (Continued)

preferredPath ----------	showPath
	showState
security----------	fabricBinding
	log
	portBinding
	switchAcl
	switchBinding
snmp ----------	accessTable
	config
	targetTable
	userTable
	V3GroupTable
	viewTable
switch	
syslog	
system	
thresholdAlerts--------	alerts
	log
zoning	

With the exception of the zoning commands, all the others are listed in alphabetical order.

The commands can be entered in any order, depending on the results you want. However, the order shown in Table 1-2, *CLI Command Tree*, page 1-5 for the zoning commands is a typical order in which the zoning commands are entered.

Note that the order in which commands are entered determines the order in which the show commands display the values. For examples of *show* commands output, refer to Chapter 2, *New and Changed Commands*.

Navigation of the CLI Command Tree

To move from the root through any of the four extended branches, enter the name of the next branch as shown in Table 1-2, *CLI Command Tree*, page 1-5.

For example, to use the `config.port.name` command to configure the name for port 4 on the switch, enter the series of commands as follows:

```
Root> config
Config> port
Config.Port> name 4 "Sam's Tape Drive"
```

If you want to set the beaconing state of port 4 using the `enter the maint.port.beacon` command, enter the following series of commands:

```
Config.Port> ..
Config> ..
Root> maint
Maint> port
Maint.Port> beacon 4 true
```

Note that you must return all the way to the root of the tree to transition to another extended branch. When traversing back to the root, the name of each branch cannot be used. Instead, use the double-dot command (two periods) to move back towards the root. Note that only one double-dot command may be entered at a time.

You can use the `root` command to jump directly to the root of the CLI command tree. The previous example, which shows stepping back to the root with the double-dot command, is simplified as follows:

```
Config.Port> root
Root> maint
Maint> port
Maint.Port> beacon 4 true
```

As an easier and simpler method, you can enter the complete command syntax from the `Root>` prompt each time. For example, to issue the `config.port.name` command and then the `maint.port.beacon` command, enter the following commands:

```
Root> config port name 4 "Sam's Tape Drive"
Root> maint port beacon 4 true
```

While entering the complete command syntax, the prompt stays at the root. The use of complete command syntax is particularly useful when writing scripts.

When coding a script, remember to code the appropriate character sequences, which are described in *Navigation Conventions* on page 1-3.

```
Root> config port name 4 "Sam's Tape Drive"<CR>
Root> maint port beacon 4 true<CR>
```

Limitation on Movements

The commands that are entered are recorded in a history log.

The history log has limitations under the following conditions:

- If a command has more than 60 characters, the command runs, but the command is not recorded in the history log, and the position in the tree does not change, as shown in the following example.

```
Root> config zoning addWwnMem TheUltimateZone 10:00:00:00
:C9:22:9B:64
Root>
```

Because the command is not recorded in the history, a subsequent asynchronous command (navigation command) cannot depend on it.

- Whenever the position in the CLI command tree moves to a new branch (for example, `config` to `maint`, `config` to `config.port`, or `config.port` to `config`), the history log is cleared. In this case, any asynchronous commands (for example, the up-arrow command <ESC>[A or the up-arrow keyboard symbol) cannot move the position back towards the root, as shown in this example:

```
Root> config
Root.Config> port
Root.Config.Port> <ESC>[A
Root.Config.Port>
```

Parameters

Some command parameters accept character strings that include spaces. Quotation marks are required when a string includes spaces.

```
Config.System> location Building_24_Room_16

Config.System> location "Building 24 Room 16"
```

If spaces are not included in a parameter that accepts a string, the quotation marks are not required around that string.

To include quotation marks in a string, use the escape character (\) before the quotation marks.

```
Config.System> location "Building 24 \"Joe's PlayLab\""
```

A null string can be created by using the quotation marks without any space between them.

```
Config.System> location ""
```

Output

Output from the CLI commands is limited to the standard 80 columns supported by most Telnet interfaces. The output is left-aligned.

Logging In and Logging Out

The CLI allows a single Telnet client to be connected to the switch. If a Telnet client logs out or is inactive for 15 minutes, the client's access times out and another Telnet client may log in.

The Telnet client (user) must log in every time the director or switch is restarted because the current user's access is lost. Examples of a restart include an initial program load (IPL) and any power-off situation.

Types of Users

The CLI supports two user access rights: *administrator* and *operator*.

Administrators can use all the commands described in this publication.

Operators can use only the `perf` and `show` branches of the CLI command tree (for example, the `perf.traffic` and `show.system` commands) with the following exceptions:

- `show.preferredPath`
- `show.security`
- `show.thresholdAlerts`

Operators can also execute the globally available commands (`login`, `logout`, and `commaDelim`).

Passwords and Secrets

Some commands require the user to enter a password or secret before the command can be executed.

Passwords can be ASCII characters in the range of 32 to 126.

Secrets can be any ASCII character (0-255) and are entered as follows:

- Non-printable and extended ASCII characters can be entered by using a backslash.
- Two hexadecimal characters must follow the backslash.
- All printable ASCII characters can be entered using the keyboard or using its hexadecimal value except for the backslash character. If a backslash is desired as part of the password its hexadecimal representation must be used.

NOTE: Spaces are valid, but the whole password or secret must be in quotes, or you need to use the hexadecimal value for the quote. Also, when you login to CLI, you will need to use quotes around the password again.

The following are examples of valid secrets.

```
simplesecret****
```

This is an example of a secret that does not use any special characters.

```
\40\72\A3\F9\12\13\14\15\16\17\18\19\55\33\87\42
```

This is an example of a 4 character length secret that is configured using the hexadecimal representation.

```
a9p\40\40xx\44\88kutfe\89h
```

This is an example of a 7 character length secret that are composed of a mix using hexadecimal and the printable ASCII characters.

Globally available commands

The following commands are available globally to all types of users. In addition, these commands can be entered from any position in the CLI command tree.

login

Syntax `login`

Purpose This command allows a Telnet client to connect to the switch.

Description This command allows the user to log in with either administrator or operator access rights.

The login command is called automatically by the CLI whenever a new Telnet session is activated or new administrator access rights are configured.

Users are prompted to change the password after logging in with the default password (*password*). However, at the next login, they will be required to change the password if the default password is still being used.

A user name and password can be set by the administrator through the `config.security.authentication.user.add` command or through the `config.security.authentication.user.modify` command.

NOTE: Access rights chosen for the CLI are completely independent of the other product interfaces, for example, SNMP or McDATA product interfaces.

Parameters — This command has no parameters.

Command Examples

```
login
Username: Administrator
Password: password

login
Username: Operator
Password: password
```

logout

Syntax — `logout`

Purpose — This command allows a Telnet client to disconnect from the switch.

Description — This command logs out the single Telnet client connected to the switch. This command can be entered at any point in the command tree.

Parameters — This command has no parameters.

Command Examples

```
Root> logout

Config> logout

Config.Port> logout
```

Using the commaDelim Command

Note that the output examples shown in the other sections of this publication presume that commaDelim is off.

commaDelim

Syntax `commaDelim enable`

Purpose This command displays information in comma-delimited, rather than tabular format. Tabular format is the default.

Description This command can be entered at any point in the command tree.

Parameter This command has one parameter:

enable	Specifies the comma-delineated state for output. Valid values are *true* and *false*. Boolean 1 and 0 may be substituted as values.

Command Examples

```
Root> commaDelim true

Config> commaDelim 1

Config.Port> commaDelim false
```

Output Example Output displayed in commaDelim mode is as follows:

```
Root> show eventLog
Date/Time,Code,Severity,FRU,Event Data,
04/12/01 10:58A,375,Major,CTP-0,00010203 04050607 08090A0B 0C0D0E0F,
04/12/01 10:58A,375,Major,CTP-0,00010203 04050607 08090A0B 0C0D0E0F,
04/12/01  9:58A,385,Severe,CTP-0,00010203 04050607 08090A0B 0C0D0E0F,
04/11/01  7:18P,395,Severe,CTP-0,00010203 04050607 08090A0B 0C0D0E0F,
```

Handling CLI Errors

Two types of errors detected by the CLI are:

- An error associated with the interface: For example, a keyword is misspelled or does not exist.

```
Root> confg
Error 234: Invalid Command
```

- An error associated with fabric or switch issues: For example, a parameter error is detected by the switch where port 24 is entered for a switch that supports only 16 ports:

```
Root> config port name 24 "Port 24"
Error 218: Invalid Port Number
```

In either case, the command is ignored. The CLI remains at the same point before the command was entered.

The error messages, including the error number and error description, are listed in Appendix A, *Error Messages*.

Using CLI Help

Using the question mark (?) within a command helps obtain information about that command.

- If the question mark is used in place of a command keyword, all the keywords at that level of the CLI command tree appear:

```
Root> config system ?
Command identified
contact           - Set the system contact attribute
date              - Set the system date and time
description       - Set the system description attribute
location          - Set the system location attribute
name              - Set the system name attribute
show              - Display the system configuration
```

- If the question mark is used at the end of a recognized command, any parameters for that command appear:

```
Root> config port name ?
                  - name <portNumber> <portName>
```

- If the question mark is used after one or more characters of a keyword, any keywords at that level of the CLI command tree appear:

```
Root> config s?
security snmp switch system
```

Commenting Scripts

Use the pound sign (#) to add comments in a script file. The pound sign must be the first character in the line; the CLI ignores everything after the pound sign in that line. The following lines are valid:

```
Root> #Change port 3 to an E_Port<CR>
Root> config port<CR>
config.port> ##################<CR>
config.port> ## Begin Script ##<CR>
config.port> ##################<CR>
```

The pound sign cannot be used after any other characters (a command, for example) to start a comment. The following is an invalid script line:

```
Root> maint system beacon true # Turn on beaconing<CR>
```

To correct the previous script line, move the comment either before or after the line with the command.

Both the following examples are valid:

```
Root> # Turn on beaconing<CR>
Root> maint system beacon true<CR>

Root> maint system beacon true<CR>
Root> # Turn on beaconing<CR>
```

NOTE: Limit comments to 200 characters per line. Comments of over 200 characters in length may cause unpredictable system behavior.

ED-5000 Director

A subset of CLI commands described in this publication is available on the ED-5000 Director™. The *Globally available commands* are described previously in this chapter.

The list of commands for ED-5000 Director are listed in Table 1-3. For a description of these commands, refer to Chapter 2, *New and Changed Commands*.

Table 1-3 CLI Command Tree for the ED-5000 Director

config ----------	security ----------	userRights ----------	administrator
			operator
			show
maint ----------	system ----------	resetConfig	
show ----------	ip ----------	ethernet	
	port ----------	config	
		info	
		status	
	switch		
	system		
	zoning		

Telnet Session

The CLI can be accessed through a Telnet client session in an out-of-band management environment, using the Ethernet port in the director/switch or Secure Shell (SSH).

Any hardware platform that supports the Telnet client software can be used to enter the CLI commands.

Use the *Configure* option in the GUI-based or web-based interfaces to enable/disable Telnet access. Telnet access is enabled by default. Any changes to the enabled state of the Telnet server are retained through system restarts and power cycles.

Ethernet Connection Loss

If the Ethernet cable is disconnected from the director or switch during a Telnet session, do one of the following:

- Replace the Ethernet cable before the client connection times out. The Telnet session will continue.
- Wait 15 minutes until the client connection times out; then replace the Ethernet cable and restart the connection.
- If the client connection has already timed out, replace the Ethernet cable. Open a GUI-based or web-based interface SAN-management window. Toggle the enabled state of the CLI, thereby clearing the client connection. Restart the client connection.

After you have re-established the client connection, verify the completeness and accuracy of your configuration.

2

CLI Commands

This chapter describes the Command Line Interface (CLI) commands, including their syntax, purpose, and parameters, as well as examples of their usage and any output that they generate.

- *Command Overview* 2-2
- *New and Changed Commands* 2-2
- *config* 2-3
- *maint* 2-134
- *perf* 2-138
- *show* 2-179

Command Overview

The listed commands are arranged in alphabetical order. The commands can be entered in any order, depending on the results desired as per the command line tree.

The various *show* commands are usually entered at the end of a group of other commands to verify configuration changes.

New and Changed Commands

New Commands

The following CLI commands are new for this edition of the *E/OS Command Line Interface User Manual*:

- *config.alias* on page 2-3
- *config.alias.activatePending* on page 2-4
- *config.alias.add* on page 2-5
- *config.alias.clearPending* on page 2-5
- *config.alias.delete* on page 2-5
- *config.alias.replacePending* on page 2-6
- *config.alias.setCLIState* on page 2-6
- *config.alias.setWebState* on page 2-6
- *config.alias.showActive* on page 2-7
- *config.alias.showPending* on page 2-8
- *show.activeAlias* on page 2-179
- *show.openSysMS.platformInfo* on page 2-211

config

The config branch of the CLI command tree contains commands that set parameter values on the switch or director. These values are not temporary (session) values but are retained across power cycles.

The commands in the config branch can only be accessed by a user logging in as administrator. CLI commands are activated on the switch immediately except under certain conditions, which are noted in the command description.

In general, the config naming commands (except for the *config.zoning* commands) use the USASCII character set. All of the characters in this 128-character set (the first 7-bit subset of the ISO-8859-1 Latin-1 character set) are valid. Any exceptions are noted in the specific command descriptions.

config.alias

The alias command on the configuration branch enters the alias configuration branch. All commands under this branch operate on a WWN and its named association. The association is unique to the entire fabric and the associations are shared across the fabric.

All operations on WWNs and their associations are performed on a pending area. The user will have to explicitly activate changes for them to be saved and distributed across a network.

The pending association, by default, is empty. The user has to explicitly load the active association list using the `replacePending` command. Operations will be able to resume only after this has been done. The user will have to activate the associations after successful completion of the changes.

This setting is specific to the switch on which you run this command.

In a fabric, only aliases are shared fabric wide. The *setWebState* and *setCliState* setting enables the usage of aliases instead of WWNs only for that particular switch. This command enables the usage of alias or WWN only in the user interfaces. Internally, aliases are replaced with WWNs and all processing takes place using WWNs only.

If the use of alias is enabled in the CLI interface, then the following commands will change such that the alias can be taken as a parameter instead of WWN in the CLI interface.

- fabricbinding.addmember

- fabricbinding.deletemember
- portbinding.addmember
- portbinding.deletemember
- switchbinding.addmember
- switchbinding.deletemember
- zoning.addwwnmember
- zoning.deletewwnmember
- security.authentication.user.add
- ficoncupzoning.addControlhost
- ficoncupzoning.deletecontrolhost
- show.security.portbinding
- show.port.profile
- show.port.info
- show.fabric.ping

In addition, for all commands that display a WWN, an alias will be displayed in its place if there is one configured.

config.alias.activatePending

Syntax `activatePending`

Description This command saves the pending alias association list to memory and distributes it in the fabric. This should be the final command executed after configuring all the desired WWN to alias association in the pending area.

Parameters This command has no parameters.

Command Example

```
Root> config alias activatePending
```

config.alias.add

Syntax `add wwn alias`

Description This command adds the association that exists between a WWN and its alias from the pending alias database. This command can be run only after copying the active association list into the pending list using the `replacePending` command. The parameter should be any one member of the association – either the WWN or the alias.

Parameters This command has two parameters:

wwn	The WWN to associate with the alias. WWNs cannot be all zeros.
alias	Alias is a string up to 24 characters. Embedded blanks are allowed. The first character cannot be a blank and trailing blanks will be removed. An alias cannot be a WWN.

Command Example

```
Root> config alias add 1:1:1:1:1:1:1:1 AliasName
```

config.alias.clearPending

Syntax `clearPending`

Description This command clears the user-modified changes in the pending alias association list.

Parameters This command has no parameters.

Command Example

```
Root> config alias clearPending
```

config.alias.delete

Syntax `delete parameter`

Description This command removes the association that exists between a WWN and its alias from the pending alias database. This command can be run only after copying the active association list into the pending list using the `replacePending` command. The parameter should be any one member of the association – either the WWN or the alias.

Parameters This command has one parameter.

parameter	This can either be WWN or alias.

Command Example

```
Root> config alias delete 11:22:33:44:55:66:77:88
```

or

```
Root> config alias delete AliasName
```

config.alias.replacePending

Syntax

```
replacePending
```

Description This command copies the list of the active alias associations to the pending alias association list.

Parameters This command has no parameters.

Command Example

```
Root> config alias replacePending
```

config.alias.setCLIState

Syntax

```
setCLIState state
```

Description This command configures the usage of aliases in place of WWNs in the CLI interface.

Parameters This command has one parameter.

state	The enabled/disabled state for displaying aliases in the CLI interface. This parameter can be set to *enable* or *disable*. Boolean *1* and *0* values may also be substituted.

Command Example

```
Root> config alias setCLIState 1
or
Root> config alias setCLIState disable
```

config.alias.setWebState

Syntax

```
setWebState state
```

Description This command configures the state for displaying aliases in place of WWNs in the web interface.

Parameters This command has one parameter:

state	The enabled/disabled state for displaying Aliases in the Web interface. This parameter can be set to *enable* or *disable*. Boolean *1* and *0* values may also be substituted.

Command Example

```
Root> config alias setWebState 1
or
Root> config alias setWebState disable
```

config.alias.showActive

Syntax `showActive`

Description This command displays all the alias entries that are available in the active alias database.

Parameters This command has no parameters.

Output This command displays the currently associated WWNs and their aliases that are in the active association list. Also, it displays the current associations count and possible total associations count.

Output Example

```
Config.Alias> showActive
CLI Alias enabled state:        Enabled
Web Alias enabled state:        Disabled
Total associations possible:    250
Current associations:           4
WWN                     Alias
----------------------  ----------------
11:22:33:44:55:66:77:11  FirstSwitch
22:22:33:44:55:66:77:12  SecondSwitch
33:22:33:44:55:66:77:13  Row2Rack1Lower
44:22:33:44:55:66:77:11  Row2Rack1Upper
```

config.alias.showPending

Syntax `showPending`

Description This command displays the alias entries that are available in the pending alias database.

Parameters This command has no parameters.

Output This command displays the currently associated WWNs and their aliases that are in the active association list. Also, it displays the current associations count and possible total associations count.

Output Example

```
Config.Alias> showPending
CLI Alias enabled state:        Disabled
Web Alias enabled state:        Disabled
Total Associations Possible:    250
Current Associations:           4
WWN                     Alias
----------------------  -----------------
11:22:33:44:55:66:77:11  FirstSwitch
22:22:33:44:55:66:77:12  SecondSwitch
33:22:33:44:55:66:77:13  Row2Rack1Lower
44:22:33:44:55:66:77:11  Row2Rack1Upper
```

config.enterpriseFabMode.setState

Syntax `setState enterpriseFabModeState`

Purpose This command sets the Enterprise Fabric Mode state for the fabric. The SANtegrity™ feature key must be installed to activate the Enterprise Fabric Mode state.

NOTE: The command *config.features.enterpriseFabMode* on page 2-9 has functionality that is identical to this command.

Parameters This command has one parameter:

enterpriseFabModeState	Specifies whether enterpriseFabMode is active. Valid values are *activate* and *deactivate*. Boolean 1 and 0 may be substituted as values.

Command Example

```
Root> config enterpriseFabMode setState 1
```

NOTE: Open Trunking should be disabled before activating Enterprise Fabric Mode.

config.features.enterpriseFabMode

Syntax

```
enterpriseFabMode enterpriseFabModeState
```

Purpose This command sets the Enterprise Fabric Mode state for the fabric. The SANtegrity™ feature key must be installed to activate the Enterprise Fabric Mode state.

Parameters This command has one parameter:

enterpriseFabModeState	Specifies whether enterpriseFabMode is active. Valid values are *activate* and *deactivate*. Boolean 1 and 0 may be substituted as values.

Command Example

```
Root> config features enterpriseFabMode 1
```

NOTE: The command *config.enterpriseFabMode.setState* on page 2-8 has functionality that is identical to this command

config.features.ficonMS

Syntax `ficonMS ficonMSState`

Purpose This command enables or disables the FICON Management Server. The FICON Management Server feature key must be installed in order to enable the FICON Management Server State.

Sphereon 4300 and Sphereon 4500 switches do not accept this command. This command is displayed on Sphereon 3016 and 3216 switches only if the feature key is installed.

NOTE: If the FICON Management Server is enabled, the default management style is the FICON Management Style. The Open Systems Management Style cannot be used.

Parameters This command has one parameter:

ficonMSState	Specifies whether the FICON Management Server is enabled. Valid values are *enable* and *disable*. Boolean 1 and 0 may be substituted as values.

Command Example

```
Root> config features ficonMS 1
```

NOTE: The command *config.ficonMS.setState* on page 2-23 has functionality that is identical to this command.

config.features.installKey

Syntax `installKey featureKey`

Purpose This command installs a feature set based on a provided feature key. The switch can be either offline or online when this command is executed.

NOTE: If any currently installed features are being removed by the new feature key, the switch must be offline when the command is given.

Parameters This command has one parameter:

featureKey	Specifies the key you have received to enable an optional software feature on a specific product. A feature key is a string of case-sensitive, alphanumeric ASCII characters. The number of characters may vary in the format; however, the key must be entered exactly, including the hyphens. An example of a feature key format is XxXx-XXxX-xxXX-xX.

Command Example

```
Root> config features installKey AaBb-CCdD-eeFF-gH
```

config.features.NPIV

Syntax

```
setState NPIVState
```

Purpose This command enables or disables the NPIV feature. The NPIV feature key must be installed in order to enable this feature.

Parameters This command has one parameter.

NPIVState	Valid values are *enable* and *disable*. Boolean 1 and 0 may be substituted as values.

Command Example

```
Root> config features NPIV enable
```

NOTE: The command *config.NPIV.setState* on page 2-27 has functionality that is identical to this command.

config.features.openSysMS

Syntax

```
openSysMS openSysMSState
```

Purpose This command enables or disables Open Systems Management Server (OSMS). OSMS is a feature that allows host control and inband management of the switch or director through a management application that resides on an Open-Systems Interconnection (OSI) device.

Parameters This command has one parameter:

osmsState	Specifies whether the Open Systems Management Server is enabled. Valid values are *enable* and *disable*. Boolean 1 and 0 may be substituted as values.

Command Example

```
Root> config features openSysMS 1
```

NOTE: The command *config.openSysMS.setState* on page 2-30 has functionality that is identical to this command.

config.features.openTrunking

Syntax

```
openTrunking openTrunkingState
```

Purpose This command enables or disables the OpenTrunking feature. The OpenTrunking feature key must be installed in order to enable open trunking.

Parameters This command has one parameter:

openTrunkingState	This parameter can be set to *enable* or *disable* the OpenTrunking feature. Boolean 1 and 0 may be substituted as values.

Command Example

```
Root> config features openTrunking 1
```

NOTE: The command *perf.openTrunking.setState* on page 2-148 has functionality that is identical to this command.

config.features.show

Syntax

```
show
```

Purpose This command shows the product feature information configured for this director or switch.

Parameters This command has no parameters.

Command Example

```
Root> config features show
```

Output The product feature data is displayed as a table that includes the following properties.

Installed Feature Set	The feature set installed using a feature key. Only installed keys are displayed.
Feature	Individual features within each set. In many cases, there is only one feature within each feature set.
State	The state of the individual feature. Fabric-wide features are displayed as *Active/Inactive*. Features related to the switch are displayed as *Enabled/Disabled*.
Exp	The remaining evaluation time in days for the trial feature.

Output Example The output from the *config.features.show* command appears as follows.

```
Installed Feature Set           Feature                         State     Exp
-----------------------------  -----------------------------  --------  -----
Security Package
  SANtegrity Binding            Switch Binding                 Enabled
  SANtegrity Binding            Fabric Binding                 Active
  SANtegrity Binding            Enterprise Fabrics             Active
  SANtegrity Authentication     SANtegrity Authentication      Enabled

FICON Cascading Bundle
  FICON Management Server       FICON Management Server        Enabled
  FICON CUP Zoning              FICON CUP Zoning               Active
  OpenTrunking                  OpenTrunking                   Active
NPIV Trial*                     NPIV Trial*                    Enabled*  27*

*You need to contact your local dealer to get the full feature.
```

NOTE: The command *show.features* on page 2-199 has functionality that is identical to this command.

config.fencing

The fencing command on the configuration branch enters the fencing configuration branch. All commands under this branch operate on the port fencing feature.

config.fencing.addPolicy

Syntax `addPolicy name`

Purpose This command configures a new fencing policy and assigns it a name. The new policy is assigned default settings, which must be changed before the policy is activated.

Refer to the command *config.fencing.setParams* on page 2-17 for default settings.

Parameters This command has one parameter.

name	Specifies the name of the new fencing policy. This name can consist of any printable USASCII characters up to a maximum length of 63 characters. This name is case-sensitive.

Command Example

```
Root> config fencing addPolicy Policy2
```

NOTE: The maximum number of policies supported is 14.

config.fencing.addPort

Syntax `addPort name portNumber`

Purpose This command adds a port to the specified fencing policy.

Parameters This command has two parameters:

name	The name of the fencing policy.
portNumber	The port number to add to the fencing policy, or *all*, which will add all of the individual ports to the fencing policy. Valid values for the port number are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 0–31 for the Sphereon 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

NOTE: A range of ports is not accepted as a valid input to this command (e.g., "0-29" is not acceptable).

The port values can also be substituted with one of the following keywords that will remove all the ports from the alert, and then use a specific type of port instead of individual port numbers.

Valid values are:

- *eport* – This adds all active E_ports.
- *fport* – This adds all active F_ports.
- *flport* – This adds all active F_Ports and FL_ports (This applies to Sphereon 4400, Sphereon 4300, Sphereon 4500 and Sphereon 4700 switches).

NOTE: A fencing policy can contain either port types or individual port numbers only.

Command Example

```
Root> config fencing addPort 24
Root> config fencing addPort eport
```

config.fencing.deletePolicy

Syntax `deletePolicy name`

Purpose This command deletes the specified fencing policy. Only disabled fencing policies can be deleted.

Parameters This command has one parameter:

name	The name of the fencing policy. You can also enter *all* for this argument. This will delete all of the configured fencing policies.

Command Example

```
Root> config fencing deletePolicy Policy1
```

config.fencing.removePort

Syntax `removePort name portNumber`

Purpose This command removes a port from the specified fencing policy.

Parameters This command has two parameters:

name	The name of the fencing policy.
portNumber	The port number to remove from the fencing policy, or *all*, which will remove all of the individual ports from the fencing policy. 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 0–31 for the Sphereon 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

Command Example `Root> config fencing removePort 24`

config.fencing.setParams

Syntax `setParams name typeNumber limit period`

Purpose This command sets the type, limit, and period values for the specified fencing policy.

Parameters This command has four parameters:

name	The name of the fencing policy.
typeNumber	This must be entered as a number that corresponds to an entry in the table shown below.
limit	The count of fencing violations that must occur within the specified period in order for a port to be automatically disabled. Acceptable values are in the range of 1-255. You may also enter *default* for this argument, which will set the default limit value for this fencing policy type.
period	The number of seconds in which the violation count must equal or exceed the threshold limit in order for a port to be fenced. You may also enter *default* for this argument, which will set the default period for this fencing policy type.

NOTE: The interval value is a fixed length amount of time. This interval is not a rolling window interval.

Type Number	Policy Type	Limit Value Range	Period Value Range
1	Protocol Errors	5	300 seconds
1	Protocol Errors	1 - 255	60 - 1800 seconds

Command Example If ports 0, 1, or 2 have more than five protocol errors on a single port within a period of 30 minutes, disable the offending port.

Where:

Port list	= 0, 1, 2
Fencing Type	= Protocol Errors
Limit	= 5
Period	= 1800 seconds

Command Example `Root> Config fencing setParams abc 1 5 300`

config.fencing.setState

Syntax `setState name enabledState`

Purpose This command enables or disables the specified fencing policy. A policy cannot be activated if it contains ports that are already controlled by a different fencing policy of the same type.

Parameters This command has two parameters:

name	The name of the fencing policy.
enabledState	Sets the fencing policy enabled state. Valid values are *enable* and *disable*. Boolean 1 and 0 values may also be substituted.

Command Example `Root> config fencing setState enable`

config.fencing.show

Syntax `show name`

Purpose This command displays the settings for fencing policies.

Parameters This command has one optional parameter:

name	The name of the fencing policy.

When no parameters are specified, the command will display the name, type, and state of all policies. If the optional parameter is specified, it will display all the information about the policy.

NOTE: If the *name* parameter is not supplied, then only 50 characters of the policy name will be displayed. In such cases, enable the Comma Delimited Mode to view the full name.

Command Example

```
Root> config fencing show
Root> config fencing show Policy_1
```

Output

If you do not specify the *name* parameter, then the output shows the following information:

Name	The name of the policy. This will be concatenated to 50 characters in the summary display. You can view the policy full name in the comma delim mode.
Ports	The ports to which the fencing policy will be applied.
Type	The type of the fencing policy.
Limit	The number of offenses that are allowed before a port is disabled.
Period	The amount of time that *limit of number of offenses* must exceed before a port is fenced.
State	The enabled state of the fencing policy.

Output Example

The output from the *config.fencing.show* command appears follows:

```
Name                              Type             State
-------------------------------------------------------
Default   Protocol Error Policy   Protocol Error   Disabled
Policy_1                          Protocol Error   Disabled
```

The output from the *config.fencing.show Policy_1* command appears as follows:

```
Name:        Policy_1
Ports:       E ports
Type:        Protocol Error
Limit:       5
Period:      300 seconds
State:       Disabled
```

config.fencing.showTypeTable

Syntax `showTypeTable`

Purpose This command displays the table of different fencing types that can be assigned to a policy. This table is used for reference only.

Parameters This command has no parameters.

Command Example

```
Root> config fencing showTypeTable
```

Output Example The output from the *config.fencing.showTypeTable* command appears as follows:

```
Number    Fencing Policy Types
--------------------------------
1         Protocol Error
2         Link Level Hot I/O
3         Security Violationss
```

config.ficonCUPZoning

The ficonCUPZoning commands add functionality to the FICON CUP Zoning branch by adding the ability to configure the Host Control List for the FCZ feature. The commands are shown only when both the FMS and FCZ feature key are installed.

config.ficonCUPZoning.addControlHost

Syntax `addControlHost  hostNodeWwn`

Purpose This command adds a control host to the Control Host List used to determine the FICON hosts capable of viewing all ports. This list overrides the FCZ port visibility mask. The maximum entries in this list is 8.

Parameters This command has one parameter:

hostNodeWwn	The node World Wide Name (WWN) of the desired control host, entered in colon-delimited notation (e.g., 01:02:03:04:05:06:07:08).

Command Example

```
Root> config ficonCUPZoning addControlHost 01:02:03:04:
05:06:07:08
```

config.ficonCUPZoning.deleteControlHost

Syntax `deleteControlHost  hostNodeWwn`

Purpose This command removes one or all control hosts from the Control Host List used to determine the FICON host(s) capable of viewing all ports. This list overrides the FCZ port visibility mask.

Parameters This command has one parameter:

hostNodeWwn	The node WWN of the desired control host, entered in colon-delimited notation (e.g., 01:02:03:04:05:06:07:08). You can also enter *all* to remove the entire list, if no attached hosts have supervisory privileges.

Command Example

```
Root> config ficonCUPZoning deleteControlHost all
```

config.ficonCUPZoning.setState

Syntax `setState ficonCUPZoningState`

Purpose This command enables or disables FICON CUP Zoning. The FICON Management Server feature key must be installed in order to enable the FICON CUP Zoning State.

Sphereon 4300 and Sphereon 4500 switches do not accept this command.

NOTE: If the FICON Management Server is enabled, the default management style is the FICON Management Style. The Open Systems Management Style cannot be used.

Parameters This command has one parameter.

ficonCUPZoningState	Specifies whether the FICON Management Server is enabled. Valid values are *enable* and *disable*. Boolean 1 and 0 may be substituted as values.

Command Example

```
Root> config ficonCUPZoning setState 1
```

config.ficonCUPZoning.show

Syntax `show`

Purpose This command displays the contents of the host control list and the enabled state of FICON CUP Zoning.

Parameters This command has no parameters.

Command Example

```
Root> config ficonCUPZoning show
```

Output The data is displayed as a table that includes the following information:

FICON CUP Zoning State	The enabled state of the FICON CUP Zoning feature.
Host Control List	List of 0-8 control hosts, displays “empty” for control host list with no members.

Output Example The output from the *config ficonCUPZoning show* command appears as follows:

```
FICON CUP Zoning State:    Enabled

Host Control List
-----------------------
01:02:03:04:05:06:07:08
09:0A:0B:0C:0D:0E:0F:00
```

NOTE: The command *show.ficonCUPZoning* on page 2-201 has functionality that is identical to this command.

config.ficonMS.setMIHPTO

Syntax `setMIHPTO timeout`

Purpose This command sets the FICON MS MIHPTO value in seconds. The default value is 180 seconds.

Parameters This command has one parameter:

timeout	Valid values are 15, 30, 45, 60, 120, 180, 240, 300, 360, 420, 480, 540, and 600.

Command Example `Root> config ficonms setMIHPTO 180`

config.ficonMS.setState

Syntax `setState ficonMSState`

Purpose This command enables or disables the FICON Management Server. The FICON Management Server feature key must be installed in order to enable the FICON Management Server State.

The Sphereon 4300 and Sphereon 4500 switches do not accept this command. This command is displayed on a Sphereon 3016 only if the feature key is installed.

NOTE: If the FICON Management Server is enabled, the default management style is the FICON Management Style. The Open Systems Management Style cannot be used.

Parameters This command has one parameter:

ficonMSState	Specifies whether the FICON Management Server is enabled. Valid values are *enable* and *disable*. Boolean 1 and 0 may be substituted as values.

Command Example `Root> config ficonMS setState 1`

NOTE: The command *config.features.ficonMS* on page 2-10 has functionality that is identical to this command.

config.ficonMS.show

Syntax `show`

Purpose This command shows the FICON MS settings.

Parameters This command has no parameters.

Command Example `Root> config ficonMS show`

Output The data is displayed as a table that includes the following information:

Ficon MS State	The state of the FICON MS feature.
Ficon MIHPTO	The FICON MIHPTO value in seconds.

Output Example The output from the *config.ficonMS.show* command appears as follows:

```
Ficon MS State: Disabled
Ficon MIHPTO (seconds):   180
```

config.ip.ethernet

Syntax `ethernet ipAddress gatewayAddress subnetMask`

Purpose This command sets the Ethernet network settings. If the IP address is reconfigured, the Telnet client must be reconnected to the new IP address. A new login will be requested.

NOTE: The Telnet connection can be lost when these Ethernet network settings are changed.

Parameters This command has three parameters:

ipAddress	Specifies the new IP address for the director or switch. The address must be entered in dotted decimal format (for example, 10.0.0.0).
gatewayAddress	Specifies the new gateway address for the Ethernet interface. The address must be entered in dotted decimal format (for example, 0.0.0.0).
subnetMask	Specifies the new subnet mask for the Ethernet interface. The address must be entered in dotted decimal format (for example, 255.0.0.0).

Command Example

```
Root> config ip ethernet 10.0.0.0 0.0.0.0 255.0.0.0
```

config.ip.lineSpeed

Syntax `lineSpeed speed duplex`

Purpose This command sets the Ethernet line speed.

Parameters This command has two parameters. One of the parameters is optional depending on the combination.

speed	The line speed. Options are *auto, 10,* or *100.* If *auto* is entered then the optional *duplex* should not be entered.
duplex	The duplex mode for the connection. Options are *full* or *half*.

Command Example

```
Root> config ip lineSpeed 10 half
```

config.ip.show

Syntax

```
show
```

Purpose This command shows the LAN configuration.

Parameters This command has no parameters.

Command Example

```
Root> config ip show
```

Output The LAN configuration data is displayed as a table that includes the following properties.

IP Address	The IP address.
Gateway Address	The gateway address.
Subnet Mask	The subnet mask.

Output Example The output from the *config.ip.show* command appears as follows:

```
IP Address:         10.0.0.0
Gateway Address:    0.0.0.0
Subnet Mask:        255.0.0.0
```

config.NPIV

N_Port ID Virtualization (NPIV) provides an FC facility for sharing a single physical N_Port among multiple N_Port IDs, thereby allowing multiple initiators, each with its own N_Port ID, to share the N_Port.

You can configure the number of allowed NPIV logins for a given port and enable or disable the feature.

Valid values for the *Login Limit* are 1 to 256. When the feature is enabled, NPIV number cannot be lowered if the NPIV devices have been logged in already.

The Product Feature Enablement key that enables NPIV has to be purchased from McDATA.

config.NPIV.maxPortIDs

Syntax `maxPortIDs portNumber maxIDs`

Purpose This command configures the maximum number of NPIV logins that are allowed on the specified port.

Parameters This command has two parameters:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 0–31 for the Sphereon 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140 all - applies the maxIDs parameter value to every port on the product.
maxIDs	Specifies the maximum number of NPIV logins allowed on the specified port.Valid values are in the range 1–256.

Command Example

```
Root> config NPIV maxPortIDs 128

Root> config NPIV portNumber 60
```

config.NPIV.setState

Syntax `setState NPIVEnabledState`

Purpose This command sets the enabled state of the NPIV feature. The NPIV feature key must be installed in order to enable this feature.

Parameters This command has one parameter:

NPIVEnabledState	This parameter can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config NPIV setState enable
```

config.NPIV.show

Syntax `show`

Purpose This command displays the current NPIV configuration for all ports.

Parameters This command has no parameters.

Command Example

```
Root> config NPIV show
```

Output This command displays the following NPIV configuration data:

NPIV state	The current enabled/disabled state of the NPIV feature.
Max Allowed	NPIV Login Table. A table mapping each port number on the switch to a corresponding max number of NPIV logins setting.

Output Example The output from the *config.NPIV.show* command appears as follows:

```
NPIV state:Enabled
Port      Max Allowed NPIV Logins
--------------------------
1      10
2      10
3      10
4      0
5      0
6      130
...
```

NOTE: The command *show.NPIV.config* on page 2-210 has functionality that is the same as this command.

config.NSTools

The NSTools command on the configuration branch enters the NSTools configuration branch. All commands under this branch operate on the Nameserver snapshot database.

config.NSTools.clearSnapshot

Syntax `clearSnapshot`

Description This command clears the Nameserver database entries from the snapshot database that was saved.

Refer to *config.NSTools.saveSnapshot* for saving the snapshot.

Parameters This command has no parameters.

Command Example

```
Root> config NSTools clearSnapshot
```

config.NSTools.saveSnapshot

Syntax `saveSnapshot`

Description This command captures a list of FC IDs in the local Nameserver database along with the timestamp of the list created.

Parameters This command has no parameters.

Command Example

```
Root> config NSTools saveSnapshot
```

Output Example The output from the *config.NSTools.saveSnapshot* command appears as follows:

```
config.NSTools> saveSnapshot
Saving snapshot of the NameServer Database ...
Snapshot Time:    09/15/2005 19:25:43
```

config.NSTools.showSnapDiff

Syntax `showSnapDiff`

Description This command displays a list of FC IDs of nodes that have logged in or logged out from the nameserver since the last snapshot was taken.

Parameters This command has no parameters.

Command Example

```
Root> config NSTools showSnapDiff
```

Output The following properties are displayed:

Snapshot Time	The time at which the Nameserver snapshot was taken.
Current Time	The current date and time.
Additional NS Entries	A list of FC IDs of nodes that logged into the Nameserver after the snapshot was taken.
Missing NS Entries	A list of FC IDs of nodes that are not logged into the Nameserver but were logged into the Nameserver at the time of snapshot was taken.

Output Example The output from the *config.NSTools.showSnapDiff* command appears as follows:

```
config.NSTools> showSnapDiff
Snapshot Time:    02/27/2006 22:35:41
Current Time:     02/27/2006 22:36:04

Missing NS Entries:
-------------------
610513

Additional NS Entries:
----------------------
610413
610713
```

config.NSTools.showSnapshot

Syntax `showSnapshot`

Description This command displays the list of FC IDs saved in the snapshot.

Parameters This command has no parameters.

Command Example
```
Root> config NSTools showSnapshot
```

Output Example The output from the *config.NSTools.showSnapshot* command appears as follows:

```
Config.NSTools> showsnapshot
Snapshot Time:    02/27/2006 22:35:41

Saved NS Entries
----------------
690BDC
690BE0
690BE1
690BE2
690BE4
690BE8
```

config.openSysMS.setHostCtrlState

Syntax
```
setHostCtrlState HostContrlState
```

Purpose This command enables or disables Open Systems Management Server (OSMS) Host Control.

Parameters This command has one parameter:

HostContrlState	This parameter can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example
```
Root> config openSysMS setHostCtrlState enable
```

config.openSysMS.setState

Syntax
```
setState osmsState
```

Purpose This command enables or disables the Open Systems Management Server (OSMS) feature.

OSMS is a feature that allows host control and inband management of the switch or director through a management application that resides on an Open-Systems Interconnection (OSI) device.

Parameters This command has one parameter.

osmsState	Specifies whether the Open Systems Management Server is enabled. Valid values are *enable* and *disable*. Boolean 1 and 0 may be substituted as values.

Command Example

```
Root> config openSysMS setState 1
```

NOTE: The command *config.features.openSysMS* on page 2-11 has functionality that is identical to this command.

config.port.blocked

Syntax

```
blocked portNumber blockedState
```

Purpose This command sets the blocked state for a port.

Parameters This command has two required parameters:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 0–31 for the Sphereon 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140
blockedState	Specifies the blocked state for the port. Valid values are *true* and *false*. Boolean 1 and 0 may be substituted as values.

Command Examples

```
Root> config port blocked 4 false
Root> config port blocked 4 0
```

config.port.fan

Syntax `fan portNumber fanState`

Purpose This command sets the Fabric Address Notification (FAN) state for a port (Sphereon 4300 and Sphereon 4500 switches only). This configuration can be applied to any port regardless of its current configuration. The FAN value is applied at the time the port is configured and operated in a loop.

Parameters This command has two required parameters:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3232 0–31 for the Sphereon 4700
fanState	Specifies the FAN state for the port. Valid values are *true* and *false*. Boolean 1 and 0 may be substituted as values.

Command Example

```
Root> config port fan 4 1
```

config.port.name

Syntax `name portNumber portName`

Purpose This command sets the name for a port.

Parameters This command has two required parameters:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 0–31 for the Sphereon 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140
portName	Specifies the name for the port. The port name must not exceed 24 characters in length.

Command Example

```
Root> config port name 4 Sam's tape drive
```

config.port.rxCredits

Syntax

```
rxCredits PortNumber RxCredits
```

Purpose This command sets the number of initial BB_Credits for a given port. The number of credits assigned must fall between the minimum and maximum allowed values for the port.

Parameters This command has two required parameters:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 0–31 for the Sphereon 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140
numBBCredits	Specifies the number of Rx BB_Credits to assign the specified port. For the Sphereon 4300 and Sphereon 4500 the RxCredits per port must be between 2 and 12. The total number of Rx Credits assigned across all ports must not exceed the maximum pool size of 150. For the Intrepid family, the RxCredits per FPM/UPM port must be between 1 and 60. The RxCredits per XPM port must be between 4 and 400. There is no pool limitation.

Command Example

```
Root> config port rxCredits 8 40
```

config.port.show

Syntax

```
show portNumber
```

Purpose This command displays the current configuration for the specified port.

Parameters This command has one parameter:

portNumber	Specifies the port number. Valid values are: 0–12 for the Sphereon 4300 0–15 for the Sphereon 3016 0–16 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 0–32 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

Command Example

```
Root> config port show 4
```

Output This command output appears as a table that includes the following properties:

Port Number	The port number.
Name	The configured port name.
Blocked	The blocked state. Valid values are *true* and *false*.
Blocked Reason	The reason for port being blocked. Valid values are *'Blocked temporarily, Internal'*, *'Blocked by user'*, *'Blocked by hardware type change'*, *'Blocked by port fencing'*.
FAN	The Fabric Address Notification (FAN) state. Valid values are *enabled* and *disabled*. (Sphereon 4300 and Sphereon 4500 switches only.)
Type	The port type. Valid values are: *F Port* *E Port* *G Port* *Fx Port (Sphereon 4300, Sphereon 4400, Sphereon 4500, and Sphereon 4700 only)* *Gx Port (Sphereon 4300, Sphereon 4400, Sphereon 4500, and Sphereon 4700 only)*

Speed	The configured port speed. Valid values are: *1G – 1 Gb/sec* *2G – 2 Gb/sec* *4G – 4 Gb/sec (Sphereon 4400 and Sphereon 4700 only)* *10G – 10 Gb/sec (XPM only)* *Neg - Negotiate* *4G Burst – 4 Gb/sec Burst (QPM only)* *4G Sust – 4 Gb/sec Sustained (QPM only)* *Neg Sust – Negotiate Sustained (QPM only)* *Neg 2G Max – Negotiate 2 Gb/sec Maximum (QPM only)* *Neg B 4G Max – Negotiate Burst 4 Gb/sec Maximum (QPM only)*
Rx BB_Credits	The number of configured Rx BB_Credits.

Output Example The output from the *config.port.show* command appears as follows:

```
Port Number:        4
Name:               Sam's tape drive
Blocked:            false
Blocked Reason:
Type:               F Port
Speed:              4G Burst
Rx BB_Credits:      12
```

config.port.showPortAddr

Syntax `showPortAddr`

Purpose This command displays the port address configuration for all ports.

NOTE: The command *show.port.showPortAddr* on page 2-229 has similar functionality.

Parameters This command has no parameters.

Command Example

```
Root> config port showPortAddr
```

Output The port configuration is shown as a table of properties. The following properties are displayed:

Port	The port number.
Original Addr	The original port address of the port.
Current Addr	The current port address of the port.
Swapped Port Num	If the port is swapped with another port, it will show the port number of the port it is swapped with.

Output Example

```
Port  Original Addr    Current Addr  SwappedPort Num
----  -------------    ------------  ---------------
0     4                4
1     5                5
2     6                7             3
3     7                6             2
4     8                8
5     9                9
6     a                a
7     b                b
8     c                c
...
```

config.port.showCredits

Syntax `showCredits`

Purpose This command shows the BB_Credit Pool information.

Parameters This command has no parameters.

Command Example

```
Root> config port showCredits
```

Output This command displays the BB_Credit data:

Pool	The BB_Credit pool. Possible values: Sphereon 4300 – Pool 0 Sphereon 4400 – Pool 0 Sphereon 4500 – Pool 0 Sphereon 4700 – Pool 0 and Pool 1
Total	The total number of BB_Credits that this pool contains.
Allocated	The number of BB_Credits that are currently allocated to ports.
Available	The number of BB_Credits that are currently available to allocate to ports.
Ports	A list of port numbers that belong to the pool.

Output Example

```
Config.Port> showCredits
Pool    Total  Allocated  Available  Ports
------  -----  ---------  ---------  -----
Pool 1  252    190        62         0-3,8-11,16-19,24-27
Pool 2  252    80         172        4-7,12-15,20-23,28-31
```

or

```
Config.Port> showCredits
Pool    Total  Allocated  Available  Ports
------  -----  ---------  ---------  -----
Pool 1  150    100        50         0-23
```

config.port.speed

Syntax `speed portNumber portSpeed`

Purpose This command sets the speed for a port.

This command will be available always, but the CLI will respond with an error if the hardware supports only one link speed. In order to change a port speed to 2Gb/sec, the switch speed must be configured to 2Gb/sec.

NOTE: Port speed changes temporarily disrupt port data transfers.

Parameters

This command has two required parameters:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 0–16 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 0–32 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140
portSpeed	Specifies the speed of the port. Valid values are *1g* *2g* *4g* *Negotiate* *4gSustained* *4gBurst* *negotiateSustained* *negotiateBurst4gMax* *negotiate2gMax* Note: *4gBurst* and *negotiateBurst4gMax* are applied only to F_port type on QPM cards. To configure to these port speed, you will need to first set the port to F_port.

Command Examples

```
Root> config port speed 4 2g

Root> config port speed 6 negotiateBurst4gMax
```

config.port.swapPortByAddr

Syntax `swapPortByAddr portAddr1 portAddr2`

Purpose This command will swap two ports given the port addresses. The ports must be offline to perform this operation.

Parameters This command has two required parameters:

portAddr1	Port address, in hexidecimal format, of the desired port to be swapped.
portAddr2	Port address, in hexidecimal format, of the desired port to be swapped.

Command Example

```
Root> config port swapPortByAddr 1e 1f
```

config.port.swapPortByNum

Syntax `swapPortByNum portNum1 portNum2`

Purpose This command will swap two ports given the port numbers. The ports must be offline to perform this operation.

Parameters This command has two required parameters:

portNum1	Port number, in hexidecimal format, of the desired port to be swapped.
portNum2	Port number, in hexidecimal format, of the desired port to be swapped.

Command Example

```
Root> config port swapPortByAddr 1e 1f
```

config.port.type

Syntax `type portNumber portType`

Purpose This command sets the allowed type for a port.

A port can be configured as F_Port, E_Port, or G_Port. On a Sphereon 4300 or Sphereon 4500, a port can also be an Fx_port or Gx_port.

NOTE: On the Sphereon 4300 Switch, the E_Port, G_Port, and GX_Port options are not valid unless the Fabric Capable feature is enabled. For more information, see the *McDATA Sphereon 4300 Switch Installation and Service Manual* (620-000171).

The port configurations function as follows:

- *F_Port*—cannot be used as an interswitch link, but may attach to a device with an N_Port.
- *E_Port*—only other switches may attach to this type of port.
- *G_Port*—either a device or another switch may attach to this type of port.
- *Fx_Port* — allows Arbitrated Loop operation in addition to the functionality of an F_Port. (Sphereon 4300 and Sphereon 4500 only.)
- *Gx_Port*—allows Arbitrated Loop operation in addition to the functionality of an F_Port or an E_Port. (Sphereon 4300 and Sphereon 4500 only.)

Parameters This command has two required parameters:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

portType	Specifies the type of the port. Valid values for the port type are: *eport* *fport* *gport* *fxport* (Sphereon 4300 and Sphereon 4500 only) *gxport* (Sphereon 4300 and Sphereon 4500 only)

Command Example `Root> config port type 4 fport`

config.security

Using the security command on the configuration branch, users can enter the security configuration branch. All commands under this branch operate on a particular security attribute.

Some security configuration commands (namely those under the fabricBinding branch) are different from other CLI commands in that they are not single action commands that take effect immediately. These commands implement a rudimentary membership list editor.

A user works on a temporary copy of a membership list in the editor and can perform actions such as adding or deleting fabric members. The edited copy can then be activated to the fabric.

It should be noted that not all verification of membership lists can be made in the pending copy. Therefore, it is possible that a user will build up a pending membership list definition without errors, but will encounter errors when saving to the fabric. It should also be noted that the state of the pending configuration must be set to *restrict* in order to make any changes to the (pending) fabric membership list.

config.security.authentication.interface

Using this command, the authentication interface is configured for Web and CLI users, OSMS, and devices. The authentication has two interfaces namely, Local and Radius, which can be used in three combinations namely, Local, Radius, and Radius then Local.

config.security.authentication.interface.api.outgoing

Syntax `outgoing enabledState`

Purpose This command determines if outgoing CHAP authentication is used on all API sessions. If this is enabled, the switch will issue a CHAP challenge to authenticate all new API connections.

Parameters This command has one parameter:

enabledState	This parameter enables and disables outgoing CHAP authentication for API sessions. Valid values for this parameter are *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config security authentication interface api
outgoing enable
```

config.security.authentication.interface.api.sequence

Syntax `sequence method1 [method2]`

Purpose This command sets the sequence that the API interface will use to authenticate. When the preferred method cannot be contacted, the backup method will be used to authenticate the API session.

Parameters This command has one required parameter, and one optional parameter:

method1	This sets the preferred method of authentication. Accepted values are *local* or *RADIUS*.
method2	This optional parameter sets the backup method of authentication. This backup method is used when the preferred method cannot be contacted. Accepted value is *local*.

NOTE: A preferred method of *local* and a backup method of *RADIUS* is not an accepted combination because the *local* method can always be contacted.

Command Example

```
Root> config security authentication interface api
sequence RADIUS local
```

config.security.authentication.interface.cli.sequence

Syntax `sequence method1 [method2]`

Purpose This command sets the sequence that the CLI interface will use to authenticate. When the preferred method cannot be contacted, the backup method will be used to authenticate the CLI login.

Parameters This command has one required parameter, and one optional parameter:

method1	This sets the preferred method of authentication for the CLI interface. Accepted values are *local* or *RADIUS*.
method2	This optional parameter sets the backup method of authentication for the CLI interface. This backup method is used when the preferred method cannot be contacted. Accepted value is *local*.

NOTE: A preferred method of *local* and a backup method of *RADIUS* is not an accepted combination because the *local* method can always be contacted.

Command Example

```
Root> config security authentication interface cli
sequence RADIUS local
```

config.security.authentication.interface.eport.outgoing

Syntax `outgoing enabledState`

Purpose This command determines if outgoing CHAP authentication is used on E_Port connections. If this is enabled, the switch will issue a CHAP challenge to authenticate the remote end of the ISL.

NOTE: This command requires that the SANtegrity Authentication feature key be installed.

Parameters This command has one parameter:

enabledState	This parameter enables and disables outgoing CHAP authentication on all ISLs. Accepted values for this parameter are *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config security authentication interface eport
outgoing disable
```

config.security.authentication.interface.eport.sequence

Syntax

```
sequence  method1  [method2]
```

Purpose

This command sets the sequence that the E_Port interface will use to authenticate. When the preferred method cannot be contacted, the backup method will be used to authenticate the remote end of the ISL.

NOTE: This command requires that the SANtegrity Authentication feature key be installed.

Parameters

This command has one required parameter, and one optional parameter:

method1	This sets the preferred method of authentication. Accepted values are *local* or *RADIUS*.
method2	This optional parameter sets the backup method of authentication. This backup method is used when the preferred method cannot be contacted. Accepted value is *local*.

NOTE: A preferred method of *local* and a backup method of *RADIUS* is not an accepted combination because the *local* method can always be contacted.

Command Example

```
Root> config security authentication interface eport
sequence RADIUS local
```

config.security.authentication.interface.nport.outgoing

Syntax

```
outgoing  enabledState
```

Purpose

This command determines if outgoing CHAP authentication is used on N_Port connections. If this is enabled, the switch will issue a CHAP challenge to authenticate the remote device.

NOTE: This command requires that the SANtegrity Authentication feature key be installed.

Parameters This command has one parameter:

enabledState	This parameter enables and disables outgoing CHAP authentication on all ISLs. Accepted values for this parameter are *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config security authentication interface eport
outgoing disable
```

config.security.authentication.interface.nport.sequence

Syntax

```
sequence  method1  [method2]
```

Purpose This command sets the sequence that the N_Port interface will use to authenticate. When the preferred method cannot be contacted, the backup method will be used to authenticate the remote end of the ISL.

NOTE: This command requires that the SANtegrity Authentication feature key be installed.

Parameters This command has one required parameter, and one optional parameter:

method1	This sets the preferred method of authentication. Accepted values are *local* or *RADIUS*.
method2	This optional parameter sets the backup method of authentication. This backup method is used when the preferred method cannot be contacted. Accepted value is *local*.

NOTE: A preferred method of *local* and a backup method of *RADIUS* is not an accepted combination because the *local* method can always be contacted.

Command Example

```
Root> config security authentication interface nport
sequence RADIUS local
```

config.security.authentication.interface.osms.outgoing

Syntax `outgoing enabledState`

Purpose This command determines if outgoing authentication is used on all OSMS requests. The OSMS key must be configured prior to setting the outgoing state to enabled.

NOTE: The SANtegrity Authentication feature key must be installed to configure the OSMS outgoing state.

Parameters This command has one parameter:

enabledState	This parameter enables and disables FCCT authentication. Accepted values for this parameter are *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config security authentication interface osms
outgoing 1
```

config.security.authentication.interface.osms.setKey

Syntax `setKey`

Purpose This command sets the FCCT key that is associated with the single OSMS username. This username is a static entry in the local authentication database. This user is not viewable. This command effectively sets the key that will be used in all OSMS authenticated requests. This entry in the user database is only used for the OSMS interface, and cannot be changed.

After issuing this command, users are directed to a password prompt where they have to enter the actual 16-byte key. After entering the new secret, they must confirm it in the following prompt. After confirmation, they will be returned to the initial prompt that the command was executed from.

No characters will be echoed back to the screen when entering a password or when confirming a password.

NOTE: The SANtegrity Authentication feature key must be installed to configure the FCCT key.

Parameters This command has no required parameters.

Command Example

```
Root> config security authentication interface osms
setKey
```

config.security.authentication.interface.serial.enhancedAuth

Syntax

```
enhancedAuth  enhancedAuthState
```

Purpose This command sets the enhanced serial authentication state. Enhanced Serial Authentication requires users to enter a password when gaining access to the serial port interface.

Parameters This command has one parameter:

enhancedAuthState	This parameter enables and disables enhanced authentication on the serial port interface. Accepted values for this parameter are *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config security authentication serial enhancedAuth
enable
```

config.security.authentication.interface.show

Syntax

```
show  interface
```

Purpose This command displays the settings in the local authentication database for a single interface.

NOTE: The SANtegrity Authentication feature key must be installed to view the E_Port, N_Port, and OSMS information.

Parameters This command has one parameter:

interface	The interface that will be displayed. Valid values for this parameter are: *cli* *web* *osms* *api* *serial* *eport* *nport*

Command Example

```
Root> config security authentication interface show Web
```

Output Example The output for the *config.security.authentication.interface.show* command appears as follows:

```
Interface: Web
Outgoing:  N/A
Incoming:  N/A
Sequence:  Local, RADIUS
```

config.security.authentication.interface.web.sequence

Syntax

```
sequence  method1  [method2]
```

Purpose This command sets the sequence used by the web interface for authentication. When the preferred method cannot be contacted, the backup method will be used to authenticate the web login.

Parameters This command has one required parameter, and one optional parameter:

method1	This sets the preferred method of authentication for the CLI interface. Accepted values are *local* or *RADIUS*.
method2	This optional parameter sets the backup method of authentication for the CLI interface. This backup method is used when the preferred method cannot be contacted. Accepted value is *local*.

NOTE: A preferred method of *local* and a backup method of *RADIUS* is not an accepted combination because the *local* method can always be contacted.

Command Example

```
Root> config security authentication interface cli
sequence RADIUS local
```

config.security.authentication.port.override

Syntax

```
override  portNumber  [overrideState]
```

Purpose

This command sets the outgoing override state for a single port. This setting allows users to override the default outgoing authentication state for either the E_Port or N_Port interface. The default setting will cause the port to use the outgoing state configure for the corresponding interface (E_Port or N_Port).

NOTE: This command requires that the SANtegrity Authentication feature key be installed.

Parameters

This command has one required parameter, and one optional parameter:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140
overrideState	This parameter sets the outgoing authentication state for the specified port. Valid values are *enable*, *disable*, or *default*. Boolean 1 and 0 values may also be substituted.

Command Example `Root> config security authentication port override 138 enable`

config.security.authentication.port.show

Syntax `show`

Purpose This command displays a table displaying the outgoing override state for each port.

Parameters This command has no parameters.

Command Example `Root> config security authentication port show`

Output This command displays all valid user names in the local database for the specified interface.

Port	The port number.
Override State	The outgoing authentication override state.

Output Example The output for the *config.security.authentication.port.show* command appears as follows:

```
Port      Override State
----      --------------
0         Default
1         Default
2         Enable
3         Default
4         Disable
```

config.security.authentication.RADIUS

Using this command, the Radius server database is configured for authentication. The timeout, attempts, and dead time values are also configured for Radius server.

config.security.authentication.RADIUS.attempts

syntax `attempts index  attempts`

Purpose This command configures the number of attempts by an authentication request to a RADIUS server if a response is not

received before the timeout. After the transmit attempt limit is reached, the switch will, if applicable, move to the next defined RADIUS server. The default number of attempts is three.

Parameters This command has two required parameters:

index	Index of the RADIUS sever (1-3) to change the transmit attempts value.
attempts	The number of transmit attempts. Valid values are between 1 and 100.

Command Example

```
Root> config security authentication RADIUS attempts 3 20
```

config.security.authentication.RADIUS.deadtime

Syntax

```
deadtime  minutes
```

Purpose This command configures the number of minutes a RADIUS server is marked as "dead". If a RADIUS server does not respond to an authentication request, it can be marked as *dead* for a specified time interval. This may speed up authentication by eliminating timeouts and retransmissions. If no alternate RADIUS servers are available (when only one server is configured or when all are marked dead), then the deadtime is ignored. Deadtime may be 0 to 1440 minutes. The default is 0.

Parameters This command has one required parameter:

minutes	The number of minutes a RADIUS server is marked "dead" before it is contacted again. Valid values are between 0 and 1440.

Command Example

```
Root> config security authentication RADIUS deadtime 120
```

config.security.authentication.RADIUS.deleteServer

Syntax

```
deleteServer index
```

Purpose This command removes a RADIUS server from the RADIUS server list. If you delete a server, and there are servers configured in higher

numbered slots, these servers will be automatically moved up to the first available slots.

Parameters This command has one required parameter:

index	Index of the server to be removed.

Command Example

```
Root> config security authentication RADIUS deleteServer
3
```

config.security.authentication.RADIUS.server

Syntax

```
server  index [IP:port]
```

Purpose This command adds or modifies one RADIUS server at a given index that will be used for authentication. Servers are queried in the order listed; so the primary server must be the first one in the list.

There are three slots available for RADIUS servers. Servers will be added into the list by the index value. The range is 1 to 3. If a server is added and there is an empty slot before that server, it will be shifted up to the empty slot. The IP:port is the IP address and the UDP port on the RADIUS server.

NOTE: If users want to configure a RADIUS server without a key, they must specify the key as "". The set of double quotes is an empty string in the CLI.

Parameters This command has one required parameter, and two optional parameters:

index	Index of the RADIUS server (1-3) to add or modify.
IP	IP address of the server.
port	The UDP port number.

Command Example

```
Root> config security authentication RADIUS server 3
14.2.114.183:6
```

config.security.authentication.RADIUS.show

Syntax `show`

Purpose This command displays the current RADIUS server configuration.

Parameters This command has no parameters.

Command Example

```
Root> config security authentication RADIUS show
```

Output This command displays all three configured RADIUS servers.

Deadtime	The amount of time a server is marked as “dead”.
Server	The IP address and UDP port of the configured RADIUS server.
Attempts	The number of transmit attempts.
Timeout	The timeout value for a server in seconds.

Output Example The output for the *config.security.authentication.RADIUS.show* command appears as follows:

```
Deadtime:    0

Index     IP Address    Port   Attempts      Timeout
-----     ------------  ----   ----------    -------
1         1.1.1.1       1111   3             2
2         2.2.2.2       2222   3             2
3
```

config.security.authentication.RADIUS.timeout

Syntax `timeout index seconds`

Purpose This command configures the waiting time, in seconds, for a response from the RADIUS server before retransmitting a packet. The default value is 4 seconds.

In extreme cases, where E_Port or N_Port authentication occur on a large number of ports with RADIUS, and a switch is coming online, users may need to increase the timeout value so that all the ports can log in.

For example, if all of the ports on an Intrepid 6140 Director are coming online at the same time and requiring authentication, some of the ports may not get an access_accept before they timeout.

Parameters This command has two required parameters:

index	Index of the RADIUS sever (1-3) to change the timeout value.
seconds	The number of seconds before the RADIUS server retransmits. Valid values are between 1 and 1000.

Command Example

```
Root> config security authentication RADIUS timeout 3 360
```

config.security.authentication.switch.setSecret

Syntax

```
SetSecret
```

Purpose This command sets the CHAP secret that is associated with the switch. This command effectively sets the secret for the local WWN username in the local authentication user database. The switch secret is used for all incoming CHAP challenges on the E_Port and N_Port interfaces.

After issuing this command, users are directed to a *password* prompt where the actual 16-byte secret is entered. After entering the new secret, it must be confirmed in the following prompt. After confirmation, users are returned to the initial prompt that the command was executed from.

No characters will be echoed back to the screen when entering a password, or when confirming a password. See *Passwords and Secrets* on page 1-16 for valid characters.

NOTE: The SANtegrity Authentication feature key must be installed to configure switch secret.

Parameters This command has no required parameters.

Command Example

```
Root> config security authentication switch setSecret
```

config.security.authentication.user

One of the fundamental concepts of the authentication portion of the CLI is that all secured interfaces have interchangeable users that are stored in a single local authentication user database. In the past, CLI supported authorization for only two username/password pairs (Administrator and Operator). These two username/password pairs were also unique to the CLI interface.

The present CLI lets you configure multiple users for their own interface, as well as for other management entities and FC connections. For this reason, the *security.userrights* branch of commands has been removed from the command tree.

config.security.authentication.user.add

Syntax `add username interface1 [interface2]`

Purpose This command adds a new user to the local authentication database. Each user can be assigned a combination of interfaces that will authenticate the new username/password combination.

After executing this command, the user will be moved to a new password prompt where the user will enter a password and will later, confirm it in the next prompt. After confirming the new password, the user will be returned to the initial prompt.

No characters will be echoed back to the screen when entering a password, or when confirming a password.

All new users will be assigned a role of *none*; a subsequent *role* command must be executed to assign a role. Web and CLI users must be assigned a role before they can access the CLI or web interfaces.

NOTE: The SANtegrity Authentication feature key must be installed to configure E_port and N_port usernames.

Parameters

This command has two required parameters and an additional interface parameter before the password parameter at the prompt after the command.

username	The new user name that will be added to the local authentication database. If the entered user name already exists in the user database, an error will be shown. This parameter can be from 1-23 characters in length for an API, Web, or CLI username. E_Port and N_Port usernames must be entered as a standard colon-delimited WWN. All characters in the printable USASCII character set are valid with the exception of spaces, single quotes, and double quotes.
interfaces	This is a list of interfaces that will be assigned to the associated username. Accepted values for this parameter are: *cli* *web* *api* *eport* *nport*
password	Sets the password for the new login username. This parameter can be from 1-24 characters in length for a Web or CLI password. CHAP secrets and FCCT keys must be exactly 16 bytes long for API, OSMS, E_Port, and N_Port interfaces. This parameter will not be echoed to the screen. See *Passwords and Secrets* on page 1-16 for valid characters.

NOTE: Currently the only possible combination of multiple interfaces is Web and CLI.

Command Example

```
Root> config security authentication user add
01:2A:3f:4:5:0:0 eport
```

config.security.authentication.user.delete

Syntax

```
delete  username
```

Purpose This command deletes an entry from the local authentication database. Both the Web and CLI interfaces must have at least one valid username with an *Administrator* role.

Parameters This command has one parameter:

username	A valid user name in the local authentication database.

Command Example

```
Root> config security authentication user delete
01:2A:3f:4:5:0:0
```

config.security.authentication.user.modify

Syntax

```
modify  username  interface1 [interface2]
```

Purpose This command modifies an existing user in the local authentication database. The user password and the combination of interfaces can be modified with this command. After executing this command, users are prompted to enter a password, similar to behavior of the *user.add* command.

The role of a user will remain the same unless the currently assigned role is invalid for the new combination of interfaces. If the role is no longer valid for an interface combination, the role will be changed back to *none*. At least one username with an *Administrator* role must exist in the user database at all times for both the web and CLI interfaces.

NOTE: The SANtegrity Authentication feature key must be installed to configure E_port and N_port usernames.

Parameters This command has two required parameters and an additional interface parameter before the password parameter at the prompt after the command:

username	The existing user name whose fields will be modified in the local authentication database. If the entered user name does not exist in the user database, an error will be shown. This parameter can be from 1-23 characters in length for an API, web or CLI user name. E_Port and N_Port user names must be entered as a standard colon-delimited WWN. All characters in the printable USASCII character set are valid with the exception of spaces, single quotes, and double quotes.
interfaces	This is a list of interfaces that will be assigned to the associated user name. Accepted values for this parameter are: *cli* *web* *api* *eport* *nport*.
password	Sets the password for the existing username. This parameter can be from 1-24 characters in length for a Web or CLI user name. CHAP secrets must be exactly 16 bytes long for API, OSMS, E_Port, and N_Port interfaces. This parameter will not be echoed to the screen. See *Passwords and Secrets* on page 1-16 for valid characters.

NOTE: Currently the only possible combination of multiple interfaces is (Web and CLI) or (E_port or N_port).

Command Example

```
Root> config security authentication user modify
01:2A:3f:4:5:0:0 nport
```

config.security.authentication.user.passExpTime

Syntax

```
passExpTime days
```

Description This command configures the password expiry time for the management users of the switch/director. The value "0" specifies that the user password will never expire.

Parameters This command has one parameter:

days	A number from 0 - 3650 specifying the number of days after which the user password will expire.

Command Example

```
Root> config security authentication user passExpTime 90
```

config.security.authentication.user.role

Syntax

```
role  username privilegeLevel
```

Purpose This command sets the role value associated with an existing user name. The role value can either be set to an administrator or an operator. This value defaults to *none* when the user is first added to the database. This value must be changed for all new CLI and web users before they will be allowed access to their respective interfaces.

Parameters This command has two required parameters:

username	A valid web or CLI username in the local authentication database.
privilegeLevel	This parameter assigns the privilege level to a username. Currently only Web and CLI users can be assigned a role value. This parameter must be either *administrator* or *operator*.

Command Example

```
Root> config security authentication user role
01:2A:3f:4:5:0:0 administrator
```

config.security.authentication.user.show

Syntax

```
show interface
```

Purpose This command displays a single interface from the local authentication database. The API, E_Port and N_Port parameters do not have a password expiration time and the column will not be displayed.

Parameters This command has one optional parameter:

interface	The interface that will be displayed. Accepted values for this parameter are: • *cli* • *web* • *api* • *eport* • *nport*

Command Example

```
Root> config security authentication user show web
```

Output The output is displayed as a table with the following properties:

Username	The username specified by the user.
Interfaces	The management interfaces that a user belong to.
Role	The management role of the user.
P-Exp	The number of days until the user's password will expire.

NOTE: P-Exp column is displayed only for Web and CLI interfaces.

Output Example The output for the *config.security.authentication.user.show* command appears as follows:

```
Interface: Web
Password Expiration Time: 365

Username            Interfaces          Role             P-Exp
------------------  ------------------  ---------------  ------
johndoe_1223        Web,CLI             Administrator    250
ewsOperator         Web                 Operator         20
Operator            Web,CLI             Operator         365
```

config.security.fabricBinding

Fabric Binding functionality provided by the SANtegrity Binding feature helps bind the switch or director to specified fabrics so that they can communicate only with those fabrics included in the Fabric Binding Membership List (FBML). This provides security from

accidental fabric merges and potential fabric disruption when fabrics become segmented because they cannot merge.

Fabric Binding Commands

The *config.security.fabricBinding* commands function in a different way from most CLI commands, which are single action commands that take effect immediately. Most of the Fabric Binding commands affect a temporary copy of an FBML in the work area called the Pending FBML. When this temporary copy is activated to the fabric, it is called the Active FBML.

NOTE: The EFCM Basic interface can change Fabric Binding status and FBMLs if it is used along with the CLI.

Because not all the verification of the Pending FBML can occur on the temporary copy in the work area, it is possible, however unlikely, that the copy of the list encounters no errors until the list is activated to the fabric.

NOTE: A Sphereon 4300 Switch cannot participate in a fabric unless the Fabric Capable feature is enabled. For more information, refer to the *McDATA Sphereon 4300 Switch Installation and Service Manual* (620-000171).

Fabric Binding Membership Terminology

Two types of FBMLs are configured using the CLI:

- **Active FBML:** When fabric binding is active, the active FBML is the list of fabric members with which the product is allowed to communicate. If fabric binding is disabled, this list is empty.
- **Pending FBML:** A list used to configure an FBML before it is made active on the director or switch. Changes to the pending FBML are not implemented in the fabric until they are saved and activated using the *config.security.fabricBinding.activatePending* command as documented on page 2-63.

The following terms apply to the switches and directors that are part of FBMLs:

- *Local:* The switch or director that is being configured. This is a required FBML member.
- *Attached:* A switch or director that is currently in a fabric with the local switch or director. Any switch and director that is attached to the local switch or director is a required FBML member.
- *Unattached:* A switch or director that is not currently in a fabric with the local switch or director. These switches and directors are

unattached if they have been added manually to the pending FBML, or if they are segmented from the local fabric.

Enable/Disable and Online State Functions

For Fabric Binding to function, specific operating parameters and optional features must be enabled. Also, there are specific requirements for disabling these parameters and features when the switch or director is offline or online. Be aware of the following:

- Because switches are bound to a fabric by World Wide Name (WWN) and domain ID, the Insistent Domain ID is automatically enabled if Fabric Binding is enabled. If Fabric Binding is enabled and the switch or director is online, you cannot disable Insistent Domain ID.
- If Fabric Binding is enabled and the director is offline, you can disable Insistent Domain ID, but this will also disable Fabric Binding.
- You cannot disable Fabric Binding if Enterprise Fabric Mode is enabled. However, if Enterprise Fabric Mode is disabled, you can disable Fabric Binding.

NOTE: Fabric Binding can be disabled when the switch is offline.

config.security.fabricBinding.activatePending

Syntax

```
activatePending
```

Purpose

This command activates the fabric binding configuration contained in the pending work area to the fabric. The pending FBML becomes the active FBML, and fabric binding is made functional.

NOTE: This command takes effect immediately. The CLI verifies the list before activating it to the fabric.

Parameters

This command has no parameters.

Command Example

```
Root> config security fabricBinding activatePending
```

config.security.fabricbinding.addAttachedMembers

Syntax `addAttachedMembers`

Purpose This command adds all the current members of the fabric to the pending FBML. If the domain ID or WWN of a fabric member already exists in the list, it is not added.

Parameters This command has no parameters.

Command Example

```
Root> config security fabricbinding addAttachedMembers
```

config.security.fabricBinding.addMember

Syntax `addMember wwn domainId`

Purpose This command adds a new member to the pending FBML in the fabric binding work area, called the pending FBML. The number of entries is limited to the maximum available domain IDs for the fabric, which is 239.

NOTE: Changes from this command are not activated to the fabric until the *activatePending* command is issued.

Parameters This command has two parameters:

wwn	Specifies the world wide name (WWN) of the member to be added to the Pending FBML. The value of the WWN must be in colon-delimited hexadecimal notation (for example, AA:00:AA:00:AA:00:AA:00).
domainId	The domain ID of the member to be added to the Pending FBML. Valid domain IDs range from 1 to 239.

Command Example

```
Root> config security fabricBinding addMember
AA:99:23:23:08:14:88:C1 2
```

config.security.fabricBinding.clearMemList

Syntax `clearMemList`

Purpose This command clears the Pending FBML in the working area. Members that are attached remain in the list because the pending FBML must contain all attached members to become active.

NOTE: This information is not saved to the fabric until the *activatePending* command is issued. When the list is cleared, the CLI automatically adds the managed switch to the Pending FBML.

Parameters This command has no parameters.

Command Example

```
Root> config security fabricBinding clearMemList
```

config.security.fabricbinding.deactivateFabBind

Syntax `deactivateFabBind`

Purpose This command deactivates the active FBML on the fabric. The Active FBML is erased when this command is executed.

NOTE: This command takes effect immediately in the fabric.

Parameters This command has no parameters.

Command Example

```
Root> config security fabricbinding deactivateFabBind
```

config.security.fabricBinding.deleteMember

Syntax `deleteMember wwn domainId`

Purpose This command removes a member from the Pending FBML in the fabric binding work area. The local member and attached members cannot be deleted from the list.

NOTE: Changes are not activated to the fabric until the *activatePending* command is issued.

Parameters This command has two parameters:

wwn	WWN of the member to be removed from the Pending FBML. The value of the WWN must be in colon-delimited hexadecimal notation (for example, AA:00:AA:00:AA:00:AA:00).
domainId	The domain ID of the member to be removed from the Pending FBML. Valid domain IDs range from 1 to 239.

Command Examples

```
Root> config security fabricBinding deleteMember
AA:99:23:23:08:14:88:C1 2
```

config.security.fabricBinding.replacePending

Syntax

```
replacePending
```

Purpose This command replaces the Pending FBML with the fabric binding configuration that is currently loaded on the fabric.

Parameters This command has no parameters.

Command Example

```
Root> config security fabricBinding replacePending
```

config.security.fabricBinding.showActive

Syntax

```
showActive
```

Purpose This command displays the fabric binding configuration (active FBML) saved on the fabric. It performs the same function as *show.preferredPath.showState* on page 2-236.

Parameters This command has no parameters.

Command Example

```
Root> config security fabricBinding showActive
```

Output This command displays the following fabric binding configuration data:

Domain ID	The domain ID of the FBML member. Valid domain IDs range from 1 to 239.
WWN	The World Wide Name (WWN) of the FBML member in colon-delimited hexadecimal notation.
Attachment Status	Indicates whether the FBML member is Local, Attached, or Unattached. For more information, see *Fabric Binding Membership Terminology* on page 2-62.

Output Example The output from the *config.security.fabricBinding.showActive* command appears as follows.

```
Domain 1  (20:30:40:50:60:70:8F:1A) (Local)
Domain 3  (00:11:22:33:44:55:66:77) (Unattached)
Domain 2  (88:99:AA:BB:CC:DD:EE:FF) (Attached)
Domain 14 (11:55:35:45:24:78:98:FA) (Attached)
```

config.security.fabricBinding.showPending

Syntax `showPending`

Purpose This command displays the pending FBML, which may not reflect what is active on the fabric.

Parameters This command has no parameters.

Command Example

```
Root> config security fabricBinding showPending
```

Output The fabric binding configuration data is displayed as a table that includes the following properties of the Pending FBML.

Domain ID	The domain ID of the FBML member. Valid domain IDs range from 1 to 239.
WWN	The World Wide Name (WWN) of the FBML member in colon-delimited hexadecimal notation.
Attachment Status	Indicates whether the FBML member is Local, Attached, or Unattached. For more information, see *Fabric Binding Membership Terminology* on page 2-62.

Output Example The output from the *config.security.fabricBinding.showPending* command appears as follows.

```
Domain 1  (20:30:40:50:60:70:8F:1A) (Local)
Domain 3  (00:11:22:33:44:55:66:77) (Unattached)
Domain 2  (88:99:AA:BB:CC:DD:EE:FF) (Attached)
Domain 14 (11:55:35:45:24:78:98:FA) (Attached)
```

config.security.portBinding

The Port Binding CLI commands enables users to bind a specific switch or director port to the WWN of an attached node, switch, or director for exclusive communication.

config.security.portBinding.bound

Syntax `bound portNumber portBindingState`

Purpose This command sets the port binding state for a given port.

Parameters This command has two parameters:

portNumber	Specifies the port number for which the port binding state is being set. Valid port number values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

portBindingState	Specifies the port binding state as active or inactive. Valid values are *true* and *false*. *true* sets the port binding to active. The specified port is bound to the WWN configured with the *config.security.portBinding.wwn* command. If no WWN has been configured, no devices can log in to that port. *false* sets the port binding to inactive. Any device is free to connect to the specified port in this state, regardless of the WWN setting. Boolean 1 and 0 may be substituted as values.

Command Examples

```
Root> config security portBinding bound 4 true
Root> config security portBinding bound 4 1
```

config.security.portBinding.show

Syntax

```
show portNumber
```

Purpose

This command shows port binding configuration for a single port.

Parameters

This command has one parameter:

portNumber	Specifies the port number for which the port binding configuration will be shown. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

Command Example

```
Root> config security portBinding show 4
```

Output The port binding configuration date is displayed as a table that includes the following properties:

Port Number	The port number.
WWN Binding	The state of port binding for the specified port: *active* or *inactive*.
Bound WWN	The WWN of the device bound to the specified port. If this field is blank, no device has been bound to the specified port.

Output Example The output from the *config.security.portBinding.show* command appears as follows.

```
Port Number:     4
WWN Binding:     Active
Bound WWN:       AA:99:23:23:08:14:88:C1
```

config.security.portBinding.wwn

Syntax `wwn portNumber boundWwn`

Purpose This command configures the single device WWN to which a port is bound.

Parameters This command has two parameters:

portNumber	Port number for which the bound WWN is being set. Valid port number values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

boundWwn	WWN of the device that is being bound to the specified port. The value must be entered in colon-delimited hexadecimal notation (for example, 11:22:33:44:55:66:AA:BB). If the boundWwn is configured and the portBindState is: *Active*—only the device described by boundWwn can connect to the specified port. *Inactive*—the WWN is retained, but any device can connect to the specified port. Instead of the WWN, either of two values can be entered in this parameter: *attached* automatically configures the currently attached device WWN as the bound WWN. *remove* changes the WWN to the default value, 00:00:00:00:00:00:00:00. Even though this removes the WWN-port association, if the portBindingState value set with the *config.security.portBinding.bound* command is still *true* (the port binding is active), other devices are prevented from logging in to this port. To allow other devices to log in to this port, use the *config.security.portBinding.bound* command to set the portBindingState parameter to *false*.

Command Examples

```
Root> config security portBinding wwn 4
AA:99:23:23:08:14:88:C1

Root> config security portBinding wwn 4 attached

Root> config security portBinding wwn 4 remove
```

config.security.ssh

The Secure Shell feature provides an encrypted connection between an SSH client and the switch. The switch acts as an SSH server to provide secure access to the CLI. This feature solves the telnet issue of user IDs and passwords being passed “in clear text” between the telnet and switch. Telnet results in a lack of security as anyone having access to the IP network or an intermediate IP network, can intercept the user ID and password and then gain unauthorized access to the switch.

config.security.ssh.resetKeys

Syntax `resetKeys`

Purpose This command resets the SSH Public/Private keys. After resetting the keys, the new keys are generated immediately and do not wait until the next user session.

Parameters This command has no parameters

Command Example
```
Root> config security ssh resetKeys
```

config.security.ssh.setRenegotiationMB

Syntax `setRenegotiationMB megabytes`

Description This command sets the number of megabytes that can be transferred using SSH before the SSH session keys are re-negotiated.

It does not affect the SSH public or private key. Instead, it indicates that new SSH session keys should be re-negotiated for the current SSH connection after this number of megabytes has been transferred between the SSH client and the switch. The re-negotiation is transparent to the user. The purpose of re-negotiation is to increase security by limiting the amount of data encrypted with the same negotiated SSH parameters.

Parameters This command has one parameter:

megabytes	The number of megabytes transferred before the SSH session is renegotiated. Valid values are *1 (MB)* to *1000 (MB)* or *0 (no renegotiation)*. The default value is 0.

Command Example
```
Root> config security ssh setRenegotiationMB 128
```

config.security.ssh.setState

Syntax `setState sshEnableState`

Purpose This command sets the enabled state for the SSH interface. In order for an SSH client connection to be accepted, the state must be set to

enable; otherwise, only Telnet can be accepted. Both SSH and Telnet cannot be enabled at the same time.

Parameters This command has one parameter:

sshEnableState	This parameter can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config security ssh setState enable
```

config.security.ssh.show

Syntax

```
show
```

Purpose This command displays the SSH Public key in PEM format, its MD5 fingerprint, its SHA-1 fingerprint, SSH, and Telnet state for the CLI interface.

Parameters This command has no parameters.

Command Example

```
Root> config security ssh show
```

Output The output of the *config.security.ssh.show* command displays the following data:

SSH	Indicates whether the SSH interface to CLI is *enabled* or *disabled*.
Telnet	Indicates whether the Telnet interface to CLI is *enabled* or *disabled*.
Renegotiation MB	The SSH MB limit before renegotiation to take place.
Public Key	The SSH public key's PEM fingerprint.
MD5 Fingerprint	The SSH public key's MD5 fingerprint.
SHA-1 Fingerprint	The SSH public key's SHA-1 fingerprint.

Output Example

```
SSH:                  enabled
Telnet:               disabled
Renegotiation MB:     0

Public Key:
-----BEGIN PUBLIC KEY-----
```

```
MIHxMIGoBgcqhkjOOAQBMIGcAkEAt+W14KwlGwHMzV15vSBxNXpMckhr
3gpVOAkq/6ACLZDDGD8Izlq+mxK0afu7Ir5hexE9v5potwk0fk38kwPh
MQIVAN/hih31RuuaQTNgQNVAtrTDkFBVAkBaYRsm4Fj7/4i8Lt7OydKJ
cYTMAJhJ71UboAVFpmfyVpCQOh3RFK9HfNYJYjkTaSTB3QQt9Hz1HilU
/oKSx8aBA0QAAkEAh0B1piZzDUfXmLuKsIf2sst7lSXfgtkxg85dfpPy
JMSqM6M93D5wM3Nh/O54tSefEDi559HftVsX4YFKmYXV+w==
-----END PUBLIC KEY-----

MD5 Fingerprint:
d1:f2:aa:9d:ec:92:de:38:75:d0:47:2f:9c:cb:b2:02

SHA-1 Fingerprint:
dc:f5:33:c8:e0:8b:01:4b:ce:b5:68:a1:55:2b:dd:8f:a5:5c:8c
:26
```

config.security.switchAcl

The access control list (ACL) feature allows the administrator to configure a set of IP addresses that are allowed to make an IP management connection to the switch or director.

config.security.switchAcl.addRange

Syntax `addRange startIPAddress endIPAddress`

Purpose This command adds a new range of IP addresses to the access control list.

Parameters This command has the following parameters:

startIPAddress	The starting IP Address of the range to be added. The address must be entered in dotted decimal form (such as, 10.0.0.0).
endIPAddress	The ending IP Address of the range to be added. The address must be entered in dotted decimal form (such as, 10.0.0.0).

NOTE: The maximum number of entries in this command is 32.

Command Example

```
Root> config security switchAcl addRange 10.0.0.0
10.0.0.2
```

config.security.switchAcl.deleteRange

Syntax `deleteRange startIPAddress endIPAddress`

Purpose This command deletes a range of IP addresses from the access control list. This range must exactly match one of the existing ranges in the access control list.

Parameters This command has the following parameters:

startIPAddress	The starting IP Address of the range to be deleted. The address must be entered in dotted decimal form (such as, 10.0.0.0). *all* - Using the optional "all" parameter by itself will remove all of the entries from the access control list.
endIPAddress	The ending IP Address of the range to be deleted. The address must be entered in dotted decimal form (such as, 10.0.0.0).

Command Example

```
Root> config security switchAcl deleteRange 10.0.0.0
10.0.0.2
```

config.security.switchAcl.setState

Syntax `setState aclEnabledState`

Purpose This command enables or disables the access control list.

Parameters This command has one parameter:

aclEnabledState	This parameter can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config security switchAcl setState 1
```

config.security.switchAcl.show

Syntax `show`

Purpose This command displays the contents of the access control list.

Parameters This command has no parameters.

Command Example

```
Root> config security switchACL show
```

Output This command displays the following access control list information:

Starting IP Address	The starting IP Address of the range in the access control list.
Ending IP Address	The ending IP Address of the range in the access control list.

Output Example The output from the *config.security.switchAcl.show* command appears as follows.

```
ACL State:  Disabled

Starting IP Address         Ending IP Address
--------------------        -----------------
110.80.1.1                  110.80.255.255
110.81.1.10                 110.81.1.255
200.11.15.1                 200.11.255.128
```

config.security.switchBinding

Switch Binding CLI commands allows users to enable the switch or director to communicate only with nodes, switches, and directors that are listed on the Switch Binding Membership List (SBML). Switch Binding is available only if the SANtegrity Binding feature is installed.

When an unauthorized WWN attempts to log in, it is denied a connection and an event is posted to the Event Log. This provides security in environments that include a large number of nodes, switches, and directors by ensuring that only the specified set of WWNs are able to attach to the managed product.

Enable, Disable and Online State Functions For Switch Binding to function, specific operating parameters and optional features must be enabled. Also, there are specific requirements for disabling these parameters and features.

- Switch Binding can be enabled or disabled whether the switch or director is offline or online.
- Enabling Enterprise Fabric Mode automatically enables Switch Binding.

- If Enterprise Fabric Mode is enabled and the switch or director is online, Switch Binding cannot be disabled.
- If Enterprise Fabric Mode is enabled and the switch or director is offline, users can disable Switch Binding, but this also disables Enterprise Fabric Mode.
- WWNs can be added to the SBML regardless of whether Switch Binding is enabled or disabled.

config.security.switchBinding.addMember

Syntax `addMember wwn`

Purpose This command adds a new member to the SBML. A maximum number of 256 members may be added to the SBML.

Parameters This command has one parameter:

wwn	Specifies the switch or N_Port device WWN of the member to be added to the SBML. The value of the WWN must be in colon-delimited hexadecimal notation (for example, AA:00:AA:00:AA:00:AA:00).

Command Example

```
Root> config security switchBinding addMember
AA:99:23:23:08:14:88:C1
```

config.security.switchBinding.deleteMember

Syntax `deleteMember wwn`

Purpose This command removes a member from the SBML. You cannot remove any member currently logged into the switch or director.

Parameters This command has one parameter:

wwn	Specifies the switch or N_Port device WWN of the member to be removed from the SBML. The value of the WWN must be in colon-delimited hexadecimal notation (for example, AA:00:AA:00:AA:00:AA:00). You may also enter *all* for this argument to clear the SBML completely. Note that you cannot clear a WWN that is currently logged into the switch.

Command Example `Root> config security switchBinding deleteMember AA:99:23:23:08:14:88:C1`

config.security.switchBinding.setState

Syntax `setState switchBindingState`

Purpose This command sets the switch binding state on the switch.

Parameters This command has one parameter:

switchBindingState	Sets the switch binding state for the switch. Valid values are: *disable* - Disables switch binding. Devices (servers, storage, and other switches) are allowed to connect to the switch without restrictions. *eRestrict* - Enables switch binding and restricts E_Port connections. E_Ports are prevented from forming ISL connections unless explicitly identified in the SBML. F_Port connections are allowed without restriction. *fRestrict* - Enables switch binding and restricts F_Port connections. Server and (or) storage devices are prevented from forming F_Port connections with the switch unless explicitly identified in the SBML. E_Ports are allowed to form ISL connections without restriction. *allRestrict* - Enables switch binding and restricts E_Port and F_Port connections. Both E_Ports and F_Ports prohibit connections with all devices unless explicitly identified in the SBML.

Command Example `Root> config security switchBinding setState allRestrict`

config.security.switchBinding.show

Syntax `show`

Purpose This command displays the switch binding configuration.

Parameters This command has no parameters.

Command Example `Root> config security switchBinding show`

Output This command displays the following switch binding configuration data:

switchBindingState	The state of switch binding, which can have the following values: *Disabled* *Enabled and Restricting F_Ports* *Enabled and Restricting E_Ports* *Enabled and Restricting All Ports*
Switch Binding Membership List	The WWNs of members of the SBML saved on the switch.

Output Example The output from the *config.security.switchBinding.show* command appears as follows:

```
Switch Binding State:   Enabled and Restricting E_Ports
00:11:22:33:44:55:66:77
88:99:AA:BB:CC:DD:EE:FF
11:55:35:45:24:78:98:FA
```

config.security.ssl

The Secure Socket Layer (SSL) protocol ensures secure transactions between web servers and browsers. The protocol uses a third party, a Certificate Authority (CA), to identify one or both ends of the transactions using a public key and private key concept. The public key is issued by the web server to the web browser, which uses this key to encrypt its URL and other HTTP data and sends it back to the web server. This encrypted key is decrypted by the web server using a private key.

config.security.ssl.generateKeys

Syntax `generateKeys validDays`

Purpose This command generates a new SSL public certificate and private key. The certificate will be valid for the number of days specified. Unlike the *resetKeys* command, this command does not wait until the next SSL connection to generate the key. Instead, it generates the certificate and private key immediately.

The purpose for generating new keys is to improve the security of the SSL connections in case the private key has been compromised. This is considered to be unlikely, but the generation of new keys is usually performed periodically as a matter of security policy.

Once a new certificate and private key are generated, users will see a message upon SSL connection that indicates that the new certificate is unrecognized. You can then choose to accept or reject the connection. The web browser warning message typically provides an MD5 or SHA-1 fingerprint that allows the user to verify the connection before continuing.

If you choose, you can manually verify the fingerprint shown by the web browser by comparing it with the fingerprint provided at the end of the *config.security.ssl.show* command.

The web browser will display another warning upon expiration of the certificate. At this point, you can either choose to continue or cancel, despite the expiry date.

NOTE: The generation of the certificate and private key can be CPU intensive; therefore it is recommended that this be performed outside of peak hours.

Parameters This command has one parameter:

validDays	The validity of the key in days. Valid values are 30 to 3650 days. This value should be selected as part of a security policy. The certificate and private key should be regenerated before this date expires.

Command Example

```
Root> config security ssl generateKeys 50
```

config.security.ssl.resetKeys

Syntax

```
resetKeys
```

Purpose This command resets the SSL public certificate and private encryption key to factory default values. For the next SSL connection, a new certificate and private key will be created. The new certificate will be valid for one year. The web browser will display a notification when the certificate expires. At this point, you can either choose to continue or cancel, despite the expiry date.

Parameters This command has no parameters.

Command Example
```
Root> config security ssl resetKeys
```

config.security.ssl.setRenegotiationMB

Syntax
```
setRenegotiationMB megabytes
```

Purpose This command sets the megabytes that can be transferred using SSL before the SSL session is automatically re-negotiated. This re-negotiation increases security by limiting the amount of data encrypted with the same negotiated SSL parameters.

This command does not affect the SSL certificate or private key. Instead, it indicates that a new SSL session should be re-negotiated for the current SSL connection after the specified megabytes have been transferred between the SSL client and the switch. The re-negotiation is transparent to the user.

Parameters This command has one parameter:

megabytes	The number of megabytes transferred before the SSL session is re-negotiated. Valid values are *50 (MB)* to *1000 (1000 MB or 1 GB)* or *0*.

Command Example
```
Root> config security ssl setRenegotiation 50
```

config.security.ssl.setWebState

Syntax
```
setWebState sslEnabledState
```

Purpose This command enables the SSL for web interface. In order for a secure (https://) connection to be accepted, the state must be set to *enable*; otherwise, only http://" is accepted. The default WebState access is non-secure.

If SSL is disabled, the https:// URL is rejected. If SSL is enabled, both the http:// and https:// are accepted. However, the http:// URL will immediately redirect the web browser to the https:// URL so that all web communication is secure.

Parameters This command has one parameter:

sslEnabledState	This parameter can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config security ssl setWebState 0
```

config.security.ssl.setAPIState

Syntax

```
setAPIState sslEnabledState
```

Purpose This command sets the enabled state for the SSL API interface. The default API access is non-secure. If SSL is enabled, there is no visual indication provided to the end user.

Parameters This command has one parameter:

sslEnabledState	This parameter can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config security ssl setAPIState 1
```

config.security.ssl.show

Syntax

```
show
```

Purpose This command displays the SSL certificate, its MD5 and SHA-1 fingerprints, and the SSL enabled states for the web and API interfaces.

Parameters This command has no parameters.

Command Example

```
Root> config security ssl show
```

Output

Web Enable State	The SSL enabled state for the web interface.
API Enable State	The SSL enabled state for the API interface.
Renegotiation MB	The SSL MB limit before renegotiation will take place.

Certificate	The SSL certificate.
PEM	The SSL certificate in Privacy Enhanced Mail (PEM) format.
MD5 Fingerprint	MD5 fingerprint of the SSL certificate.
SHA-1 Fingerprint	SHA-1 Fingerprint of the SSL certificate.

Output Example

```
Web SSL State:       Disabled
API SSL State:       Enabled
Renegotiation MB:    50

Certificate:
    Data:
        Version: 3 (0x2)
        Serial Number: 1115038194 (0x427621f2)
        Signature Algorithm: sha1WithRSAEncryption
        Issuer: CN=Switch Serial Number TEST4500, O=Switch Serial Number TEST450
0
        Validity
            Not Before: May  2 12:49:54 2005 GMT
            Not After : Jun 21 12:49:54 2005 GMT
        Subject: CN=172.26.22.212, O=Switch Serial Number TEST4500
        Subject Public Key Info:
            Public Key Algorithm: rsaEncryption
            RSA Public Key: (512 bit)
                Modulus (512 bit):
                    00:ba:7a:de:88:4a:6a:91:49:10:8e:0e:d5:a0:93:
                    43:3f:f4:79:7a:88:a2:c1:17:51:28:c9:bd:2d:d2:
                    e8:ea:d4:86:b0:12:59:7b:06:f4:19:4b:25:a1:06:
                    a1:31:e2:16:9d:e3:c1:d7:47:0e:ab:ef:53:b7:81:
                    82:16:49:21:5f
                Exponent: 65537 (0x10001)
        X509v3 extensions:
            X509v3 Subject Alternative Name:
            DNS:172.26.22.212
    Signature Algorithm: sha1WithRSAEncryption
        5a:6b:7d:b9:35:3e:13:53:61:38:be:bb:54:39:18:39:23:ac:
        52:a1:bf:d4:87:79:22:2c:ee:fb:3e:40:89:3d:97:9e:c7:b3:
        7f:f2:4f:2e:af:67:3c:08:63:71:1b:b3:85:7b:dc:81:a8:3c:
        85:da:84:07:62:2b:a5:83:92:aa


PEM:
-----BEGIN CERTIFICATE-----
MIIBoDCCAUqgAwIBAgIEQnYh8jANBgkqhkiG9w0BAQUFADBQMSYwJAYDVQQDEx1T
d2l0Y2ggU2VyaWFsIE51bWJlciBURVNUNDUwMDEmMCQGA1UEChMdU3dpdGNoIFNl
```

```
cmlhbCBOdW1iZXIgVEVTVDQ1MDAwHhcNMDUwNTAyMTI0OTU0WhcNMDUwNjIxMTI0
OTU0WjBAMRYwFAYDVQQDEw0xNzIuMjYuMjIuMjEyMSYwJAYDVQQKEx1Td2l0Y2gg
U2VyaWFsIE51bWJlciBURVNUNDUwMDBcMA0GCSqGSIb3DQEBAQUAA0sAMEgCQQC6
et6ISmqRSRCODtWgk0M/9Hl6iKLBF1Eoyb0t0ujq1IawEll7BvQZSyWhBqEx4had
48HXRw6r71O3gYIWSSFfAgMBAAGjHDAaMBgGA1UdEQQRMA+CDTE3Mi4yNi4yMi4y
MTIwDQYJKoZIhvcNAQEFBQADQQBaa325NT4TU2E4vrtUORg5I6xSob/Uh3kiLO77
PkCJPZeex7N/8k8ur2c8CGNxG7OFe9yBqDyF2oQHYiulg5Kq
-----END CERTIFICATE-----

MD5:
1F:AC:B8:FF:BD:92:F0:13:E7:43:5E:AB:7F:C4:2D:E6

SHA-1:
5E:4A:0E:91:33:4B:10:75:00:EE:33:A8:AD:55:14:46:F4:E3:6B:43
```

config.snmp

The E/OS provides additional level of security to the existing SNMP framework by supporting SNMPv3 in addition to SNMP versions 1 and 2, which authenticate the SNMP requests based on the community string.

SNMPv3 provides security and access control by supporting a set of authentication protocols (HMAC-MD5-96, HMAC-SHA-96) and a privacy protocol (CBC-DES symmetric encryption protocol). The security and access based on the User-based Security Model (USM) and View-based Access Control Model (VACM) requires using multiple tables: User Table, Access Table, Security-to-Group Table and Target Table. The E/OS CLI provides commands to configure these tables and enables or disables v1-v2/v3 support.

The SNMP client must be configured according to the security and access settings on the agent. To ensure that existing v1 and v2 community strings can continue to communicate with the agent, they must be configured appropriately in SNMPv3.

NOTE: Before enabling SNMPv3, ensure that all desired communities are configured for SNMPv3 access. If existing community strings are not configured for SNMPv3, then existing SNMP access will be lost.

The authentication/privacy key (password) configured for an SNMPv3 User on a switch is not localized. Therefore, the authentication/privacy key configured in the SNMP management application must be configured as a non-localized authentication/privacy key in ASCII format. For more information

on localization, refer to
http://www.ietf.org/rfc/rfc3414.txt?number=3414.

config.snmp.addAccessEntry

Syntax `addAccessEntry index secModel secLevel groupName`

Purpose This command adds an entry to the access table.

Parameters This command has four parameters:

index	Index of the access entry. Valid values are 1 to 12.
secModel	Specifies the Security Model to be used for this entry. Possible values for this parameter are *v1*, *v2* and *usm*.
secLevel	Specifies the security level for this entry. It specifies whether the entry requires authentication and/or privacy. The possible values for this parameter are *authPriv*, *authNoPriv* and *noAuthNoPriv*.
groupName	Specifies the Group Name for the particular Access table entry. The maximum length for the group name is 32 characters and all characters in ISO Latin 1 character set are valid for the group name. Duplicate group names are allowed as long as the groupName, secModel, and secLevel for those entries can specify a Unique Access Table Entry (At least one field differs when the group name is the same).

Using Authentication (Auth): The authentication protocols such as HMAC-MD5 or HMAC-SHA will be used to calculate the hash value for the packet and this calculated Hash value will be sent along with the packets as part of the SNMPv3 Header.

Using privacy (priv): The data part of the packet will be encrypted using a privacy protocol such as DES. Privacy without authentication is not allowed by SNMPv3. Presently, the only authentication protocols supported are HMAC-MD5 and HMAC-SHA. DES is the only privacy protocol that is supported.

Command Example

```
Root> config snmp addaccessentry 1 v2 authpriv joe
```

config.snmp.addAccessViews

Syntax `addAccessViews index secModel secLevel groupName`

Purpose This command sets the views for a particular entry in the access table. This command has a one-to-one mapping with the *config.snmp.addAccessEntry* command.

Parameters This command has four parameters:

index	Index of the access entry. Valid values are 1 to 12.
readView	The name of the Read View. See the View table for possible values.
writeView	The name of the Write View. See the View table for possible values.
notifyView	The name of the Notify View. See the View table for possible values.

Command Example

```
Root> config snmp addaccessview 1 internet management
experimental
```

config.snmp.addCommunity

Syntax `addCommunity commIndex commName writeAuthorization trapRecipient udpPortNum`

Purpose This command adds an SNMP community to the SNMP configuration and specifies a trap recipient.

Parameters This command has five parameters. Up to six community names and trap recipients may be defined as follows:

commIndex	Specifies the community to be created or edited. Valid values are integers in the range 1–6.
commName	Specifies the community name of the community specified by *commIndex*. The community name must not exceed 32 characters in length. Valid characters include all those in the ISO Latin-1 character set. Duplicate community names are allowed but the corresponding *writeAuthorization* values must match.

writeAuthorization	Specifies the write authorization state of the community. Valid values are *enable* and *disable*. Boolean 1 and 0 may be substituted as values.
trapRecipient	Specifies the IP address of the trap recipient. Values must be 4 bytes in dotted-decimal format.
udpPortNum	Specifies the User Datagram Protocol (UDP) port number to which the director sends traps for each recipient. The value can be a decimal number or *default*. The default value is 162. Valid values include all legal UDP port numbers.

Command Example

```
Root> config snmp addCommunity 1 CommunityName1 enabled
123.123.123.123 162
```

config.snmp.addTargetParams

Syntax

```
addTargetParams index secName grpName model level
```

Purpose

This command associates additional USM configuration values to the trap recipient. These values are required to perform the access control validation before sending the trap messages. This command operates on an entry created by one of the following commands: *addv1Target*, *addv2Target*, or *addv3Target*.

Parameters

This command has five parameters:

index	Index of the Target entry. Valid values are indices already created using one of the addv1Target, addv2Target or addv3Target commands.
secName	The Security Name to be used for the corresponding trap entry. The maximum length for the security name is 32 characters and all characters in the ISO Latin-1 character set are valid. This name is the same as the User name in the USM user table. Refer to the command *config.snmp.addUserEntry* on page 22-88.
secModel	Specifies the security model to be used for this entry. Possible values for this parameter are *v1*, *v2* and *usm*.

secLevel	Specifies the security level for this entry. It specifies whether the entry requires authentication and/or privacy. The following values are valid: *authPriv:* Requires both authentication and privacy *authNoPriv:* Requires authentication, but no privacy *noAuthNoPriv*: Requires neither authentication nor privacy

Using Authentication (Auth): The authentication protocols such as HMAC-MD5 or HMAC-SHA will be used to calculate the hash value for the packet and this calculated Hash value will be sent along with the packets as part of the SNMPv3 Header.

Using privacy (priv): The data part of the packet will be encrypted using a privacy protocol such as DES. Privacy without authentication is not allowed by SNMPv3. Presently, the only authentication protocols supported are HMAC-MD5 and HMAC-SHA. DES is the only privacy protocol that is supported.

Command Example

```
Root> config snmp addtargetparams 1 joe v1 authpriv
```

config.snmp.addUserEntry

Syntax

```
addUserEntry index username authPtcl privPtcl
```

Purpose

This command adds a User-based Security Model (USM) user entry to the User Table (RFC 2574). It also specifies the authentication protocol and privacy protocol for this user.

Parameters

This command has four parameters:

index	Index of the target entry. Valid values are 1 to 6.
username	Specifies the User Name (also referred to as Security Name). The maximum length for the User Name is 32 characters. All characters in the ISO-Latin 1 character set are valid. Duplicate entries are not allowed.

authPtcl	Specifies the authentication protocol being used by this user. The possible values for this parameter are *noauth*, *md5* and *sha*. The value *noauth* specifies that this user does not use any authentication protocol. The values *MD5* and *SHA* specify that the respective protocols that are used for authentication. If this parameter is set to MD5 or SHA, then after the command has been executed, the user will be prompted twice for a 16 byte MD5 key, or a 20 byte SHA key.
privPtcl	Specifies the privacy protocol being used by this user entry. This parameter can take the values *noprivacy* and *des*. If this parameter is set to *DES*, then after the prompt for the authentication key, the user will be prompted twice for a 16 byte DES key.

NOTE: Privacy protocol can be selected only when authentication is enabled.

Command Example

```
Root> config snmp adduserentry 1 smith noauth noprivacy

Root> config snmp adduserentry 1 smith md5 des
Auth Password:16 byte key (eg: 1234 5678 9123 4567)
Confirm: Retype the auth password
Privacy Password:16 byte key (eg: 1234 5678 9123 4567)
Confirm: Retype the privacy password
```

config.snmp.addV3Group

Syntax

```
addV3Group index username secModel groupName
```

Purpose

This command configures an entry in the Security-to-Group table. This table is used to map a user to a group and a security model.

Parameters

This command has four parameters:

index	Index of the user entry. Valid values are 1 to 6.

username	Specifies the User Name (also referred as Security Name) for this entry. The maximum length for this User Name is 32 characters. All characters in the ISO-Latin 1 character set are valid for this user name. The same user can be mapped to the same group if the security model is different or, mapped to the same security model with a different group name.
secModel	Specifies the Security Model to be used for this entry. Possible values for this parameter are *v1*, *v2* and *usm*.
groupName	Name of the group to which the v3 User belongs or is mapped. One or more users can be grouped under a single Group Name. Maximum length for Group Name is 32 characters and all characters in the ISO Latin-1 character set are valid. Duplicate values are also allowed.

Command Example

```
Root> config snmp addV3Group 1 smith v2 smithGroup
```

Output Example

The output shows the same user mapped to different groups and security models.

```
Config.SNMP> addv3Group 1 smith v1 smithGroup
Config.SNMP> addv3Group 2 smith USM smithGroup
Config.SNMP> addv3Group 3 smith USM smithOtherGroup
Config.SNMP> showV3Group
SNMPv3 State:    Disabled
Index  Username                          Model  Group Name
-----  --------------------------------  -----  ----------
1      smith                             V1     smithGroup
2      smith                             USM    smithGroup
3      smith                             USM    smithOtherGroup
```

config.snmp.addV1Target

Syntax

```
addV1Target index community [IP] [udpNum]
```

Purpose

This command configures v1 community string. The IP address and port number of v1 trap recipient can be optionally specified. The community string can be used for v1 access only if mapped to a security and group name.

Parameters This command has four parameters. The last two are optional.

index	Index of the target entry. Valid values are 1 to 6.
community	Community string of the target entry. The maximum length of the community string is 32 characters. All characters in the ISO Latin-1 character set are valid for community names. Duplicate community names are allowed, but the corresponding security names (refer to the command *config.snmp.addTargetParams* on page 22-87) must also match.
IP	The address of the trap recipient shown in 4-byte dotted-decimal format.
udpNum	The UDP port number of the trap recipient, to which the SNMP agent will send the traps. This value is expressed in decimal and the default value is 162. The default number is assumed if this field is replaced with *default*. All legal UDP port numbers are allowed. If the IP address is specified and this parameter is not specified, it will be set to the default value.

Command Example

```
Root> config snmp addv1target 4 joe 125.26.78.95 162
```

config.snmp.addV2Target

Syntax

```
addV2Target index community [IP] [udpNum]
```

Purpose This command configures v2 community string. The IP address and port number of v2 trap recipient can be optionally specified. The community string can be used for v2 access only if mapped to a security and group name.

Parameters This command has four parameters. The last two are optional.

index	Index of the target entry. Valid values are 1 to 6.

community	Community string of the target entry described by the index. The maximum length of the community string is 32 characters. All characters in the ISO Latin-1 character set are valid for community names. Duplicate community strings are allowed.
IP	The IP address of the trap recipient shown in 4-byte dotted-decimal format.
udpNum	UDP Port Number of the trap recipient to which the SNMP agent will send the traps. This value is expressed in decimal and the default value is 162. The default number is assumed if this field is replaced with "default". All legal UDP port numbers are allowed. If the IP address is specified and this parameter is not specified, it will be set to the default value.

Command Example

```
Root> config snmp addv2target 3 smith 125.26.78.96 162
Root> config snmp addv2target 3 smith
```

config.snmp.addV3Target

Syntax

```
addV3Target index [IP] [udpNum]
```

Purpose

This command configures the IP address and optionally the port number of a v3 trap recipient. The community name is not used for v3 Traps.

Parameters

This command has three parameters. The last one is optional.

index	Index of the target entry. Valid values are 1 to 6.
IP	The address of the trap recipient shown in 4-byte dotted-decimal format.
udpNum	UDP port number of the Trap recipient to which the SNMP agent will send the traps. This value is expressed in decimal and the default value is 162. The default number is assumed if this field is replaced with "default". All legal UDP port numbers are allowed. If this parameter is not specified, it will be set to the default value.

Command Example

```
Root> config snmp addv3target 6 124.56.67.98 165
Root> config snmp addv3target 6 124.56.67.98
```

config.snmp.authTraps

Syntax `authTraps enabledState`

Purpose This command enables or disables the authentication traps to be sent to the SNMP management stations when unauthorized stations try to access SNMP information from the director or switch.

Parameters This command has one parameter:

enabledState	Specifies whether the authentication traps are enabled. Valid values are *enable* and *disable*. Boolean 1 and 0 may be substituted as values.

Command Examples

```
Root> config snmp authTraps enable

Root> config snmp authTraps 1
```

config.snmp.deleteAccessEntry

Syntax `deleteAccessEntry index`

Purpose This command deletes the specified entry from the access table.

Parameters This command has 1 parameter:

commIndex	Index of the access entry. Valid values are 1 to 6.

Command Example

```
Root> config snmp deleteAccessEntry 1
```

config.snmp.deleteCommunity

Syntax `deleteCommunity commIndex`

Purpose This command deletes an SNMP community and trap recipient, if configured.

Parameters This command has one parameter:

commIndex	Specifies the community to be deleted. Valid values are integers in the range 1–6. This value was set in the commIndex parameter of the *config.snmp.addCommunity* command.

Command Example
```
Root> config snmp deleteCommunity 5
```

config.snmp.deleteUserEntry

Syntax `deleteUserEntry index`

Purpose This command deletes the specified user entry from the user table.

Parameters This command has one parameter:

index	Index of the user entry. Valid values are 1 to 6.

Command Example
```
Root> config snmp deleteUserEntry 1
```

config.snmp.deleteTargetEntry

Syntax `deleteTargetEntry index`

Purpose This command deletes the specified entry from the target table.

Parameters This command has one parameter:

Index	Index of the target entry. Valid values are 1 to 6.

Command Example
```
Root> config snmp deletetargetentry 1
```

config.snmp.deleteV3Group

Syntax `deleteV3Group index`

Purpose This command deletes the specified entries from the Security-to-Group table.

Parameters This command has one parameter:

index	Index of the user entry. Valid values are 1 to 6.

Command Example

```
Root> config snmp deleteV3Group 1
```

config.snmp.sendTestTrap

Synopsis

```
sendTestTrap
```

Purpose This command instantly generates the *fcConnUnitEvent* trap with event type as "status" and event description as "Reason code 0".

Parameters This command has no parameters.

Command Example

```
Root> config snmp sendTestTrap
```

config.snmp.setSNMPv3State

Syntax

```
setSNMPv3State enabledState
```

Purpose Enables / disables SNMPv3.

NOTE: If the SNMP User Table, Access Table, and Security-to-Group Tables are not properly configured, SNMP access will be lost upon completion of this command. Use the command *config.snmp.validateUser* to ensure proper configuration of user entries.

Parameters This command has one parameter:

enabledState	Enabled state of SNMPv3. This can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config snmp setSNMPv3State enable
```

config.snmp.setFaMibVersion

Syntax

```
setFaMibVersion versionNumber
```

Purpose This command sets the version of the Fibre Alliance MIB with which the SNMP agent interacts. The version number can be set to 3.0 or 3.1.

Parameters This command has one parameter:

versionNumber	Sets the version of the Fibre Alliance MIB version number. Accepted values for this command are 3.0 or 3.1.

Command Example

```
Root> config snmp setFaMibVersion 3.1
```

config.snmp.setState

Syntax

```
setState enabledState
```

Purpose This command enables or disables the SNMP agent. When disabled, the SNMP agent does not respond to any requests or send any traps.

Parameters This command has one parameter:

enabledState	Sets the state of the SNMP agent. This parameter can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config snmp setState 1
```

config.snmp.show

Syntax

```
show
```

Purpose This command shows the SNMP configuration of the switch.

Parameters This command has no parameters.

Command Example

```
Root> config snmp show
```

Output The switch configuration data is displayed as a table that includes the following properties:

SNMP Agent State	The state of the SNMP agent. If it is disabled, the SNMP agent does not respond to any requests and does not produce any traps.

FA MIB Version Number	Version of the Fibre Alliance MIB (FA MIB) that the SNMP agent is configured to use.
Authentication Traps	The state of the authentication traps (for example, *enabled*) that are sent to SNMP management stations when unauthorized stations attempt to access SNMP information from the switch.
Index	The community index number.
Community Name	The name of the community.
WriteAuth	The write authorization state.
Trap Recipient	The address of the trap recipient shown in 4-byte dotted-decimal format.
UDP Port	The User Datagram Protocol (UDP) port number to which the switch will send traps for each recipient.

Output Example The output from the *config.snmp.show* command appears as follows:

```
SNMP Agent State:        Enabled
FA MIB Version Number:   3.0
Authentication Traps:    Enabled
Index  Community Name                  WriteAuth  Trap Recipient    UDP Port
-----  ------------------------------  ---------  ---------------   ------
1      CommunityName1                  Enabled    123.123.123.123   162
2      CommunityName2                  Enabled    10.25.25.10       144
3      CommunityName3                  Disabled   132.44.85.224     162
4      public                          Enabled                      162
5
6
```

config.snmp.showAccessTable

Syntax `showAccessTable [index]`

Purpose This command displays the configured values for the access table.

Parameters This command has one optional parameter:

index	Index of the access entry. Valid values are 1 to 12.

Command Example

```
Config.SNMP> showAccessTable
SNMPv3 State:    Enabled
Index  Group Name
```

```
-----  ----------
1      group1
2
3
4      v1Group
5
6
7      v2Group
8
9
10     usmGroup
11     usmGroup
12
```

or

If you specify the index, the output of this command will contain the following data:

Index	Index of the access entry. Valid values are 1 to 6.
Group Name	The group name.
Security Model	The security model.
Security Level	The security level.
Read View	The read view name.
Write View	The write view name.
Notify View	The notify view name.

```
Config.SNMP> showAccessTable 1
Index:              1
Security Model:     Any
Security Level:     None
Group Name:         group1
Read View:          fcmgmt_3_1
Write View:         fceos
Notify View:        internet
```

config.snmp.showTargetTable

Syntax `showTargetTable [index]`

Purpose This command displays the configured values for the target table.

Parameters This command has one optional parameter:

index	Index of the access entry. Valid values are 1 to 6.

Command Example

```
Config.SNMP> showTargetTable

SNMPv3 State:    Enabled
Index  Target IP       UDP Port  Community                          MP Model
-----  -------------   --------  ---------------------------------  --------
1      172.19.16.169   162       public                             SNMPv1
2
3
4
5
6
```

or

Specifying the index will give the following output:

```
Config.SNMP> showTargetTable 1

Index:              1
Target IP:          172.19.16.169
UDP Port:           162
Community Name:     public
MP Model:           SNMPv1
Security Name:      user1
Security Model:     V1
Security Level:     No Authentication and No Privacy
```

These are explained in the table below.

SNMPv3 State	Indicates whether SNMPv3 is enabled.
Index	The index number.
Target IP	The IP address of the trap recipient.
UDP Port	The UDP port of the trap recipient.
Community	The community name.
MP Model	The messaging model.

Security Name	The security name (user name).
Security Model	The security model.
Security Level	The security level.

NOTE: The command *show.snmp.targetTable* on page 22-242 has functionality that is same as that of this command.

config.snmp.showUserTable

Syntax `showUserTable [index]`

Purpose This command displays the users configured presently in the USM table.

Parameters This command has no parameters.

Output This command displays the following switch configuration data:

SNMPv3 State	Indicates whether SNMPv3 is enabled.
Index	The index number.
Username	The user name.
Auth Protocol	The authentication protocol.
Privacy Protocol	The privacy protocol.

Command Example

```
Config.SNMP> showUserTable

SNMPv3 State:    Enabled
Index  Username                          Auth Protocol      Privacy Protocol
-----  --------------------------------  -----------------  ----------------
1      User1                             No Authentication  No Privacy
2      User2                             HMAC-MD5           No Privacy
3      User3                             HMAC-SHA           DES
4
5
6
```

NOTE: This command and the command *show.snmp.userTable* on page 22-243 has the same functionality.

config.snmp.showV3GroupTable

Syntax `showV3GroupTable`

Purpose This command displays the Security-to-Group table.

Parameters This command has no parameters.

Output This command displays the following switch configuration data:

SNMPv3 State	Indicates whether SNMPv3 is enabled or disabled.
Index	The index number.
Username	The username.
Model	The security model.
Group Name	The group name.

Example

```
config.SNMP> showV3GroupTable
SNMPv3 State:    Enabled
Index  Username                          Model  Group Name
-----  --------------------------------  -----  ----------
1      User1                             V1     Group1
2
3
4
5
6
```

NOTE: This command and the command *show.snmp.V3GroupTable* on page 22-244 has the same functionality.

config.snmp.showViewTable

Syntax `showViewTable`

Purpose This command displays the values for the VACM views presently configured.

Parameters This command has no parameters.

Output This command displays the following switch configuration data:

View Name	The name of the view.
Type	The type of the view.
Object ID	The Object ID.

Command Example `config.snmp> showViewTable`

```
View Name                        Type                Object ID
-------------------------------  ------------------  ---------
no_access                        View Excluded       .1.3.6.1
internet                         View Included       .1.3.6.1
management                       View Included       .1.3.6.1.2
experimental                     View Included       .1.3.6.1.3
private                          View Included       .1.3.6.1.4
snmpv3                           View Included       .1.3.6.1.6
fceos                            View Included       .1.3.6.1.4.1.289
fcmgmt_3_1                       View Included       .1.3.6.1.2.1.8888
fcmgmt_3_0                       View Included       .1.3.6.1.3.94
fcfe                             View Included       .1.3.6.1.3.42
system                           View Included       .1.3.6.1.2.1.1
ip                               View Included       .1.3.6.1.2.1.4
```

config.snmp.validateUser

Syntax `validateUser username secModel secLevel`

Purpose This command searches the user, group, and access tables for the given username, security model, and security level. If the username, security model, and security level cannot be traced in these tables, a message will be displayed with the reason.

Parameters This command has three parameters:

username	The user name for the user validation.
secModel	The security model of the user.
secLevel	The security level of the user.

Output This command displays the following switch configuration data:

Username	The user name.
Auth Protocol	The authentication protocol used for this user.
Priv Protocol	The privacy protocol used for this user.
Security Model	The security model for this user.
Security Level	The security level for this user.
Context Match	The context match method.
Group Name	The group that this user belongs to.
Read View	The read view access for this user.
Write View	The write view access for this user.
Notify View	The notify view access for this user.

Command Example

```
Root> Config SNMP validateUser Jerry v1 noauthnopriv

Username:           Jerry
Auth Protocol:      No Authentication
Priv Protocol:      No Privacy
Security Model:     V1
Security Level:     No Authentication and No Privacy
Context Match:      Prefix
Group Name:         Group1
Read View:          internet
Write View:         management
Notify View:        private
```

config.switch

All commands under this branch operate on a particular switch attribute. Switch attributes are specific to the Fibre Channel switch nature of the product.

Some of the *config.switch* commands require that the switch be set offline. (Use the *maint.system.setOnlineState* to set the switch offline.) If some of these commands are entered while the switch is online, an error message results.

config.switch.apiState

Syntax `apiState apiEnabledState`

Purpose This command sets the state of the API interface. When disabled, access through the API interface will be turned off.

Parameters This command has one parameter:

apiEnabledState	This parameter can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config switch apiState enable
```

config.switch.banner

The banner command on the configuration branch enters the banner configuration branch. All commands operate on the banner content and the state of the banner.

This configured banner text is displayed during login through CLI or EFCM Basic, if banner state is enabled. Refer to *config.switch.banner.bannerText* for configuring the banner text.

For example, when the user connects to the switch using the telnet command:

```
McDATA (R) Fibre Channel Director Firmware Version
09.00.00

Access is restricted to Authorized personnel only

Username>
```

config.switch.banner.bannerText

Syntax `bannerText lineNumber lineContent`

Description This command configures the banner text for a particular line number.

Parameters This command has two parameters:

lineNumber	Specifies the line number in the banner text. This can take a value from 0 to 24.
lineContent	The text for a particular line. If an empty line is to be displayed, an empty string in double quotes is to be configured. For a string that is separated by spaces, the entire string should be enclosed within quotes. This has an 80 character limitation and accepts alphanumeric characters.

Command Example

```
config.switch.banner> bannerText 1 "McDATA (R) Fibre
Channel Director Firmware Version 08.00.00"

config.switch.banner> bannerText 2 "Access is restricted
to Authorized personnel only"

config.switch.banner> bannerText 3 " "
```

config.switch.banner.setCLIState

Syntax `setCLIState state`

Description This command configures the enabled state for whether the configured banner will get displayed at the CLI login prompt.

Parameters This command has one parameter.

state	The enabled/disabled state for CLI banner. This parameter can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config switch banner setCLIState 1
```

config.switch.banner.setWebState

Syntax `setWebState state`

Description This command configures the enabled state for whether the configured banner will get displayed at the Web login.

Parameters This command has one parameter.

state	The enabled/disabled state for CLI banner. This parameter can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config switch banner setWebState 0
```

config.switch.banner.show

Syntax

```
show
```

Description This command displays the configured banner.

Parameters This command has no parameters.

Command Example

```
Root> config switch banner show
```

Output The login banner and settings are displayed on the screen.

Output Example

```
Config.Switch> banner
Config.switch.banner> show
CLI Banner Enabled State:    Disabled
Web Banner Enabled State:    Disabled
Banner content:
McDATA (R) Fibre Channel Director Firmware Version
09.00.00
Access is restricted to Authorized personnel only
config.switch.banner>
```

config.switch.domainIDOffset

Syntax

```
domainIDOffset offset
```

Description This command configures the offset of the Domain ID range in which the switch or director should operate.

Parameters This command has one parameter:

offset	The Domain ID offset. Values are in hexadecimal. Valid values are: *00* *32* *64* *96* *128* *160* *192*

Command Example

```
Root> config switch domainIDOffset 160
```

config.switch.domainRSCN

Syntax

```
domainRSCN domainRSCNState
```

Purpose Sets the domain RSCN state for the switch or director. You can run this command when the switch or director is either offline or online. When this parameter is enabled, domain registered state change notifications (domain RSCNs) are sent between end devices in a fabric to provide additional connection information to host bus adapters (HBA) and storage devices.

As an example, this information might be that a logical path has been broken because of a physical event, such as a fiber optic cable being disconnected from a port.

Parameters This command has one parameter:

domainRSCNState	Specifies whether the domain RSCN state is enabled. Valid values are *enable* and *disable*. Boolean 1 and 0 may be substituted as values.

Command Example

```
Root> config switch domainRSCN 1
```

config.switch.edTOV

Syntax `edTOV timeoutValue`

Purpose Sets the error detect timeout value (E_D_TOV) for the switch.

NOTE: The switch must be set offline before this command is entered.

Special care should be used when scripting this command due to its relationship with R_A_TOV.

Parameters This command has one parameter:

timeoutValue	Specifies the new E_D_TOV value. The units for this value are tenths of a second. This parameter must be an integer in the range 2–600 (0.2 second to 60 seconds), and it must be smaller than the R_A_TOV.

Command Example

```
Root> config switch edTOV 4
```

config.switch.haMode

Syntax `haMode haEnabledState`

Purpose This command sets the state of high availability.

Parameters This command has one parameter:

haEnabledState	This parameter can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config switch haMode enable
```

NOTE: This command is applicable only to Sphereon 4400.

config.switch.insistDomainId

Syntax `insistDomainId insistentDomainIdState`

Purpose This command sets the insistent domain ID state for the switch.

Parameters This command has one parameter:

insistentDomainIdState	Specifies whether the insistent domain ID state is enabled. Valid values are *enable* and *disable*. Boolean 1 and 0 may be substituted as values.

Command Example

```
Root> config switch insistDomainId 1
```

NOTE: The Insistent Domain ID must be enabled if the Enterprise Fabric Mode (an optional SANtegrity feature) or Preferred Path is enabled.

config.switch.interopMode

Syntax

```
interopMode interopMode
```

Purpose This command sets the interoperability mode for the switch. The switch must be offline to complete this command.

NOTE: The switch must be set offline before this command is entered.

Parameters This command has one parameter:

interopMode	Specifies the interoperability mode. Valid values are *mcdata* and *open*: *mcdata* — McDATA Fabric 1.0. Select this mode if the fabric contains only McDATA switches and directors that are also operating in McDATA Fabric 1.0 mode. *open* — Open Fabric 1.0. Select this mode if the fabric contains McDATA switches and directors and other Open Fabric-compliant switches. Select this mode for managing heterogeneous fabrics.

Command Example

```
Root> config switch interopMode open
```

config.switch.islFSPFCost

Syntax

```
islFSPFCost islFSPFCostState
```

Purpose This command configures the Fabric Shortest Path First (FSPF) cost of Inter-Switch Links (ISLs) on the switch. Cost is used to determine the

shortest path (or the path which would take the least amount of time for traffic to travel) to a destination.

Parameters This command has two parameters:

ignore	Every ISL has the same FSPF cost. In essence, the actual FSPF cost is ignored.
port	Each ISL has a McDATA default cost, which depends on the speed of the port.

TIP: It is recommended that all the switches in the fabric to be configured have the same value for the ISL FSPF Cost Configuration parameter.

Command Example
```
Root> config switch islFSPFCost ignore
```

config.switch.ltdFabRSCN

Syntax
```
ltdFabRSCN ltdFabRSCNState
```

Purpose This command sets the status of limited fabric RSCNs. When enabled, fabric registered state change notifications (RSCNs) are suppressed during an IPL.

Parameters This command has one parameter:

ltdFabRSCNState	Specifies whether the limited fabric RSCN state is enabled. Valid values are *enable* and *disable*. Boolean 1 and 0 may be substituted as values.

Command Example
```
Root> config switch ltdFabRSCN 1
```

config.switch.prefDomainId

Syntax
```
prefDomainId domainId
```

Purpose This command sets the preferred domain ID for the switch or director. The switch or director must be offline to complete this command.

Parameters This command has one parameter:

domainId	Specifies the new preferred domain ID value. This parameter must be an integer in the range 1–31.

Command Example

```
Root> config switch prefDomainId 1
```

config.switch.priority

Syntax

```
priority Priority
```

Purpose This command sets the switch priority.

NOTE: The switch must be set offline before this command is entered.

Parameters This command has one parameter:

Priority	Specifies the switch priority. Valid values are: *principal*, *default*, or *neverprincipal*. *principal* — sets the numerical switch priority to 1. The switch with a priority of 1 becomes the principal switch; however, if two or more switches have a priority of 1, the switch with the lowest WWN becomes the principal switch. *default* — sets the numerical switch priority to 254. If no switch is set to principal, the switch with a priority 254 becomes the principal switch; however, if two or more switches have a priority of 254, the switch with the lowest WWN becomes the principal switch. *neverprincipal* — sets the numerical switch priority to 255. This disables the switch from becoming a principal switch. At least one switch in a multiswitch fabric must have a switch priority value of *principal* or *default*. The number codes 2–253 are not in use now.

Command Example

```
Root> config switch priority principal
```

config.switch.raTOV

Syntax `raTOV timeoutValue`

Purpose This command sets the resource allocation timeout value (R_A_TOV) for the switch.

NOTE: The switch must be set offline before this command is entered.

Special care should be taken when scripting this command due to its relationship with E_D_TOV.

Parameters This command has one parameter:

timeoutValue	Specifies the new R_A_TOV value. The units for this value are tenths of a second. This parameter must be an integer in the range 10–1200 (1 second to 120 seconds), and it must be greater than the E_D_TOV.

Command Example

```
Root> config switch raTOV 20
```

config.switch.rerouteDelay

Syntax `rerouteDelay rerouteDelayState`

Purpose This command enables or disables the rerouting delay for the switch.

NOTE: The switch can be either offline or online when this command is executed.

This command is only applicable if the configured switch is in a multiswitch fabric. Enabling the rerouting delay ensures that frames are delivered in order through the fabric to their destination.

If there is a change in the fabric topology that creates a new path (for example, a new switch is added to the fabric), frames may be routed over this new path if its hop count is less than a previous path with a minimum hop count. This may result in frames being delivered to a destination out of order because frames sent over the new, shorter path may arrive ahead of older frames still in route over the older path.

If rerouting delay is enabled, traffic ceases in the fabric for the time specified in the *config.switch.edTOV* command. This delay allows frames sent on the old path to exit to their destination before new frames begin traversing the new path. Note that during this delay period, frames addressed to the destinations that are being rerouted are discarded if they are Class 3 frames and rejected if they are Class 2 or Class F frames.

Parameter This command has one parameter:

rerouteDelayState	Specifies whether rerouting delay is enabled. Valid values are *true* and *false*. Boolean 1 and 0 may be substituted as values.

Command Example

```
Root> config switch rerouteDelay true
```

config.switch.RSCNZoneIsolation

Syntax

```
RSCNZoneIsolation RSCNZoneIsolationState
```

Description This command configures the state of RSCN Zone Isolation.

Parameters This command has one parameter:

RSCNZoneIsolationState	This parameter can be set to *fabric* and *none*. When set to *fabric*, RSCNs will only be sent to affected fabric members when zoning information changes. When set to *none*, filtering of RSCNs will not take place, and RSCNs will be sent to all zoneset members when zoning information changes.

config.switch.safeZoning

Syntax

```
safeZoning safeZoningState
```

Purpose This command sets the state for safe zoning. When enabled, zone merges will not happen unless zone sets are equivalent; in addition, the option to set the default zone will be disabled.

Parameters This command has one parameter:

safeZoningState	This parameter can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config switch safeZoning enable
```

config.switch.speed

Syntax

```
speed switchSpeed
```

Purpose This command sets the speed for the switch.

NOTE: This command is only applicable for the Intrepid 6064.

NOTE: The switch must be set offline before this command is entered.

A switch can be configured to operate at 1 Gbps or 2 Gbps.

If the switch has FPM cards, configuring the switch speed to 2 Gbps makes all the ports on the FPM cards inactive, and their operational state will be set to inactive. FPM ports do not support 2 Gbps and, therefore, will remain inactive after the switch is returned to the online state.

Parameters This command has one required parameter.

switchSpeed	Specifies the speed of the switch. Valid values are *1 Gb/s* or *2 Gb/sec*.

Command Examples

```
Root> config switch speed 2g
```

config.switch.show

Syntax

```
show
```

Purpose This command displays the switch configuration.

NOTE: The switch can be either offline or online when this command is executed.

Parameters This command has no parameters.

Command Example

```
Root> config switch show
```

Output The switch configuration data is displayed as a table that includes the following properties:

R_A_TOV	Resource Allocation Time Out Value. This time outs the operations that depend on the maximum possible time that a frame can be delayed in a fabric and still be delivered.
E_D_TOV	Error Detect Time Out Value. This indicates the maximum turnaround time that an operation could require.
Preferred Domain ID	The preferred domain ID of the switch.
Switch Priority	The switch priority. Values are *Principal* is *1*, *Default* is *2 to 254*, or *Never Principal* is *255*.
Speed	The switch speed. (This is available only for intrepid 6064)
Rerouting Delay	The rerouting delay that ensures that frames are delivered in order through the fabric to their destination. Values are *Enabled* or *Disabled*.
Interop Mode	Interoperability mode for the switch.
Insistent Domain Id	When enabled, this ensures that the embedded firmware cannot change the preferred domain ID of a switch.
Domain RSCN	When enabled, this allows domain RSCNs to be sent to registered members of the fabric.
Zoning RSCN	When enabled, allows zoning RSCNs to be sent to registered members of the fabric.
Limited Fabric RSCN	When enabled, fabric RSCNs are suppressed after an IPL.
Zone FlexPars	When set to *fabric*, RSCNs will only be sent to affected fabric members when zoning information changes. When set to *none*, filtering of RSCNs will not take place, and RSCNs will be sent to all zoneset members when zoning information changes.

RSCN Zone Isolation	When set to *fabric*, RSCNs will only be sent to affected fabric members when zoning information changes. When set to *none*, filtering of RSCNs will not take place, and RSCNs will be sent to all zoneset members when zoning information changes.
Safe Zoning	Safe Zoning State.
ISL FSPF Cost	The method for computing the FSPF cost for ISLs.
Web Enable	The enabled state of web.
API Enable	API enable state.
HA Mode	The enabled state of high availability mode.
Domain ID offset	This configures Domain ID offset.
PassExpirationDays	The password expiration time in days for the management users.

Output Example The output from the *config.switch.show command* appears as follows:

```
R_A_TOV:                100
E_D_TOV:                20
Preferred Domain ID:    1
Domain ID Offset:       96
Switch Priority:        Default
Speed:                  2 Gb/sec
Rerouting Delay:        Disabled
Interop Mode:           McDATA Fabric 1.0
Insistent Domain ID:    Enabled
Domain RSCN:            Enabled
Zoning RSCN:            Enabled
Limited Fabric RSCN:    Disabled
Zone FlexPars:          No Filtering
RSCN Zone Isolation:    No Filtering
Safe Zoning:            Disabled
ISL FSPF Cost:          By Port Speed
Web Enabled:            Enabled
API Enabled:            Enabled
Password Exp. Time:     0
```

config.switch.webState

Syntax `webState webEnabledState`

Purpose This command sets the state of the web interface. When disabled, access through the web interface will be turned off.

Parameters This command has one parameter:

webEnabledState	This parameter can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config switch webState enable
```

config.switch.zoneFlexPars

Syntax

```
zoneFlexPars zoneFlexParstate
```

Purpose This command configures the state of Zone FlexPars.

Parameters This command has one parameter:

zoneFlexParsState	This parameter can be set to *fabric* and *none*. When set to *fabric*, RSCNs will only be sent to affected fabric members when zoning information changes. When set to *none*, filtering of RSCNs will not take place, and RSCNs will be sent to all zoneset members when zoning information changes.

Command Example

```
Root> config switch zoneFlexPars fabric
```

config.switch.zoningRSCN

Syntax

```
zoningRSCN  zoningRSCNState
```

Description This command sets the state of Zoning RSCNs.

Parameters This command has one parameter:

zoningRSCNState	This parameter can be set to *enable*, *disable*, *true*, or *false*. Boolean 1 and 0 values may also be substituted.

config.syslog

The syslog feature records events such as logins, configuration changes, and error messages that occur on the switch. If an error condition occurs, the switch attempts to write an entry to the system

log. The syslog feature will send the user requested logs (supported logs) to the syslog service on a remote host.

You may configure up to three remote syslog recipients. A single facility may be configured for each remote syslog recipient and the default is *Local 0*. All syslog facilities are limited to the *local use* facility (Local 0 - Local 7).

config.syslog.addServer

Syntax `addServer index IP facility`

Purpose This command configures a syslog server at a given index.

Parameters This command has three parameters:

index	The index number for the server. Possible values are 1 to 3.
IP	The IP address of the server.
facility	The facility for the server. Possible values are *Local0 - Local7*.

Command Example

```
Root> config syslog addserver 1 121.34.56.78 Local1
```

config.syslog.deleteServer

Syntax `deleteServer index`

Purpose This command deletes a syslog server configuration.

Parameters This command has one parameter:

index	The index number of the server to be deleted. Possible values are 1 to 3.

Command Example

```
Root> config syslog deleteserver 2
```

config.syslog.setLogConfig

Syntax `setLogConfig logName state`

Purpose This command enables syslog support for the given log.

Parameters This command has two parameters:

logName	The log type. Possible values are *Event*, *Trunking*, *Link*, *Security*, *Audit*, *Fabric*, *and Frame*.
state	This parameter can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted. If the state is enabled, messages for that log will be sent to the configured syslog servers.

Command Example

```
Root> config syslog setLogConfig event enable
```

config.syslog.setState

Syntax

```
setState enabledState
```

Purpose This command sets the enabled or disabled state for the syslog feature.

Parameters This command has one parameter:

enabledState	This parameter can be set to *enable* or *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> config syslog setState enable
```

config.syslog.show

Syntax

```
show
```

Purpose This command displays the syslog configuration.

NOTE: The command *show.syslog* on page 2-251 has functionality that is the same as this command.

Parameters This command has no parameters.

Output

The syslog configuration is shown as a table of properties. The following properties are displayed:

Log	The index number of the server.
State	Reports if syslog support is enabled.
Index	The index number of the server.
IP Address	The IP address of the server.
Facility	The facility level for the server. Values are *Local 0 - Local 7*.

Command Example

```
Root>Config SysLog show
Syslog State:    Disabled
Index  IP Address       Facility
-----  ---------------  --------
1      172.16.22.23     Local 0
2
3      180.77.66.55     Local 5

Log                           State
----------------------------  --------
Event Log                     Enabled
Open Trunking Re-Route Log    Disabled
Link Incident Log             Disabled
Security Log                  Enabled
Audit Log                     Enabled
Fabric Log                    Enabled
Embedded Port Frame Log       Disabled
```

config.system

With the system command, the configuration branch enters the system configuration branch. All commands under this branch operate on a particular system attribute. System attributes are generic attributes that are not specific to Fibre Channel, and thus would be present on any product.

config.system.contact

Syntax

```
contact systemContact
```

Purpose

This command sets the system contact attribute.

Parameters This command has one parameter:

systemContact	Specifies the new system contact string for the director or switch. The contact can contain 0–255 characters.

Command Example

```
Root> config system contact Joe
```

config.system.date

Syntax

```
date systemDate systemTime
```

Purpose This command sets the system date and time.

Parameters This command has two required parameters:

systemDate	Specifies the new system date. The format of the date parameter must be mm:dd:yyyy or mm/dd/yyyy. Valid date values include: mm: 1–12 dd: 1–31 yyyy: >1980
systemTime	Specifies the new system time. The format of the time parameter must be hh:mm:ss. Valid time values include: hh: 0–23 mm: 0–59 ss: 0–59

Command Examples

```
Root> config system date 04:16:2001 10:34:01
Root> config system date 10/09/2001 14:07:55
```

config.system.description

Syntax

```
description systemDescription
```

Purpose This command sets the system description string.

Parameters This command has one parameter:

systemDescription	Specifies the new system description string for the director or switch. The name can contain 0–255 characters.

Command Example

```
Root> config system description
McDATAIntrepid6140FibreChannelDirector
```

config.system.location

Syntax

```
location systemLocation
```

Purpose This command sets the system location attribute.

Parameters This command has one parameter:

systemLocation	Specifies the new system location for the director or switch. The location can contain 0–255 characters.

Command Example

```
Root> config system location Everywhere
```

config.system.name

Syntax

```
name systemName
```

Purpose This command sets the system name attribute.

Parameters This command has one required parameter:

systemName	Specifies the new system name for the switch or switch. The name can contain 0–24 characters.

Command Example

```
Root> config system name JoeSwitch
```

config.system.show

Syntax

```
show
```

Purpose This command shows the system configuration.

Parameters This command has no parameters.

Command Example

```
Root> config system show
```

Output The system configuration is displayed as a table that includes the following properties:

Name	The system name.
Description	The system description.
Contact	The system contact.
Location	The system location.
Date/Time	The system date and time.

Output Examples The output from the *config.system.show* command appears as follows:

```
Name:          Joe's Switch
Description:   McDATA Intrepid 6140 Fibre Channel Director
Contact:       Joe
Location:      Everywhere
Date/Time:     04/16/2001  10:34:01
```

config.zoning

Note that the *config.zoning* commands function in a different way from most CLI commands, which are single action commands that take effect immediately. A zoning configuration is typically too complicated to be described by a single command, so the first zoning command entered invokes a work-area editor. The commands take effect on a temporary copy of a zone set in the work area until the temporary copy in the work area is activated to the fabric--or is discarded.

Because not all the verification of the zone set can occur on the temporary copy in the work area, it is possible, however unlikely, that the copy of the zone set encounters no errors until the zone set is activated to the fabric.

NOTE: Port numbers cannot be used for zone members if the interoperability mode for the switch or director is set to Open Fabric 1.0 mode. In this case, you must use port WWNs as zone members.

NOTE: A Sphereon 4300 Switch cannot participate in a fabric unless the Fabric Capable feature is enabled. For more information, see the *McDATA Sphereon 4300 Switch Installation and Service Manual* (620-000171).

Table 2-1 shows the limits for configuring zoning in McDATA fabrics that are supported by switch and director firmware as of 11/14/03. Although EFCM 8.0 or EFCM 8.0b may allow you to configure greater values in the Zoning Library, values in this table have been tested and are supported. For the latest limits, refer to the *Supported Fabrics Configuration Document* located on www.mcdata.com in the Resource Library or contact your customer support representative.

Table 2-1 Supported Zoning Configurations

Product	Intrepid 6064 Intrepid 6140	Sphereon 4700	Sphereon 4400	Sphereon 4500	Sphereon 4300	Sphereon 3x32 Sphereon 3x16	ED-5000
Number of End Ports	1024	1024	1024	1024	1024	1024	1024
Unique Zone Members	4096	4096	4096	4096	4096	4096	1042
Members per Zone	4096	4096	4096	4096	4096	4096	1024
Zones	2048	2048	2048	2048	2048	2048	512

config.zoning.activateZoneSet

Syntax `activateZoneSet`

Purpose This command activates the zone set contained in the work area to the fabric and takes effect immediately.

NOTE: This command takes effect immediately in the fabric.

Parameters This command has no parameters.

Command Example

```
Root> config zoning activateZoneSet
```

NOTE: If the interoperability mode for the switch or director is set to Open Fabric 1.0 mode when the zone is activated, any zone members specified by the port number are ignored.

config.zoning.addPortMem

Syntax `addPortMem "zoneName" domainId portNumber`

Purpose This command adds the domain ID and port number of a zone member to the specified zone in the work area.

NOTE: Port numbers cannot be used for zone members if the interoperability mode for the switch or director is set to Open Fabric 1.0 mode.

NOTE: A product can have a maximum of 4096 zone members in its zones.

NOTE: The ED-5000 supports a maximum of 512 zones.

Parameters This command has the following parameters:

zoneName	Specifies the name of the zone.
domainId	Specifies the domain ID of the member to be added to the zone. Valid values are in the range 1–31.
portNumber	Specifies the port number of the member to be added to the zone. Valid port number values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–31 for the ED-5000 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

Command Example `Root> config zoning addPortMem TheUltimateZone 10 6`

config.zoning.addWwnMem

Syntax `addWwnMem zoneName wwn`

Purpose This command adds a WWN zone member to the specified zone in the work area.

NOTE: A product can have at most 4096 zone members in its zones.

NOTE: The ED-5000 supports a maximum of 512 zones.

Parameters This command has two parameters:

zoneName	Specifies the name of the zone.
wwn	The WWN of the member to be added to the zone. The value of the WWN must be in colon-delimited hexadecimal notation (for example, AA:00:AA:00:AA:00:AA:00).

Command Example
```
Root> config zoning addWwnMem TheUltimateZone
10:00:00:00:C9:22:9B:64
```

config.zoning.addZone

Syntax `addZone zoneName`

Purpose This command adds a new (empty) zone to the zone set in the work area.

NOTE: Changes are not activated on the switch until the *config.zoning.activateZoneSet* command is issued.

NOTE: A zone set can have max of 4096 unique zone member.

NOTE: A switch or director can have maximum of 2048 zones in a zone set, except for the ED-5000, which allows a maximum of 512 zones.

Parameters This command has one parameter:

zoneName	Specifies the name of the new zone. The zoneName must contain 1–64 characters. Valid characters are: ABCDEFGHIJKLMNOPQRSTUVWXYZabcdefghijkl mnopqrstuvwxyz0123456789$-^_ Spaces are not permitted, and the first character must be alphabetical.

Command Example

```
Root> config zoning addZone TheUltimateZone
```

config.zoning.clearZone

Syntax

```
clearZone zoneName
```

Purpose This command clears all zone members for the specified zone in the work area. This command does not change the zone name.

Parameters This command has one parameter:

zoneName	Specifies the name of the zone to be cleared.

Command Example

```
Root> config zoning clearZone TheNotUltimateAtAllZone
```

config.zoning.clearZoneSet

Syntax

```
clearZoneSet
```

Purpose This command clears the zone set contained in the work area, removing all zones, and takes effect immediately. This command does not change the zone set name.

Parameters This command has no parameters.

Command Example

```
Root> config zoning clearZoneSet
```

config.zoning.deactivateZoneSet

Syntax `deactivateZoneSet`

Purpose This command places all attached devices in the default zone and takes effect immediately for the entire fabric. This command clears both the active zone set and the working area. This command takes effect immediately in the fabric.

NOTE: The default zone must be activated independently of this command.

Parameters This command has no parameters.

Command Example

```
Root> config zoning deactiveZoneSet
```

config.zoning.deletePortMem

Syntax `deletePortMem zoneName domainId portNumber`

Purpose This command deletes a domain ID and port number for a zone member in the specified zone in the work area.

Parameters This command has three parameters:

zoneName	Specifies the name of the zone that contains the member to be deleted.
domainId	Specifies the domain ID of the member that has to be deleted from the zone. Valid domain IDs are in the range 1–31.

portNumber	Specifies the port number of the member to be deleted from the zone. Valid port numbers values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–31 for the ED-5000 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

Command Example

```
Root> config zoning deletePortMem TheUltimateZone 10 5
```

config.zoning.deleteWwnMem

Syntax

```
deleteWwnMem zoneName wwn
```

Purpose

This command removes a WWN member from a zone that is in the work area.

Parameters

This command has two parameters:

zoneName	Specifies the name of the zone that contains the member to be deleted.
wwn	Specifies the WWN of the member to be deleted from the zone. The value of the WWN must be in colon-delimited hexadecimal notation (for example, AA:00:AA:00:AA:00:AA:00).

Command Example

```
Root> config zoning deleteWwnMem TheNotSoUltimateZone
10:00:00:00:C9:22:9B:AB
```

config.zoning.deleteZone

Syntax `deleteZone zoneName`

Purpose This command deletes a zone from the zone set in the work area.

NOTE: Changes are not activated on the switch until the *config.zoning.activateZoneSet* command is issued.

Parameters This command has one parameter:

zoneName	Specifies the name of the zone to be deleted.

Command Example

```
Root> config zoning deleteZone TheLeastUltimateZone
```

config.zoning.renameZone

Syntax `renameZone oldZoneName newZoneName`

Purpose This command renames a zone in the work area.

Parameters This command has two parameters:

oldZoneName	Specifies the current zone name of the zone to be renamed.
newZoneName	Specifies the new zone name. The newZoneName must contain 1–64 characters. Valid characters are: ABCDEFGHIJKLMNOPQRSTUVWXYZabcdefghijkl mnopqrstuvwxyz0123456789$-^_ Spaces are not permitted, and the first character must be alphabetical.

Command Example

```
Root> config zoning renameZone TheOldUltimateZone
TheUltimateZone
```

config.zoning.renameZoneSet

Syntax `renameZoneSet zoneSetName`

Purpose This command changes the name of the zone set in the work area.

NOTE: Changes are not activated on the switch until the *config.zoning.activateZoneSet* command is issued.

Parameters This command has one parameter:

zoneSetName	Specifies the new name for the zone set. The zoneSetName must contain 1–64 characters. Valid characters are: ABCDEFGHIJKLMNOPQRSTUVWXYZabcdefghijkl mnopqrstuvwxyz0123456789$-^_ Spaces are not permitted, and the first character must be alphabetical.

Command Example

```
Root> config zoning renameZoneSet TheUltimateZoneSet
```

config.zoning.replaceZoneSet

Syntax `replaceZoneSet`

Purpose This command replaces the work area with the active zone set that is currently loaded on the fabric.

Parameters This command has no parameters.

Command Example

```
Root> config zoning replaceZoneSet
```

config.zoning.setDefZoneState

Syntax `setDefZoneState defaultZoneState`

Purpose This command enables or disables the default zone and takes effect immediately fabric wide.

NOTE: This command takes effect immediately in the fabric.

Parameters This command has one parameter:

defaultZoneState	Specifies whether the default zone is enabled. Valid values are *true* and *false*. Boolean 1 and 0 may be substituted as values.

Command Examples

```
Root> config zoning setDefZoneState false
Root> config zoning setDefZoneState 0
```

config.zoning.showActive

Syntax `showActive`

Purpose This command shows the zoning configuration saved on the fabric.

Parameters This command has no parameters.

Command Example

```
Root> config zoning showActive
```

Output The zoning configuration data is displayed as a table that includes the following properties.

Active ZoneSet	The enabled status, name, and member zones of the zone set.

Output Example The output from the *config.zoning.showActive* command appears as follows:

```
Active Zone Set
Default Zone Enabled:  False
ZoneSet:  TheUltimateZoneSet
    Zone:  TheUltimateZone
           ZoneMember: Domain 10, Port 6
           ZoneMember: Domain 15, Port 2
           ZoneMember: Domain 2, Port 63
           ZoneMember: 10:00:00:00:C9:22:9B:64
           ZoneMember: 10:00:00:00:C9:22:9B:BD
    Zone:  TheNotSoUltimateZone
           ZoneMember: 10:00:00:00:C9:22:9B:AB
           ZoneMember: 10:00:00:00:C9:22:9B:C6
           ZoneMember: 10:00:00:00:C9:22:9B:AB
    Zone:  TheNotUltimateAtAllZone
           ZoneMember: Domain 2, Port 63
```

config.zoning.showPending

Syntax `showPending`

Purpose This command shows the zoning configuration in the work area of the zone set that has not yet been activated.

Parameters This command has no parameters.

Command Example

```
Root> config zoning showPending
```

Output The zoning configuration data is displayed as a table that includes the following properties:

Local ZoneSet	The enabled status, name, and member zones of the zone set.

Output Example The output from the *config.zoning.showPending* command appears as follows:

```
Pending Zone Set
Default Zone Enabled:  False
ZoneSet:  TheNewUltimateZoneSet
    Zone:  TheNewUltimateZone
           ZoneMember: Domain 10, Port 6
           ZoneMember: Domain 15, Port 2
    Zone:  TheNewNotSoUltimateZone
           ZoneMember: 10:00:00:00:C9:22:9B:AB
           ZoneMember: 10:00:00:00:C9:22:9B:C6
           ZoneMember: 10:00:00:00:C9:22:9B:AB
    Zone:  TheNewNotUltimateAtAllZone
          ZoneMember: Domain 2, Port 63
```

maint

The maint branch of the CLI command tree contains commands that relate to maintenance activities. The commands in the maint branch can be used only by the administrator.

Note that the *maint.system.resetConfig* command resets all configuration data and non-volatile settings, including network information, to their default values (factory settings). Management access may be lost until the network information is restored.

maint.port.beacon

Syntax `beacon portNumber beaconState`

Purpose This command enables or disables port beaconing for a port.

Parameters This command has two required parameters:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 4700 0–31 for the Sphereon 3032 and 3232 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140
beaconState	Specifies whether beaconing is enabled. Valid values are *true* and *false*. Boolean 1 and 0 may be substituted as values.

Command Examples

```
Root> maint port beacon 4 false
Root> maint port beacon 4 0
```

maint.port.reset

Syntax `reset portNumber`

Purpose This command resets an individual port without affecting any other ports. However, if a device is attached to the port and the device is online, the reset causes a link reset to occur. If the port is in a failed state (that is, after failing a loopback test), the reset restores the port to an operational state. The reset also clears all statistics counters and disables port beaconing for the specified port.

Parameters This command has one parameter:

portNumber	Specifies the port number to be reset. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

Command Example

```
Root> maint port reset 4
```

maint.system.beacon

Syntax `beacon beaconState`

Purpose This command enables or disables unit beaconing.

Parameters This command has one parameter:

beaconState	Specifies whether unit beaconing is enabled. Valid values are *true* and *false*. Boolean 1 and 0 may be substituted as values.

Command Examples

```
Root> maint system beacon false
Root> maint system beacon 0
```

maint.system.clearSysError

Syntax `clearSysError`

Purpose This command clears the system error light.

Parameters This command has no parameters.

Command Example

```
Root> maint system clearSysError
```

maint.system.ipl

Syntax `ipl`

Purpose This command IPLs the switch.

ATTENTION! Connection to the CLI is lost when this command runs.

Parameters This command has no parameters.

Command Example

```
Root> maint system ipl
```

maint.system.resetConfig

Syntax `resetConfig`

Purpose This command resets all NV-RAM configuration parameters to their default values, including feature keys and IP addresses.

NOTE: This command IPLs the switch. Connection from the CLI to the switch is lost when this command runs.

ATTENTION! This command resets all configuration data and non-volatile settings, including network information, to their default values (factory settings). Management access may be lost until the network information is restored.

The default values are set in the firmware of the director or switch. For information about the default values, refer to the service manual of your director or switch.

Parameters This command has no parameters.

Command Example

```
Root> maint system resetConfig
```

maint.system.setOnlineState

Syntax

```
setOnlineState onlineState
```

Purpose This command sets the switch online or offline.

Parameters This command has one parameter:

onlineState	Specifies whether the switch is online. Valid values are *true* and *false*. Boolean 1 and 0 may be substituted as values.

Command Examples

```
Root> maint system setOnlineState true
```

```
Root> maint system setOnlineState 1
```

perf

The perf branch of the CLI command tree contains commands that relate to performance services. The commands in the perf branch can be used by either the administrator or the operator.

The counters in perf command output are 32-bit values that wrap at 4,294,967,296. To calculate the full value of a counter, multiply 4,294,967,296 by the value in the wrap field, and add the resulting product to the value in the count field. For example, if a TxFrames statistic has a count value of 1842953 and a wrap value of 12, the full value of the counter is:

(4,294,967,296 x 12) + 1842953 = 51,541,450,505.

perf.AFD

The Advanced Fabric Diagnostics (AFD) command on the performance branch enters the AFD configuration branch. All commands under this branch operate on a particular feature of fabric diagnostics.

perf.AFD.HDDReport

Syntax `HDDReport logSetting`

Description This command configures the Hot Device Detection (HDD) logging parameters.

Parameters This command has one parameter:

logSetting	This parameter has the following four values: • *nolog* - disables logging. • *evtlog* - logs all HDD events to the event log. • *evtlogemail* - logs all HDD events to the event log and enables email notification for these events, if email notification is enabled. • *evtlogemailcallhome* - logs all events to the event log and enables email notification and call home notification for these events, if email notification and call home notification are enabled.

Command Example `Root> perf AFD HDDReport evtlog`

perf.AFD.POMReport

Syntax `POMReport logSetting`

Description This command configures the Predictive Optics Monitoring (POM) event reporting configuration.

Parameters This command has one parameter:

logSetting	This parameter has the following values: • *nolog* - disables logging. • *evtlogemail* - logs all POM events to the event log and enables email notification for these events, if email notification is enabled. • *evtlogemailcallhome* - logs all events to the event log and enables email notification and call home notification for these events, if email notification and call home notification are enabled.

Command Example `Root> perf AFD POMReport evtlogemail`

perf.AFD.show

Syntax `show`

Description This command displays all the configured settings under AFD.

Parameters This command has no parameters.

Command Example `Root> perf AFD show`

Output The configured settings are displayed as described in the following table:

HDD Logging	The current HDD logging value.
POM Logging	The current POM logging value.

Output Example

```
Perf.AFD> show
```

```
HDD Report:     No logging
POM Report:     No logging
```

perf.class2

Syntax `class2 portNumber`

Purpose This command displays port Class 2 counters for a single port.

Parameters This command has one parameter:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 43000–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

Command Example

```
Root> perf class2 2
```

Output The port Class 2 counter data is displayed as a table that includes the following statistics, along with a wrap count for each corresponding counter.

Port	The port number.
RxFrames	The number of Fibre Channel Class 2 frames that the port has received.
TxFrames	The number of Fibre Channel Class 2 frames that the port has transmitted.
RxWords	The number of Class 2 4-byte words within frames that the port has received.

TxWords	The number of Class 2 4-byte words within frames that the port has transmitted.
Busied Frms	The number of times the FBSY (Fabric Busy link response) was returned to this port as a result of a Class 2 frame that could not be delivered to the other end of the link. This occurs if either the fabric or the destination port is temporarily busy.
Rjct Frames	The number of times the FRJT (Frame Reject link response) was returned to this port as the result of a Class 2 frame that was rejected by the fabric.

Output Example The output from the *perf.class2* command appears as follows:

```
Port 2
Statistic          Wrap          Count
--------        -------------    ------------
RxFrames        23               2953184
TxFrames        12               1842953
RxWords         65               2953184
TxWords         32               1842953
Busied Frms     0                2953184
Rjct Frames     0                1842953
```

perf.class3

Syntax `class3 portNumber`

Purpose This command displays port Class 3 counters for a single port.

Parameters This command has one parameter:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 45000 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

Command Example

```
Root> perf class3 2
```

Output

The port Class 3 counter data is displayed as a table that includes the following statistics, along with a wrap count for each corresponding counter.

Port	The port number.
RxFrames	The number of Fibre Channel Class 3 frames that the port has received.
TxFrames	The number of Fibre Channel Class 3 frames that the port has transmitted.
RxWords	The number of Class 3 4-byte words within frames that the port has received.
TxWords	The number of Class 3 4-byte words within frames that the port has transmitted.
Disc Frames	The number of Class 3 frames that have been discarded upon receipt by this port. There are no FBSYs (Fabric Busy link response) or FRJTs (Frame Reject link response) generated for Class 3 frames.

Output Example

The output from the *perf.class3* command appears as follows:

```
Port 2
Statistic              Wrap      Count
----------------       --------  --------
RxFrames               3         2953184
TxFrames               2         1842953
RxWords                65        2953184
TxWords                32        1842953
Disc Frames            26        2953184
```

perf.clearStats

Syntax

```
clearStats portNumber
```

Purpose

This command resets all port statistics for an individual port or for all ports.

Parameters This command has one parameter:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140 *all* for every port on the director or switch

Command Example

```
Root> perf clearStats 4
Root> perf clearStats all
```

perf.errors

Syntax

```
errors portNumber
```

Purpose This command displays port error counters for a single port.

Parameters This command has one parameter:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

Command Example

```
Root> perf errors 2
```

Output

The port error counter data is displayed as a table that includes the following statistics:

Port	The port number.
Prim Seq Err	The number of state machine protocol errors detected by the port hardware.
Disc Frms	The number of received frames discarded due to a frame size of less than size words or to frames dropped because the BB_Credit was zero. This number is counted during the first round of frame verification and applies to both Class 2 and Class 3 traffic.
Inv Tx Wrds	The number of 10-bit transmission words that the port is unable to map to 8-bit bytes because of disparity errors or misaligned K characters while in the OL2 or OL3 state.
CRC Errors	The number of frame CRC errors detected by the port.
Delim Errs	The number of invalid frame delimiters (SOF or EOF) received by the port.
Addr Id Errs	The number of frames received with unknown addressing.
FrmsTooShrt	The number of frames received that are too short.

Output Example

The output from the *perf.errors* command appears as follows:

```
Port 2
StatisticCount
---------------------
Prim Seq Err753452
Disc Frms351269
Inv Tx Wrds2953184
CRC Errs1842953
Delim Errs2953184
Addr Id Errs1842953
FrmsTooShrt40059
```

perf.link

Syntax

```
link portNumber
```

Purpose This command displays port link counters for a single port.

Parameters This command has one parameter:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

Command Example

```
Root> perf link 2
```

Output The port link counter data is displayed as a table that includes the following statistics:

Port	The port number.
OLS In	The number of offline sequences initiated by the attached N_Port.
OLS Out	The number of offline sequences initiated by this switch or director port.
Reset In	The number of link resets initiated by the attached N_Port.
Reset Out	The number of link resets initiated by this switch or director.
LIPS In	The number of Loop Initialization Primitives (LIPs) detected on this switch loop port.
LIPS Out	The number of LIPs generated on this switch loop port.
Link Flrs	The number of times the port has detected a link error resulting from an invalid link state transition or timeout.

Sync Losses	The number of times the port has detected a loss of synchronization timeout while not in an offline or LF2 state.
Sig Losses	The number of times the port has detected a loss of signal while not in an offline or LF2 state.
Time at 0 Tx Credit	The number of 100 millisecond intervals where the switch port has zero Tx BB_Credit.

Output Example The output from the *perf.link* command appears as follows:

```
Port 2
Statistic              Count
-----------            ----------
OLS In                 753452
OLS Out                351269
Reset In               2953184
Reset Out              1842953
Link Flrs              2953184
Sync Losses            1842953
Sig Losses             35246
Time at 0 Tx Credit    0
```

perf.openTrunking.backPressure

Syntax `backPressure backPressureState`

Purpose This command configures the Back Pressure state of the OpenTrunking configuration.

Parameters This command has one parameter:

backPressureState	This parameter can be set to *enable* or *disable* OpenTrunking back pressure. Boolean 1 and 0 values may also be substituted. If the state is configured to be enabled, a back pressure entry is made to the Event Log and an SNMP trap is generated if SNMP is configured.

Command Example

```
Root> perf openTrunking backPressure 1
```

perf.openTrunking.congestionThresh

Syntax `congestionThresh portNumber congestionThreshold`

Purpose This command configures the congestion threshold for an individual port or for all ports.

Parameters This command has the following parameters:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140 *all* applies the congestionThreshold value to every port on the product.
congestionThreshold	Specifies the congestion threshold in terms of a percentage. Valid values are integers in the range 1 to 99 or *default*. Specifying the value *default* sets the specified port to the default threshold level of 10.

Command Example

```
Root> perf openTrunking congestionThresh 8 20
```

perf.openTrunking.lowBBCreditThresh

Syntax `lowBBCreditThresh lowBBcreditThreshold`

Purpose This command configures the low BB_credit threshold of the OpenTrunking configuration. The low BB_credit threshold is defined as the percentage of time that no transmit BB_Credits are passed on the link. When the threshold value is exceeded, the system tries to reroute the flows that are going to the ISL with the problem.

Effectively, the threshold is the percent of the time that the port does not receive BB_Credits before traffic is rerouted away from the port.

This threshold is also used for prevention of improperly rerouting to an ISL that lacks BB_Credits. In other words, the system does not reroute a flow to a link that lacks BB_Credits even if that link is significantly under its loading threshold. The system tries to reroute traffic away from a link that lacks BB_Credits, even if the loading threshold is significantly below the limit.

Parameters This command has one parameter:

lowBBcreditThreshold	Specifies the low BB_credit threshold in terms of a percentage. Valid values are integers in the range 1 to 99 or *default*. Specifying the value *default* sets the parameter to the default threshold level of 10%.

Command Example

```
Root> perf openTrunking lowBBCreditThresh 20
```

perf.openTrunking.setState

Syntax

```
setState openTrunkingState
```

Purpose This command enables or disables OpenTrunking feature. The OpenTrunking feature key must be installed in order to enable open trunking.

Parameters This command has one parameter:

openTrunkingState	This parameter can be set to *enable* or *disable* the OpenTrunking feature. Boolean 1 and 0 may be substituted as values.

Command Example

```
Root> perf opentrunking setState 1
```

NOTE: The command *config.features.openTrunking* on page 2-12 has functionality that is identical to this command.

perf.openTrunking.show

Syntax `show portNumber`

Purpose This command displays the current OpenTrunking configuration per port.

Parameters This command has one parameter:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 4700 0–31 for the Sphereon 3032 and 3232 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

Command Example

```
Root> perf openTrunking show 11
```

Output The OpenTrunking configuration data is displayed as a table that includes the following statistics:

Congestion Threshold	The threshold is listed as a percentage. If the value is a default value, `(default)` is displayed next to the percentage.
Flows Rerouted To	Trunking statistic displaying flows rerouted to the specified port. (These statistics are cleared by the *perf.clearStats* command.)
Flows Rerouted From	Trunking statistic displaying flows rerouted from the specified port. (These statistics are cleared by the *perf.clearStats* command.)

Unresolved Congestion	The current enabled/disabled state of the unresolved congestion trunking feature. (The indicated state applies to every port on the product.)
Backpressure	The current enabled/disabled state of the backpressure trunking feature. (The indicated state applies to every port on the product.)
Low BB_Credit Threshold	The current threshold setting of the Low BB_Credit Threshold trunking feature. If the value is a default value, (default) is displayed next to the percentage. (The indicated value applies to every port on the product.)

Output Example The output from the *perf.openTrunking.show* command appears as follows:

```
Port Number:                        1
Congestion Threshold (%):           56
Flows Rerouted To:                  26739
Flows Rerouted From:                23987
Unresolved Congestion:              Enabled
Backpressure:                       Disabled
Low BB_Credit Threshold (%):        75 (default)
```

perf.openTrunking.unresCongestion

Syntax `unresCongestion unresolvedCongestionState`

Purpose This command configures the Unresolved Congestion state of the OpenTrunking configuration. If the state is configured to be enabled, an unresolved congestion entry is made to the Event Log and an SNMP trap is generated if SNMP is configured.

Parameters This command has one parameter:

unresolvedCongestionState	This parameter can be set to *enable* or *disable* the Unresolved Congestion state of the OpenTrunking configuration. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> perf openTrunking unresCongestion 1
```

perf.preferredPath

The *perf.preferredPath* commands enable you to use the preferred path feature to influence the route of data traffic that traverses multiple switches or directors in a fabric. If more than one ISL connects switches in your SAN, this feature is useful for specifying an ISL preference for a particular flow.

The preferred path feature allows the user to enhance the path selection algorithm of the switch by providing the ability to prioritize ISLs for a selected port on the switch. The preferred path capability customizes the static load-balancing function by allowing the user to specify an ISL preference for each remote domain. preferred path, however, is still subject to the standard Fabric Shortest Path First (FSPF) requirements, which allow the firmware to override the configuration setting if errors are encountered.

The data path consists of the source port of the switch or director being configured, the exit port of that switch or director, and the domain ID of the destination switch or director. Each switch or director must be configured for its part of the desired path in order to achieve optimal performance.

You may need to configure preferred paths for all switches or directors along the desired path for a proper multi-hop preferred path. (For examples of preferred path implementation and other related information, see the Element Manager manual your switch or product.)

The following rules apply when configuring preferred paths:

- The domain ID of the switch must be set to insistent.
- Domain IDs must be in the range of 1 -31.
- The specified numbers for source ports and exit ports must be in the range equal to the number of ports for the switch being configured.
- For any source port, only one path may be defined to each destination domain ID.

perf.preferredPath.clearPath

Syntax `clearPath destDomainID sourcePort`

Purpose This command deletes a preferred path. The command causes the specified path to use a path selection algorithm that is different from the preferred path. All configured paths can be removed by specifying the *all* parameter for both the destination domain ID and source port.

Parameters This command has the following parameters:

destDomainId	Specifies the destination domain ID. Valid domain IDs are in the range 1–31 or *all*, which deletes all preferred paths to and from the source port specified in the sourcePort parameter.
sourcePort	Specifies the number of the source port. Valid port numbers values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the ED-5000 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140 Or you can specify *all* to delete all paths to the destination domain ID.

Command Example

```
Root> perf preferredPath clearPath 10 5
```

perf.preferredPath.setPath

Syntax `setPath destDomainID sourcePort exitPort`

Purpose This command sets a preferred exit port, given the destination domain ID and source port. An exit port can be set for each combination of destination domain ID and source port.

NOTE: You cannot set a path where the Destination Domain ID is the same as the domain ID of the switch.

Parameters This command has the following parameters:

destDomainId	Specifies the destination domain ID. Valid domain IDs are in the range 1–31.
sourcePort	Specifies the number of the source port. Valid port number values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 45000–31 for the Sphereon 3032 and 3232 0–31 for the ED-5000 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

exitPort	Specifies the number of the desired exit port. Valid port numbers values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the ED-5000 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

Command Example `Root> perf preferredPath setPath 17 5 11`

perf.preferredPath.setState

Syntax `setState enabledState`

Purpose This command enables or disables the preferred path feature.

NOTE: Insistent domain IDs must be used in order to enable the preferred path state.

Parameters This command has one parameter:

enabledState	Sets the state of the preferred path feature. When disabled, the preferred path settings are ignored for all path selection decisions. Accepted values for this command are *enable* and *disable*. Boolean 1 and 0 may be substituted as values.

Command Example `Root> perf preferredPath setState enable`

perf.preferredPath.showPath

Syntax `showPath destDomainID sourcePort`

Purpose This command displays the requested preferred path configuration. The output shows the configured preferred exit port. Using *all* for either the destination domain ID or the specified source port parameter results in an output that shows all configured and actual exit ports for the other parameter. If the destination domain is set to *all*, then all paths from the specified source port are displayed. If the source port is set to *all*, the output shows all source port paths to the specified domain. You cannot specify *all* for both the parameters.

Parameters This command has the following parameters:

destDomainId	Specifies the destination domain ID. Valid domain IDs are in the range 1–31 or *all*, which shows all paths to and from the source port specified in the sourcePort parameter.
sourcePort	Specifies the number of the source port. Valid port numbers values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the ED-5000 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140 Or, you can specify *all* to show all paths to the destination domain ID specified for the destDomainId parameter.

Output

The output from the *perf.preferredPath.showPath* command includes the following parameters:

Destination Domain	The destination domain ID for which a preferred path has been configured. This is displayed only if the destination domain parameter is set to *all*.
Source Port	This is the source port for which a preferred path to the specified destination domain ID is specified. This is displayed only if the source port parameter is set to *all*.
Preferred Exit Port	The configured preferred path exit port. This value can be any port number, or blank to indicate that no preferred path has been configured.

Command and Output Examples

The following examples show the output returned by the three methods of specifying the *perf.preferredPath.showPath* command.

Single values for both parameters

```
Root> perf preferredPath showPath 21 10
Preferred Path State: Enabled
Preferred Exit Port:  Not Configured
```

destDomainId set to all

```
Root> perf preferredPath showPath all 15
Preferred Path State: Enabled
Destination Domain  Preferred Exit Port
------------------  -------------------
1                   23
3                   24
4                   23
17                  12
```

sourcePort set to all

```
Root> perf preferredPath showPath 1 all
Preferred Path State: Enabled
Source Port         Preferred Exit Port
------------------  -------------------
0                   2
2                   5
3                   17
22                  5
```

perf.preferredPath.showState

Syntax `showState`

Purpose This command shows the enabled state for preferred path

Parameters This command has no parameters.

Command Example

```
Root> Perf PreferredPath showState
```

perf.thresholdAlerts

The *perf.thresholdAlerts* commands enable you to configure alerts that notify you of specific conditions on your system.

You can configure a maximum of 16 threshold alerts, including both counter threshold alerts (CTAs) and throughput threshold alerts (TTAs). Each of these types of alerts have commands that are specific to the alert type.

- *Counter threshold alerts:* These are alerts that are triggered by counts of events. The commands used to configure these alerts start with *perf.thresholdAlerts.counter*.
- *Throughput threshold alerts:* These alerts are triggered by port throughput. The commands used to configure these alerts start with *perf.thresholdAlerts.throughput*.

For a list of the available threshold alerts counters, see *Alert Types and Counters* on page 2-159.

Creating Threshold Alerts

The tasks you need to complete to create and activate a threshold alert differ depending on the type of alert you are creating. To implement a counter threshold alert, see *Activating a Counter Threshold Alert* below. To implement a throughput alert, see *Activating a Throughput Threshold Alert* on page 2-158.

Activating a Counter Threshold Alert

In order to activate a counter threshold alert using the CLI, you must enter certain commands in the order specified in this section.

1. Create a counter threshold alert using the command *perf.thresholdAlerts.counter.addAlert* on page 2-161. Use this command to create a name for the threshold alert that you can use in subsequent commands. The threshold alert must then be configured using the other counter threshold alert commands.
2. Assign the threshold alert to a port using the command *perf.thresholdAlerts.counter.addPort* on page 2-162.
3. Configure the threshold alert using other *perf.thresholdalert* commands. For example, you may want to associate the threshold alert counter with the threshold alert name using the *perf.thresholdAlerts.counter.setCounter* command, described on page 2-164. Use the following commands to view alert settings and configure an alert:
   - *perf.thresholdAlerts.counter.removePort* on page 2-163
   - *perf.thresholdAlerts.counter.setCounter* on page 2-164
   - *perf.thresholdAlerts.counter.setParams* on page 2-165
   - *perf.thresholdAlerts.counter.show* on page 2-166
   - *perf.thresholdAlerts.counter.showStatisticTable* on page 2-166
4. Once the alert is fully configured, activate the alert using the *perf.thresholdAlerts.setState* command described on 2-168. To modify an alert you will need to disable it first.

Activating a Throughput Threshold Alert

In order to activate a throughput threshold alert using the CLI, you must enter certain commands in the specified sequence:

1. Create a throughput threshold alert using the command *perf.thresholdAlerts.throughput.addAlert* on page 2-170. Use this command to create a name for the threshold alert that you can use in subsequent commands. The threshold alert must then be configured using the other throughput threshold alert commands.
2. Assign the threshold alert to a port using the command *perf.thresholdAlerts.throughput.addPort* on page 2-171.
3. Identify the throughput statistic that triggers the throughput threshold alert using the command *perf.thresholdAlerts.throughput.setUtilType* on page 2-173.

4. Identify the percentage of throughput that triggers the throughput threshold alert using the command *perf.thresholdAlerts.throughput.setUtilPercentage* on page 2-174.
5. Configure the threshold alert using other perf.thresholdalert commands. For example, you may want to set the duration and interval times for the alert, as described in *perf.thresholdAlerts.throughput.setParams* on page 2-175. Use the following commands to view alert settings and configure an alert:
   - *perf.thresholdAlerts.throughput.removePort* on page 2-172
   - *perf.thresholdAlerts.throughput.setParams* on page 2-175
   - *perf.thresholdAlerts.throughput.show* on page 2-175
   - *perf.thresholdAlerts.throughput.showUtilTypeTable* on page 2-176
6. Once the alert is fully configured, it can be activated using the *perf.thresholdAlerts.setState* command, described on 2-168. You will need to disable an alert before you can modify it.

Alert Types and Counters

Table 2-2 provides a list of throughput threshold alerts.

Table 2-2 Throughput Threshold Alerts

Utilization Code	Threshold Alert Type
Tx Util	TTA - Transmit Utilization
Rx Util	TTA - Receive Utilization
Tx/Rx Util	TTA - Transmit or Receive Utilization

Table 2-3 provides a list of threshold alert counters and counter sets.

Table 2-3 Alert Counters

Number	Threshold Alert Counter or Counter Set
1	Link Resets Sent
2	Link Resets Received
3	OLS Sent
4	OLS Received

Table 2-3 Alert Counters (Continued)

Number	Threshold Alert Counter or Counter Set
5	Link Failures
6	Sync Losses
7	Signal Losses
8	Protocol Errors
9	Invalid Tx Words
10	CRC Errors
11	Discarded Frames
12	Frames Too Short
13	Delimiter Errors
14	Address ID Errors
15	Class2BusiedFrames
16	Class2RejectedFrames
17	Class3DiscardedFrames
18	Physical Link Errors Set
19	Link Sequence Counts Set
20	Logical Link Errors Set (see below)
21	LIPs Detected (Sphereon 4300 and Sphereon 4500 switches only)
22	LIPs Generated (Sphereon 4300 and Sphereon 4500 switches only)

Description of Summed Sets

Some of the threshold alerts consist of groups of related items called *Summed Sets*. When any of the items in the summed set are encountered, the total value of the summed set counter is incremented. The items that make up the summed sets are:

- **Physical Link Errors Summed Set**
  - Link Failures
  - Sync Losses

- Signal Losses
- Protocol Errors
- Invalid Tx Words
- CRC Errors
- Frames Too Short
- Delimiter Errors

- **Link Sequence Counts Summed Set**
  - Link Resets Received
  - Link Reset Sent
  - OLS Received
  - OLS Sent

- **Logical Link Errors Summed Set**
  - Discarded Frames
  - Address ID Errors
  - Class 2 Busied Frames
  - Class 2 Rejected Frames
  - Class 3 Discarded Frames

perf.thresholdAlerts.counter.addAlert

Syntax `addAlert name`

Purpose This command configures a new counter threshold alert and assigns it a name. The new alert is assigned default settings which can then be changed using the other counter threshold alert commands.

The default settings for a new counter threshold alert are as follows:

- Ports: None
- Counter: None
- Increment: 100
- Interval: 60 minutes
- State: Disabled

Parameters This command has one parameter:

name	Specifies the name of the new counter threshold alert. This name can consist of any ASCII characters up to a maximum length of 64 characters. To use spaces or special characters in this name, put quotation marks around the name. This parameter is case-sensitive.

TIP: Although the system supports a name length of 64 characters, you may want to use a much shorter name. Some commands that display the threshold name show a maximum of 51 characters. If you specify lengthy names, you can display the complete name by entering the comma-delimited mode using the commaDelim command. For more information, see *Using the commaDelim Command* on page 1-19.

Command Example

```
Root> perf thresholdAlerts counter addAlert checklinks
```

perf.thresholdAlerts.counter.addPort

Syntax

```
addPort name portNumber
```

Purpose This command adds a port to the specified counter threshold alert.

NOTE: An alert cannot be modified unless it is in the disabled state. Verify that the alert is disabled before executing this command.

Parameters This command has the following parameters:

name	The name of a counter threshold alert as defined by the command *perf.thresholdAlerts.counter.addAlert* on page 2-161.

portNumber	Specifies the port number or port type. Valid port number values: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140 *all* applies the counter threshold alert to every port on the product.

Specifying a port type removes all the ports from the alert and applies the alert to each port that is the specified type of port. Valid values are:

- *eport*
- *fport*
- *flport* (Sphereon 4300 and Sphereon 4500 only)

NOTE: A counter threshold alert is not allowed to specify both port types and individual port numbers.

Command Example

```
Root> perf thresholdAlerts counter addPort checklinks 12
```

perf.thresholdAlerts.counter.removePort

Syntax

```
removePort name portNumber
```

Purpose

This command removes a port from the specified counter threshold alert.

NOTE: An alert cannot be modified unless it is in the disabled state. Verify that the alert is disabled before executing this command.

Parameters This command has the following parameters:

name	The name of a counter threshold alert as defined by the command *perf.thresholdAlerts.counter.addAlert*, described on 2-161.
portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140 *all* removes every port on the product from the counter threshold alert.

Command Example

```
Root> perf thresholdAlerts counter removePort checklinks 12
```

perf.thresholdAlerts.counter.setCounter

Syntax

```
setCounter name counterNumber
```

Purpose This command sets the counter statistic that will be used to trigger the counter threshold alert. Use this command to associate a counter with the threshold alert name created using the *perf.thresholdAlerts.counter.addAlert* command.

NOTE: An alert cannot be modified unless it is in the disabled state. Verify that the alert is disabled before executing this command.

Parameters This command has the following parameters:

name	The name of a counter threshold alert as defined by the command *perf.thresholdAlerts.counter.addAlert*, described in 2-161.
counterNumber	Specifies the counter number. Valid values are shown in Table 2-3, *Alert Counters*, page 2-159.

Command Example

```
Root> perf thresholdAlerts counter setCounter checklinks 1
```

perf.thresholdAlerts.counter.setParams

Syntax

```
setParams name increment interval
```

Purpose This command sets the increment and interval times for a specified counter threshold alert.

NOTE: An alert cannot be modified unless it is in the disabled state. Verify that the alert is disabled before executing this command.

Parameters This command has the following parameters:

name	The name of a counter threshold alert as defined by the command *perf.thresholdAlerts.counter.addAlert*, described on 2-161.
increment	This sets the number of times a counter must increment during the interval period to trigger the alert. Acceptable values are in the range of 1 to 70,560.
interval	This sets the interval time in minutes for the alert. Acceptable values are in the range of 5 to 70,560 minutes.

Example If ports 0,1, or 2 CRC Error counter increments more then 5 times within a period of 30 minutes, send an alert.

```
Port list = 0, 1, 2
CTA Counter = CRCErrors
Increment value= 5
Interval Time = 30
```

The increment value takes place in an interval that is a fixed length amount of time. This interval is not a rolling window interval.

Command Example

```
Root> perf thresholdAlerts counter setParams checklinks 5 30
```

perf.thresholdAlerts.counter.show

Syntax

```
show name
```

Purpose

This command displays the settings for an individual counter threshold alert.

Parameters

This command has one parameter:

name	The name of a threshold alert as defined by the command *perf.thresholdAlerts.counter.addAlert*, described on 2-161. You can specify *all* instead of a name, which means that all threshold alerts are displayed.

NOTE: The output of this command truncates threshold alert names that are longer than 51 characters. If you specify lengthy names, you can display the complete name by entering the comma-delimited mode using the *commaDelim* command. For more information, see *Using the commaDelim Command* on page 1-19.

Command Example

```
Root> perf thresholdAlerts counter show checklinks
```

Output Example

The output from the *perf.thresholdAlerts.counter.show* command appears as follows:

```
Index:              3
Name:               Example_CRC_Error_Finder
Ports:              2,4-7,20-24
Counter Statistic:  CRC Errors
Increment:          5
Interval:           30
Alert State:        Disabled
```

perf.thresholdAlerts.counter.showStatisticTable

Syntax

```
showStatisticTable
```

Purpose

This command displays the table of different statistic counters that can be added to a counter threshold alert. This table is used for reference only.

Parameters

This command has no parameters.

Command Example

```
Root> perf threshAlerts counter showStatisticTable
```

Output Example

The output from the *perf.thresholdAlerts.counter.showStatisticTable* command appears as follows:

```
NumberCounter or Counter Set
----------------------------
1  Link Resets Sent
2  Link Resets Received
3  OLS Sent
4  OLS Received
5  Link Failures
6  Sync Losses
7  Signal Losses
8  Protocol Errors
9  Invalid Tx Words
10 CRC Errors
11 Discarded Frames
12 Frames Too Short
13 Delimiter Errors
14 Address ID Errors
15 Cls2 BusiedFrms
16 Cls2 RejectedFrms
17 Cls3 DiscardFrms
18 Phys Lnk Err Set
19 Lnk Seq Cnt Set
20 Logic Lnk Err Set
21 LIPS Detected
22 LIPS Generated
```

perf.thresholdAlerts.deleteAlert

Syntax `deleteAlert name`

Purpose This command deletes a specified threshold alert.

NOTE: An alert cannot be modified unless it is in the disabled state. Verify that the alert is disabled before executing this command.

Parameters This command has one parameter:

name	The name of a threshold alert as defined by the commands *perf.thresholdAlerts.counter.addAlert* and *perf.thresholdAlerts.throughput.addAlert*, or, enter *all* to delete all of the configured threshold alerts.

Command Example

```
Root> perf thresholdAlerts deleteAlert checklinks
```

perf.thresholdAlerts.setState

Syntax `setState name enabledState`

Purpose This command enables or disables specified threshold alert.

Parameters This command has the following parameters:

name	The name of a threshold alert as defined by the commands *perf.thresholdAlerts.counter.addAlert* and *perf.thresholdAlerts.throughput.addAlert*.
enabledState	Sets the counter threshold alert enabled state. Valid values are *enable* and *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> perf thresholdAlerts setState checklinks enabled
```

perf.thresholdAlerts.show

Syntax `show`

Purpose This command displays information about all threshold alerts.

Parameters This command has no parameters.

Command Example

```
Root> perf thresholdAlerts show
```

Output The data is displayed as a table that includes the following properties:

Name	The name of the threshold alert (truncated to 51 characters).	
Type	The trigger statistic or threshold type of the alert (abbreviated to 17 chars).	
	Tx Util	TTA - Transmit Utilization
	Rx Util	TTA - Receive Utilization
	Tx/Rx Util	TTA - Transmit or Receive Utilization
	Link Resets Sent	CTA - Link Resets Sent
	Link Resets Received	CTA - Link Resets Received
	OLS Sent	CTA - OLS Sent
	OLS Received	CTA - OLS Received
	Link Failures	CTA - Link Failures
	Sync Losses	CTA - Sync Losses
	Signal Losses	CTA - Signal Losses
	Protocol Errors	CTA - Primitive Sequence Errors/Protocol Errors
	Invalid Tx Words	CTA - Invalid Tx Words
	CRC Errors	CTA - CRC Errors
	Discarded Frames	CTA - Discarded Frames
	Frames Too Short	CTA - Frames Too Short
	Delimiter Errors	CTA - Delimiter Errors
	Address ID Errors	CTA - Address ID Errors
	Cls2 BusiedFrms	CTA - Class 2 Busied Frames
	Cls2 RejectedFrms	CTA - Class 2 Rejected Frames

	Cls3 DiscardFrms	CTA - Class 3 Discarded Frames
	Phys Lnk Err Set	CTA - Physical Link Errors Summed Set
	Lnk Seq Cnt Set	CTA - Link Sequence Counts Summed Set
	Logic Lnk Err Set	CTA - Logical Link Errors Summed Set
	LIPs Detected	CTA - Loop Initialization Primitive Detected
	LIPs Generated	CTA - Loop Initialization Primitive Generated
State		The enabled state of the CTA. Either enabled or disabled.

Output Example

```
Name                                                Type                State
--------------------------------------------------- ------------------  --------
Throughput Threshold #1                             Rx Util             Enable
Threshold for CRC                                   CRC Errors          Disabled
Safety #2                                           Logic Lnk Err Set   Enabled
Safety #1                                           Cls2 BusiedFrms     Disabled
```

perf.thresholdAlerts.throughput.addAlert

Syntax `addAlert name`

Purpose This command configures a new throughput threshold alert and assigns it a name. The new alert is assigned default settings that can then be changed using the other throughput threshold alert commands.

The default settings for a new counter threshold alert are as follows:

- Ports: None
- Utilization Type: None
- Utilization Percentage: 50%
- Duration: 30 minutes
- Interval: 60 minutes

- Alert State: Disabled

Parameters This command has one parameter:

name	Specifies the name of the new throughput threshold alert. This name can consist of any ASCII characters up to a maximum length of 64 characters. To use spaces or special characters in this name, put quotation marks around the name. This parameter is case-sensitive.

TIP: Although the system supports a name length of 64 characters, you may want to use a much shorter name. Some commands that display the threshold name show a maximum of 51 characters. If you specify lengthy names, you can display the complete name by entering the comma-delimited mode using the commaDelim command. For more information, see *Using the commaDelim Command* on page 1-19.

Command Example

```
Root> perf thresholdAlerts throughput addAlert port6Rx
```

perf.thresholdAlerts.throughput.addPort

Syntax

```
addPort name portNumber
```

Purpose This command adds a port to the specified throughput threshold alert.

NOTE: An alert cannot be modified unless it is in the disabled state. Verify that the alert is disabled before executing this command.

Parameters This command has the following parameters:

name	The name of a throughput threshold alert as defined by the command *perf.thresholdAlerts.throughput.addAlert*, described on 2-170.

portNumber	Specifies the port number or port type. Valid values are either a single port number, all ports, or port type. The following port numbers are valid: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 4700 0–31 for the Sphereon 3032 and 3232 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140 *all* applies the throughput threshold alert to every port on the product.

Specifying a *port type* removes the alert from all ports and applies the alert to all ports of the specified type. Valid values are:

- *eport*
- *fport*
- *flport* (Sphereon 4300 and Sphereon 4500 only)

NOTE: This parameter cannot specify both individual port numbers and a port type.

Command Example

```
Root> perf thresholdAlerts throughput addPort eportRx eport
```

perf.thresholdAlerts.throughput.removePort

Syntax

```
removePort name portNumber
```

Purpose

This command removes a port from the specified throughput threshold alert.

NOTE: An alert cannot be modified unless it is in the disabled state. Verify that the alert is disabled before executing this command.

Parameters This command has the following parameters:

name	The name of a throughput threshold alert as defined by the command *perf.thresholdAlerts.throughput.addAlert*, described on 2-170.
portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 4700 0–31 for the Sphereon 3032 and 3232 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140 *all* removes the throughput threshold alert from every port on the product.

Command Example

```
Root> perf thresholdAlerts throughput removePort eportRx all
```

perf.thresholdAlerts.throughput.setUtilType

Syntax

```
setUtilType name utilizationType
```

Purpose This command sets the throughput statistic that is used to trigger the throughput threshold alert.

NOTE: An alert cannot be modified unless it is in the disabled state. Verify that the alert is disabled before executing this command.

Parameters This command has the following parameters:

name	The name of a throughput threshold alert as defined by the command *perf.thresholdAlerts.throughput.addAlert*, described on 2-170.
utilizationType	The type of traffic that triggers the alert. Enter the number that corresponds to the desired utilization type: 1 - Transmit Traffic (Tx) 2 - Receive Traffic (Rx) 3 - Both (Rx and Tx)

Command Example

```
Root> perf thresholdAlerts throughput setUtilType
eportRx 1
```

perf.thresholdAlerts.throughput.setUtilPercentage

Syntax

```
setUtilPercentage name utilizationPercentage
```

Purpose This command sets the throughput utilization percentage that is used to trigger the throughput threshold alert.

NOTE: An alert cannot be modified unless it is in the disabled state. Verify that the alert is disabled before executing this command.

Parameters This command has the following parameters:

name	The name of a throughput threshold alert as defined by the command *perf.thresholdAlerts.throughput.addAlert*, described on 2-170.
utilizationPercentage	The percentage of throughput utilization that triggers the alert. This must be entered as a number. Accepted values are in the range 1 to 100.

Command Example

```
Root> perf thresholdAlerts throughput setUtilPercentage
eportRx 70
```

perf.thresholdAlerts.throughput.setParams

Syntax `setParams name duration interval`

Purpose This command sets the name, duration, and interval for a specified throughput threshold alert. It also enables you to configure an alert to be sent when the following two events occur at the same time.

- The throughput threshold alert value is surpassed to more than the timespan specified in the duration parameter.
- The duration parameter is surpassed within the time frame specified by the interval parameter.

Parameters This command has the following parameters:

name	The name of a throughput threshold alert as defined by the command *perf.thresholdAlerts.throughput.addAlert*, described on 2-170.
duration	The duration time in minutes that the utilization must exist to trigger the alert. Acceptable values are in the range 0 to 70,560 minutes. Setting this value to zero means that the alert is triggered if the specified utilization is exceeded at any time. The value of this parameter must be less than or equal to the value of the interval parameter.
interval	This sets the interval time in minutes. The interval is a fixed length of time. It is not a rolling window of time. Acceptable values are in the range 5 to 70,560 minutes. The value of this parameter must be greater than or equal to the value of the duration parameter.

Command Example

```
Root> perf thresholdAlerts throughput SetParams eportRx 1
10
```

perf.thresholdAlerts.throughput.show

Syntax `show name`

Purpose This command displays the settings for an individual throughput threshold alert.

Parameters This command has one parameter:

name	The name of a throughput threshold alert as defined by the command *perf.thresholdAlerts.throughput.addAlert*, described on 2-170. You can also specify *all* instead of a name, to display all threshold alerts.

NOTE: The output of this command truncates all the threshold alert names that are longer than 51 characters. In case you specify lengthy names, you can display the complete name by entering the comma-delimited mode using the commaDelim command. For more information, see *Using the commaDelim Command* on page 1-19.

Command Example

```
Root> perf thresholdAlerts throughput show eportRx
```

Output Example The output from the *perf.thresholdAlerts.throughput.show* command appears as follows:

```
Name:                    90% Receive Throughput Threshold
Ports:                   5,8,12,20-24
Utilization Type:        Rx
Utilization Percentage:  90%
Duration:                15
Interval:                30
Alert State:             Disabled
```

perf.thresholdAlerts.throughput.showUtilTypeTable

Syntax

```
showUtilTypeTable
```

Purpose This command displays a table of the utilization types that can be used for a throughput threshold alert. This table is used for reference only.

Parameters This command has no parameters.

Command Example

```
Root> perf thresholdAlerts throughput showUtilTypeTable
```

Output Example The output from the *perf.thresholdAlerts.throughput.showUtilTypeTable* command appears as follows:

```
NumberUtilization Type
----------------------------
```

```
1  Transmit Traffic (Tx)
2  Receive Traffic (Rx)
3  Both (Tx/Rx)
```

perf.traffic

Syntax `traffic portNumber`

Purpose This command displays port traffic counters for a specified port.

Parameters This command has one parameter:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

Command Example

```
Root> perf traffic 2
```

Output The port traffic counter data is displayed as a table that includes the following statistics, along with a wrap count for each corresponding counter.

Port	The port number.
Rx%	The received link utilization percentage.
Tx%	The transmitted link utilization percentage.
RxFrames	The number of Fibre Channel Class 2 and Class 3 frames that the port has received.

TxFrames	The number of Fibre Channel Class 2 and Class 3 frames that the port has transmitted.
RxWords	The number of 4-byte words in Class 2 and Class 3 frames that the port has received.
TxWords	The number of 4-byte words in Class 2 and Class 3 frames that the port has transmitted.

Output Example

The output from the *perf.traffic* command appears as follows:

```
Port 2
Statistic           Wrap          Count
-----------         ----------    ----------
Rx%                 N/A           75
Tx%                 N/A           30
RxFrames            23            2953184
TxFrames            12            1842953
RxWords             65            2953184
TxWords             32            1842953
```

show

The *show* branch of the CLI command tree contains commands that display, but do not change, stored data values. The displayed output that results from these commands is not necessarily identical with the output from the show commands that are within the other CLI command tree branches, for example, *config.port.show*.

The commands in the show branch can by used by either the administrator or the operator.

show.activeAlias

Synopsis `activeAlias`

Description This command displays the active WWN aliases.

Parameters This command has no parameters.

Command Example

```
Root> show activeAlias
```

Output The following attributes are displayed by this command.

CLI Alias enabled state	The CLI enabled/disabled state of WWN aliases.
WEB Alias enabled state	The WEB enabled/disabled state of WWN aliases.
Total associations possible	The total number of possible associations.
Current association count	The number of configured associations.
WWN	The WWNs with configured aliases.
Alias	The Aliases associated with the WWNs.

Output Example

```
show> activeAlias
CLI Alias enabled state:        Disabled
Web Alias enabled state:        Disabled
Total Associations Possible:    250
Current Association Count:      9
WWN                       Alias
-----------------------  ------------------------
```

```
11:22:33:44:55:66:77:01  NAME1
11:22:33:44:55:66:77:02  NAME2
11:22:33:44:55:66:77:03  NAME3
11:22:33:44:55:66:77:04  NAME4
```

show.all

Syntax `all`

Purpose This command displays all configuration and status information that are available. The command results in a sequential display of the output of other CLI *show* commands. This set of show commands returns the full configuration and status of the switch and fabric.

Parameters This command has no parameters.

Command Example

```
Root> show all
```

Output The output of this command is a sequential display of the output of other CLI *show* commands. The commands are displayed in the following order:

- *show.ip.ethernet*
- *show.system*
- *show.switch*
- *show.openSysMS.config*
- *show.port.config*
- *show.frus*
- *config.snmp.show*
- *show.zoning*
- *show.port.state*
- *show.port.info*
- *show.port.technology*
- *show.loginserver*
- *show.features*
- *show.security.portbinding*
- *show.security.switchbinding*

- *show.security.fabricbinding*
- *show.openTrunking.config*
- *show.thresholdAlerts.alerts*
- *show.fabric.topology*
- *show.fabric.nodes*
- *show.security.switchACL*
- *show.ficonCUPZoning*
- *show.fencing.Policies*
- *show.activeAlias*

show.auditLog

Syntax `auditLog [clear]`

Purpose This command displays the entries of the audit log after the last time the log was cleared.

Parameters This command has one optional parameter:

clear	Adding the optional *clear* parameter removes all entries from the log. If the log is full, it will resume collecting log entries.

Command Example `show auditLog`

Output The output from this command displays the following data:

Date/Time	The date and time of the log entry.
Action	Type of audit log event.
Source	Source of audit log event.
User ID	Identifier of the user that made the command. Usually an IP address.

Output Example

```
Date/Time       Action          Source    User Id
```

```
----------      -----------      -------   -------------
11/24/03 04:18P Switch set online   CLI    172.16.22.23
11/24/03 03:38P Switch name modifiedCLI    172.16.22.23
11/24/03 03:38P Switch set offline  CLI    172.16.22.23
11/24/03 11:27A Firmware downloaded Web    172.60.5.40
```

show.epFrameLog.config

Syntax `config`

Purpose This command shows the current embedded port frame log settings.

Parameters This command has no parameters.

Command Example

```
Root> show epFrameLog config
```

Output The output from this command contains the following data:

Filter Class F Frames	If enabled, then filtering of Class F frames will take place.
Filter Port	The port that is being filtered on.
Trigger State	The state of the trigger. Active if the trigger conditions have not been met.
Num of Entries	Number of frames that have been logged since the start condition was met.
Start offset	The number of bytes into the frame to where the start bit pattern will be looked for.
Start Bit Pattern	The bit pattern that triggers the logging to begin.
End Offset	The number of bytes into the frame to where the end bit pattern will be looked for.
End Bit Pattern	The bit pattern that triggers the logging to end.
Start Condition Met	True if the start condition was met.
End Condition Met	False if the end condition was not met.

Command Example

```
Root> show EPFrameLog config

Filter Class F Frames:   Disabled
Filter Port:             15
Start Offset:            0
Start Bit Pattern:       FFXXXXX3452
```

```
End Offset:                0
End Bit Pattern:           FBXXXXX3321
Trigger State:             Active
Num of Entries:            6
Start Condition Met:       True
End Condition Met:         False
```

show.epFrameLog.disableTrigger

Syntax `disableTrigger`

Purpose This command clears the embedded port frame log trigger, which was configured with the command *show.epFrameLog.setTrigger*.

Parameters This command has no parameters.

Command Example

```
Root> show epFrameLog disableTrigger
```

show.epFrameLog.filterClassFFrames

Syntax `filterClassFFrames [enable]`

Purpose This command will turn on or off the ability to filter out Class-F frames, or show its current state. When the filtering is enabled, everything but Class-F frames will be logged. This setting will not be stored in NV RAM and will not persist after IML.

Parameters This command has one optional parameter. If no parameters are entered, it will show the current state.

filterstate	Specifies the on/off state. Valid values are *enable* and *disable*. Boolean 1 and 0 values may also be substituted.

Command Example

```
Root> show epFrameLog filterClassFFrames enable
```

show.epFrameLog.noWrap

Syntax `noWrap [clear]`

Purpose This command displays the contents of the non-wrapping region of the FC2 frame log. Specifying the optional keyword clear removes all entries from the non-wrapping region of the log.

The log entries will not persist over IMLs or power cycles; it will not be stored in NV RAM. This log will not include entries for frames discarded by hardware such as un-routable Class-3 frames, unless Class-3 discard is disabled in the hardware.

NOTE: This log will not wrap. The log will stop collecting entries after is it filled.

Parameters

This command has one optional parameter. If no parameter is specified, then the 500 entries of the log will be displayed.

clear	Adding the optional *clear* parameter removes all entries from the non-wrapping region of the log.

Command Example

```
Root> show epFrameLog noWrap
```

Output

This command displays the following data:

Count	A constantly incrementing counter.
Date/Time	Time of the frame.
Port #	The port number.
Direction	Direction of the frame through the port (I = In, O = Out, D= Discard).
SOF	Start of frame.
EOF	End of frame.
Header	The 24 byte FC frame header.
PL (size in bytes)	The first 32 bytes of the FC frame payload.

Output Example

The output of the show.epFrameLog.nowrap command appears as follows:

```
Count     Date/Time         Port #    Direction SOF    EOF           Payload Size
------    ---------------   ------    --------- ---    --- ------------
39         11/24/03 11:30A  39         O         i3     n      2112
Header: 22000026 000000EF E1000000 00000000 FFFF0000 00000000
PL:     00010203 04050607 08090A0B 0C0D0E0F 10111213 14151617 18191A1B 1C1D1E1F
38         11/24/03 11:30A  38         I         i3     n      2112
Header: 22000026 000000EF E1000000 00000000 FFFF0000 00000000
PL:     00010203 04050607 08090A0B 0C0D0E0F 10111213 14151617 18191A1B 1C1D1E1F
37         11/24/03 11:30A  38         O         i3     n      2112
```

```
Header: 22000025 000000EF E1000000 00000000 FFFF0000 00000000
PL:     00010203 04050607 08090A0B 0C0D0E0F 10111213 14151617 18191A1B 1C1D1E1F
```

show.epFrameLog.removeFilterPort

Synopsis `removeFilterPort portNumber`

Description This command removes a port from FC2 frame logging filter.

Parameters This command has one parameter which can be either "all" or a port number.

portnumber	The port number to specify "all" for disabling FC2 frame log for all the ports or the port number for which frame log entries will be recorded. Valid Port Numbers range from: 0–11 for the Sphereon 4300 0–16 for the Sphereon 3016 and Sphereon 4400 0–24 for the Sphereon 4500 0–32 for the Sphereon 3032 and Sphereon 4700 0–64 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

Command Example

```
Root> show epFrameLog removeFilterPort 10
```

show.epFrameLog.setFilterPort

Syntax `setFilterPort portNumber`

Purpose This command adds a port number to a list of ports that will be filtered for FC2 frame log. This setting is not be stored in NV RAM and does not persist after IML.

Parameters This command has one parameter.

Port Num	The port number to specify "all" for disabling FC2 frame log for all the ports or the port number for which frame log entries will be recorded. Valid Port Numbers range from: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140 [all] The "all" parameter will make the FC2 log collect entries from all of the ports on the switch. [none] The "none" parameter will make the FC2 log stop collecting entries.

Command Example

```
Root> show epFrameLog setFilterPort 63
```

show.epFrameLog.setTrigger

Syntax

```
setTrigger portNumber offStart bitStart offEnd bitEnd
```

Purpose This command sets a logging trigger value for the embedded port frame log.

Parameters This command has five parameters:

portNumber	The port to monitor this trigger on. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 and 3232 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140
offStart	The offset for the start bit pattern.
bitStart	The bit pattern that will trigger the logging. 'X' or 'x' can be used as a wild card.
offEnd	The offset for the end bit pattern.
bitEnd	The bit pattern that will end the logging. 'X' or 'x' can be used as a wild card.

Command Example

```
show.EPFrameLog> setTrigger 5 0 FFXXXXX3452 0 FBXXXXX3321
```

NOTE: Once the trigger conditions have been met, user will have to clear the filter manually. No new entries are written to the frame log until the user initiates it.

show.epFrameLog.wrap

Syntax

```
wrap [clear]
```

Purpose This command displays the contents of the wrapping region of the FC2 frame log. Specifying the optional keyword *clear* clears all entries from both the wrapping and the non-wrapping regions of the log.

The log entries will not persist over IMLs or power cycles, and will not be stored in NV RAM. This log will not include entries for frames

discarded by hardware, such as un-routable class-3 frames unless class-3 discard is disabled in the hardware.

NOTE: This log will begin to wrap after the log is filled.

Parameters

This command has one optional parameter. If no parameter is specified, then the 1000 entries of the log will be displayed.

clear	Adding the optional *clear* parameter removes all entries from both the wrapping and the non-wrapping regions of the log.

Command Example

```
Root> show epFrameLog wrap
```

Output

This command displays the following data:

Count	A constantly incrementing counter.
Date/Time	Time of the frame.
Port #	The port number.
Direction	Direction of the frame through the port (I = In, O = Out, D= Discard).
SOF	Start of frame.
EOF	End of frame.
Header	The 24 byte FC frame header.
PL (size in bytes)	The first 32 bytes of the FC frame payload.

Output Example

The output of the show.epFrameLog.wrap command appears as follows:

```
Count     Date/Time         Port #    Direction SOF    EOF       Payload Size
------    ---------------   ------    --------- ---    ---  ------------
39        11/24/03 11:30A   39        O         i3     n          2112
Header: 22000026 000000EF E1000000 00000000 FFFF0000 00000000
PL:     00010203 04050607 08090A0B 0C0D0E0F 10111213 14151617 18191A1B 1C1D1E1F
38        11/24/03 11:30A   38        I         i3     n          2112
Header: 22000026 000000EF E1000000 00000000 FFFF0000 00000000
PL:     00010203 04050607 08090A0B 0C0D0E0F 10111213 14151617 18191A1B 1C1D1E1F
37        11/24/03 11:30A   38        O         i3     n          2112
Header: 22000025 000000EF E1000000 00000000 FFFF0000 00000000
PL:     00010203 04050607 08090A0B 0C0D0E0F 10111213 14151617 18191A1B 1C1D1E1F
```

show.eventLog

Syntax `eventLog [clear]`

Purpose This command displays the contents of the event log as maintained in NV-RAM on the director or switch.

Parameters This command has one parameter:

clear	This optional parameter causes all event log entries to be cleared.

Command Example

```
Root> show eventLog
```

Output The event log data are displayed as a table that includes the following properties.

Date/Time	The date and time when the event occurred.
Code	The event reason code.
Severity	The severity of the event. The values are: **Major**—Unit operational (major failure). **Minor**—Unit operational (minor failure). **Severe**—Unit not operational. The causes are either that the switch contains no operational SBAR cards or that the system shuts down due to CTP thermal threshold violations. **Info**—Unit operational (information only).
FRU	The FRU and FRU position, where applicable.
Event Data	The 32-byte hexadecimal description of the event in words.

Output Example The output from the *show.eventLog* command appears as follows:

```
Date/Time          Code  Severity  FRU    Event Data
---------------  ----  --------  -----  ------------------------------------
04/12/01  10:58A  375   Major     CTP-0  00010203 04050607 08090A0B 0C0D0E0F
04/12/01   9:58A  385   Severe    CTP-0  00010203 04050607 08090A0B 0C0D0E0F
04/11/01   7:18P  395   Severe    CTP-0  00010203 04050607 08090A0B 0C0D0E0F
```

show.fabricLog.noWrap

Syntax `noWrap [clear]`

Purpose This command displays the contents of the non-wrapping region of the fabric log. The log entries will not persist over IMLs or power cycles; it will not be stored in NV RAM.

NOTE: This log will not wrap. The log will stop collecting entries after is it filled.

Parameters This command has one optional parameter. If no parameter is specified, then the 200 entries of the log will be displayed.

clear	Removes all entries from the log.

Command Example `Root> show fabricLog noWrap`

Output This command displays the following data:

Count	A constantly incrementing counter.
Date/Time	The date and time of the log entry.
Description	A description of the log entry.
Data	Extended data that is associated to the log entry.

Output Example The output of the *show.fabricLog.noWrap* command appears as follows:

```
Count        Date/Time           Description
----------   ---------------     -------------
11           11/24/03 04:18P     Port RSCN
Data: RSCN Reason=2301, Port Offline/Online=26437, Ports 0, 1, 2, 3, 4, 5, 6,
   7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24,
   25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39 40, 41, 42,
   43, 44, 45, 46, 47, 48, 49,50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60,
   61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78,
   79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96,
   97, 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111,
   112, 113, 114, 115, 116, 117, 118, 119, 120, 121, 122, 123, 124, 125,
   126, 127, 132, 133, 134, 135, 136, 137, 138, 139, 140, 141, 142, 143,
144
10           12/04/03 08:15A     Fabric Operational
```

```
Data:
9            12/04/03 08:15A     Paths Operational
Data:
8            12/04/03 08:15A     Zone Merge Completed
```

show.fabricLog.wrap

Syntax `wrap [clear]`

Purpose This command displays the contents of the wrapping region of the fabric log. The log entries will not persist over IMLs or power cycles; it will not be stored in NV RAM.

NOTE: This log will begin to wrap after the log is filled.

Parameters This command has one optional parameter. If no parameter is specified, then the 1000 entries of the log will be displayed.

clear	Removes all entries from the log.

Command Example `show fabricLog Wrap`

Output This command displays the following data:

Count	A constantly incrementing counter.
Date/Time	The date and time of the log entry.
Description	A description of the log entry.
Data	Extended data that is associated to the log entry.

Output Example The output of the *show.fabricLog.wrap* command appears as follows:

```
Count        Date/Time           Description
----------   ---------------     -------------
11           11/24/03 04:18P     Port RSCN
Data: RSCN Reason=2301, Port Offline/Online=26437, Ports 0, 1, 2, 3, 4, 5, 6,
   7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24,
   25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39 40, 41, 42,
   43, 44, 45, 46, 47, 48, 49,50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60,
   61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78,
   79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96,
   97, 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111,
   112, 113, 114, 115, 116, 117, 118, 119, 120, 121, 122, 123, 124, 125,
```

```
   126, 127, 132, 133, 134, 135, 136, 137, 138, 139, 140, 141, 142, 143,
144
10            12/04/03 08:15A     Fabric Operational
Data:
9             12/04/03 08:15A     Paths Operational
Data:
8             12/04/03 08:15A     Zone Merge Completed
Data:
```

show.fabric.nodes

Syntax `nodes`

Purpose This command displays a list of all fabric-attached nodes.

Parameters This command has no parameters.

Command Example `Root> show fabric nodes`

Output The data is displayed as a table that includes the following properties:

Domain ID	Domain ID of the switch to which the device is attached.
Node WWN	The Node WWN of the fabric attached node.
Port WWN	The Port WWN of the fabric attached port.

Output Example The output from the *show.fabric.nodes* command appears as follows:

```
Domain ID  Node WWN                  Port WWN
---------  ------------------------  ------------------------
3          6C:61:62:01:3A:C5:CC:BF   6C:61:62:01:3A:C6:0D:87
```

show.fabric.ping

Syntax `ping destination [count] [timeout]`

Description This command pings the specified destination.

Parameters This command has three parameters. The last 2 parameters are optional.

destination	The destination to be pinged. This parameter can be an FC ID or the WWN of the destination in the fabric.
count	The number of times the destination is to be pinged. Default is 4. Maximum count possible is 10.
timeout	The time the command waits before timing out. Default is 5s. Maximum possible timeout is 10s.

Command Example

```
Root> show fabric ping 6F0613
```

Output

Time taken (ms)	The time taken to get reply from the destination.

Output Example

```
Ping 6F0613
Show.Fabric> ping 6F0613
This command may take up to 20s to complete
Received response from 6F0613 in 57ms.
Received response from 6F0613 in 57ms.
Received response from 6F0613 in 52ms.
Received response from 6F0613 in 58ms.

Show.Fabric> ping 6F0713
This command may take up to 20s to complete
Received response from 6F0713 in 400ms.
Response from 6F0713 timed out
Received response from 6F0713 in 95ms.
Received response from 6F0713 in 80ms.
```

show.fabric.principal

Syntax

```
principal
```

Purpose This command displays the WWN of the principal switch in the fabric.

Parameters This command has no parameters.

Command Example

```
Root> show fabric principal
```

Output The data is displayed as a table that includes the following properties:

Principal Switch WWN	The WWN of the principal switch in the fabric.

Output Example

```
Principal Switch WWN:     00:00:00:00:00:00:00:00
```

show.fabric.showRouteTable

Syntax

```
showRouteTable [source] [destination]
```

Description

This command displays routes for specified online ingress port to specified domains in the fabric.

Parameters

This command has two parameters, which are optional.

source	The source port/Ingress port for which the route table is displayed.
destination	The destination Domain ID for which the route is displayed.

NOTE: If a parameter is not mentioned, then all the online ports and domains will be displayed.

Command Example

```
Root> show fabric showRouteTable
```

Output

The data is displayed as a table that includes the following properties:

Ingress	The ingress port on the switch.
DID	The destination Domain ID.
Egress	The egress port on the switch.
Rem DID	The neighboring switch's Domain ID.
Rem Ingress	The ingress port on the neighboring switch.
Hops	The number of hops the route makes to reach the neighboring DID.
Act Cost*	True cost of the link based on the port speed.
Eff Cost*	This is the FSPF cost of routing.
Path	Specifies if the path is a Preferred Path. Valid values are *Yes* or *No*.

* The actual cost and effective cost can be different based on whether ISL cost configuration is configured or not. If ISL cost configuration is configured, then links with different speeds will have different costs (1G = 1000, 2G = 1000, 4G = 250, 10G = 100). Actual cost lists the actual cost that based on the cost configuration and effective cost is the cost assuming that the ISL cost configuration is not configured.

Output Example

```
Show.Fabric> showRouteTable
Ingress  DID  Egress  Rem Did  Rem Ingress  Hops  Act Cost  Eff Cost  PPath
-------  ---  ------  -------  -----------  ----  --------  --------  -----
1        3    2       3        3            1     1000      1000      No
1        9    5       9        3            1     1000      1000      No
2        1    1       6        63           3     3000      3000      No
2        6    1       6        63           1     1000      1000      No
2        9    5       9        3            1     1000      1000      No
2        10   1       6        63           2     2000      2000      No
5        1    1       6        63           3     3000      3000      No
5        3    2       3        3            1     1000      1000      No
5        6    1       6        63           1     1000      1000      No
5        10   1       6        63           2     2000      2000      No


Show.Fabric> showRouteTable 5
Ingress  DID  Egress  Rem Did  Rem Ingress  Hops  Act Cost  Eff Cost  PPath
-------  ---  ------  -------  -----------  ----  --------  --------  -----
5        1    1       6        63           3     3000      3000      No
5        3    2       3        3            1     1000      1000      No
5        6    1       6        63           1     1000      1000      No
5        10   1       6        63           2     2000      2000      No

Show.Fabric> showRouteTable 5 10
Ingress  DID  Egress  Rem Did  Rem Ingress  Hops  Act Cost  Eff Cost  PPath
-------  ---  ------  -------  -----------  ----  --------  --------  -----
5        10   1       6        63           2     2000      2000      No
```

show.fabric.topology

Syntax `topology`

Purpose This command displays a text description of the fabric. The principal switch in the fabric will have a "*" next to it.

Parameters This command has no parameters.

Command Example `Root> show fabric topology`

Output The features data is displayed as a table that includes the following properties.

Switch WWN	The WWN of the switch at the local end of the ISL.
DID	The Domain ID of the switch at the local end of the ISL.
OutPrt	The port number at the local end of the ISL.
Remote WWN	The WWN of the switch at the remote end of the ISL.
RemDID	The domain ID of the switch at the remote end of the ISL.
RemPrt	The port number at the remote end of the ISL.

Output Example The output from the *show.fabric.topology* command appears as follows:

```
Switch WWN                DID  OutPrt  Remote WWN                RemDID  RemPrt
------------------------ ---  ------  ------------------------  ------  ------
02:30:40:32:34:34:32:21* 2    24      24:45:73:49:05:43:22:11   10      2
                              25      24:45:73:49:05:43:22:11   10      3
                              26      24:45:73:49:05:43:22:11   10      4
24:45:73:49:05:43:22:11  10   2       02:30:40:32:34:34:32:21   2       24
                              3       02:30:40:32:34:34:32:21   2       25
                              4       02:30:40:32:34:34:32:21   2       26
21:23:21:25:76:43:23:21  10   7       02:30:40:32:34:34:32:21   15      3
02:30:40:32:34:34:32:21  15   3       21:23:21:25:76:43:23:21   10      7
```

show.fabric.traceRoute

Syntax `traceRoute source destination`

Description This command retrieves the route between two nodes in the fabric.

Parameters This command has two parameters:

source	The source port for the trace route. This can be either a Port ID or a WWN.
destination	The destination port for the trace route. This can be either a Port ID or a WWN.

Command Example

```
Root> show fabric traceRoute
```

Output

Return code	The return value. Possible values are: • Command Completed Successfully • Command Not Supported in Next Switch • No Response from Next Switch • Maximum Hop Count Reached • Source Port not in Fabric • Destination Port not in Fabric • Devices not in Common Zone • No Route Between Designated Ports • No Additional Explanation • Fabric Busy • Fabric Build in Progress • Unable to run a trace route at this time
Number of Entries	The number of entries returned from the trace route.
Switch WWN	The switch WWN at that point in the trace route.
Domain ID	The switch Domain ID at that point in the trace route.
Ingress Port WWN	The Ingress Port WWN taken by the trace route.
Ingress Port Num	The Ingress Port Num taken by the trace route.
Egress Port WWN	The Egress Port WWN taken by the trace route.
Egress Port Num	The Egress Port Num taken by the trace route.
Direction	The direction the trace route was going for the specified entry. Possible values are: • Source to destination • At Destination • Destination to source

Output Example

Show.Fabric> traceroute 50:06:04:8D:C7:DF:AE:A0 50:06:04:8D:C7:DF:AE:9F

```
Return code:          Command Completed Successfully
Number of Entries:    6

Entry 0
Switch WWN:           10:00:08:00:88:60:F0:A2
```

```
Domain ID:              26
Ingress Port WWN:       20:15:08:00:88:60:F0:A2
Ingress Port Num:       17
Egress Port WWN:        20:0D:08:00:88:60:F0:A2
Egress Port Num:        9
Direction:              Source to destination

Entry 1
Switch WWN:             10:00:08:00:88:22:33:44
Domain ID:              2
Ingress Port WWN:       20:17:08:00:88:22:33:44
Ingress Port Num:       19
Egress Port WWN:        20:1B:08:00:88:22:33:44
Egress Port Num:        23
Direction:              Source to destination

Entry 2
Switch WWN:             10:00:08:00:88:A0:B0:9C
Domain ID:              31
Ingress Port WWN:       20:12:08:00:88:A0:B0:9C
Ingress Port Num:       14
Egress Port WWN:        20:0F:08:00:88:A0:B0:9C
Egress Port Num:        11
Direction:              At destination

Entry 3
Switch WWN:             10:00:08:00:88:A0:B0:9C
Domain ID:              31
Ingress Port WWN:       20:0F:08:00:88:A0:B0:9C
Ingress Port Num:       11
Egress Port WWN:        20:12:08:00:88:A0:B0:9C
Egress Port Num:        14
Direction:              Destination to source

Entry 4
Switch WWN:             10:00:08:00:88:22:33:44
Domain ID:              2
Ingress Port WWN:       20:1B:08:00:88:22:33:44
Ingress Port Num:       23
Egress Port WWN:        20:17:08:00:88:22:33:44
Egress Port Num:        19
Direction:              Destination to source

Entry 5
Switch WWN:             10:00:08:00:88:60:F0:A2
Domain ID:              26
Ingress Port WWN:       20:0D:08:00:88:60:F0:A2
Ingress Port Num:       9
Egress Port WWN:        20:15:08:00:88:60:F0:A2
Egress Port Num:        17
Direction:              Destination to source
```

show.features

Syntax `features`

Purpose This command displays a table of all installed feature sets and their states. This command provides the same output as the command *config.features.show* on page 2-12.

Parameters This command has no parameters.

Command Example

```
Root> show features
```

Output The features data is displayed as a table that includes the following properties:

Installed Feature Set	The feature set installed using a feature key. Only installed keys are displayed.
Feature	Individual features within each set. In many cases, there is only one feature within each feature set.
State	The state of the individual feature. Fabric-wide features are displayed as Active/Inactive. Switch-centric features are displayed as Enabled/Disabled.
Exp	The remaining evaluation time in days for the trial feature.

Output Example The output from the *show.features* command appears as follows:

```
Installed Feature Set           Feature                         State     Exp
------------------------------  ------------------------------  --------  -----
Security Package
  SANtegrity Binding            Switch Binding                  Enabled
  SANtegrity Binding            Fabric Binding                  Active
  SANtegrity Binding            Enterprise Fabrics              Active
  SANtegrity Authentication     SANtegrity Authentication       Enabled

FICON Cascading Bundle
  FICON Management Server       FICON Management Server         Enabled
  FICON CUP Zoning              FICON CUP Zoning                Active
  OpenTrunking                  OpenTrunking                    Active
NPIV Trial*                     NPIV Trial*                     Enabled*  27*
```

NOTE: The "*" in the output example indicates that the feature is a trial version. When the trial period expires, the *State* property will show the feature as *Disabled* and *Exp* property will show no value for the number of days.

NOTE: If a feature is present in two bundles, it will be shown in only one bundle under *Installed Feature Set* property.

show.fencing.policies

Syntax `fencing [name]`

Purpose This command displays a table of the configured fencing policies. If a specific policy name is given, then a full description of the policy is shown.

Parameters This command has one optional parameter, an individual policy name. If an individual policy name is given, then a detailed description will be shown for the specified policy. If no parameter is given, then a summary of all policies will be shown.

Command Example

```
Root> show fencing
Root> show fencing Protocol Errors #2
```

Output The data is displayed as a table that includes the following properties:

Name	The name of the policy. This will be concatenated to 50 characters in the summary display. The policy full name will be shown in comma-delim mode.
Ports	The ports to which the fencing policy will be applied.
Type	The type of the fencing policy.
Limit	The number of offenses that are allowed before a port is disabled.
Period	The amount of time that limit of number of offenses must exceed before a port is fenced.
State	The enabled state of the fencing policy.

Output Example

```
Root> show fencing
Name                        Type             State
--------------------------  ---------------  --------
Default_Protocol_Errors     Protocol Errors  Enabled
Protocol Errors #2          Protocol Errors  Disabled
Safety #2                   Protocol Errors  Enabled

Root> show fencing Protocol Errors #2
Name:        Protocol Errors #2
Ports:       2,4-7,20-24
Type:        Protocol Errors
Limit:       5
Period:      1800 seconds
State:       Disabled
```

show.ficonCUPZoning

Syntax

`ficonCUPZoning`

Purpose

This command displays the contents of the host control list and the enabled state of FICON CUP Zoning.

NOTE: The command *config.ficonCUPZoning.show* on page 2-22 has functionality that is the same as this command.

Parameters

This command has no parameters.

Command Example

`show ficonCUPzoning`

Output

The data is presented as a table with the following properties:

FICON CUP Zoning State	The enabled state of the FICON CUP Zoning feature
Host Control List	List of 0-8 control hosts, displays “empty” for control host list with no members.

Output Example

```
FICON CUP Zoning State:  Enabled
Host Control List
-----------------------
01:02:03:04:05:06:07:08
09:0A:0B:0C:0D:0E:0F:00
```

show.ficonMS

Syntax `ficonMs`

Purpose This command displays the FICON MS settings.

NOTE: This command is displayed on a Sphereon 3016 only if the feature key is installed.

Parameters This command has no parameters.

Command Example
```
Root> show ficonms
```

Output The data is displayed as a table that includes the following properties:

Ficon MS State	The state of the FICON MS feature.
Ficon MIHPTO	The Ficon MIHPTO value in seconds.

Output Example
```
Ficon MS State:            Disabled
Ficon MIHPTO (seconds):    180
```

show.frus

Syntax `frus`

Purpose This command displays information about all field-replaceable units (FRUs).

Parameters This command has no parameters.

Command Example
```
Root> show frus
```

Output The FRU information is displayed as a table that includes the following properties:

FRU	The FRU name. (This may show *Unknown* or *Not Installed* if the FRU is not installed.) The QPM FRU is applicable only to Intrepid 6140.
Position	The relative position of the FRU, that is, its slot.

State	The state of the FRU. Values are: **Active**—the current module is active. **Backup**—this module is not currently being used, but it is available for immediate failover. **Degraded**—the back end path is failed. (QPM and XPM only). **Powered Off**—the module is installed, but powered off. (Intrepid 6064 and QPM only). **NotInst**—the module is not currently installed. **Failed**—the current module is failed.
Serial Num	The serial number of the FRU. (This field is blank for power supply modules of the Sphereon 4300 and Sphereon 4500 switches.)
Part Num	The part number of the FRU.
Beacon	The beaconing state of the FRU. The valid values are *On* or *Off*.
Pwr On Hrs	The power-on hours value for the FRU.

NOTE: The QPM FRU is only applicable to Intrepid 6140 and Intrepid 6064.

Output Example The output from the *show.frus* command appears as follows:

```
FRU    Position  State   Serial Num      Part Num   Beacon  Pwr On Hrs
-----  --------  ------  --------------  ---------  ------  ----------
CTP    0         Active  470-000399-700  123456789  False   2800
CTP    1         Backup  470-000399-700  223456789  True    2801
SBAR   0         Active  470-000399-700  223456789  False   2801
SBAR   1         Failed  470-000399-700  223456789  False   2801
FPM    0         Prwoff
FPM    1         Active  470-000399-700  223456789  False   2801
QPM    3         Active  470-000399-700  223456789  False   831
XPM    2         Degred  470-000399-700  223456789  False   831
UPM    4         Active  470-000399-700  223456789  False   831
Power  0         Active  470-000399-700  223456789  False   831
Fan    0         Active  470-000399-700  223456789  False   831
```

show.ip.ethernet

Syntax `ethernet`

Purpose This command displays Ethernet attributes.

Parameters This command has no parameters.

Command Example

```
Root> show ip ethernet
```

Output The Ethernet attributes data is displayed as a table that includes the following properties:

IP Address	The IP address for the Ethernet adapter as set in the *config.ip.ethernet* command.
Gateway Address	The gateway address for the Ethernet adapter as set in the *config.ip.ethernet* command.
Subnet Mask	The subnet mask for the Ethernet adapter as set in the *config.ip.ethernet* command.

Output Example The output from the *show.ip.ethernet* command appears as follows:

```
LAN Information
IP Address:       144.49.10.15
Gateway Address:  144.49.10.1
Subnet Mask:      255.255.255.0
```

show.linkIncidentLog

Syntax

```
linkIncidentLog [clear]
```

Purpose This command displays the contents of the link incident log on the director or switch.

ATTENTION! If the switch is restarted (as occurs during IPL, IML, configuration reset, feature key installation, or firmware load) or is power cycled, the information in the link incident log is lost.

Parameters This command has one optional parameter:

clear	This optional parameter causes all link incident log entries to be cleared.

Command Example

```
Root> show linkIncidentLog
```

Output The event log data are displayed as a table that includes the following properties:

Date/Time	The date and time when the event occurred.
Port	The number of the port where the link incident occurred.
Link Incident Event	An ASCII string describing the link incident event.

Output Example The output from the *show.linkIncidentLog* command appears as follows:

```
Date / Time       Port  Link Incident Event
---------------   ----  ------------------------------------------------------
02/27/03 01:28P   20    Not Operational primitive sequence (NOS) received.
02/27/03 01:28P   4     Primitive sequence timeout.
02/27/03 01:27P   62    Not Operational primitive sequence (NOS) received.
02/27/03 01:27P   62    Invalid primitive seq received for current link state
```

show.loginServer

Syntax `loginServer`

Purpose This command displays information from the login server database for devices attached to this switch. Note that it is possible to have more than one device per port for any public loop devices attached to an FL_Port.

Parameters This command has no parameters.

Command Example

```
Root> show loginServer
```

Output The device information is displayed as a table that includes the following properties:

Port	The port number where the device is attached.
BB Crdt	The Buffer to buffer credit (BB_Credit). The maximum number of remaining frames that can be transmitted without causing a buffer overrun condition at the receiver.
RxFldSz	The buffer-to-buffer receive data field size from the FLOGI received from the attached N_Port.

COS	The class of service (for example, 1; 2; 3; 4; 5; 6; F; 1,2; 2,3).
Port Name	The port WWN of the attached device.
Node Name	The node WWN of the attached device.

Output Example The output from the *show.loginServer* command appears as follows:

```
Port BB Crdt   RxFldSz   COS   Port Name                Node Name
---- -------   -------   ---   ----------------------   ----------------------
0    10                 2,3   00:11:22:33:44:55:00:77  20:11:22:33:44:55:66:77
1    10                 2     00:11:22:33:44:55:00:78  20:11:22:33:44:55:66:78
4    10                 2,3   00:11:22:33:44:55:00:79  20:11:22:33:44:55:66:79
7    10                 2,3   00:11:22:33:44:55:00:80  20:11:22:33:44:55:66:80
8    10                 2     00:11:22:33:44:55:00:81  20:11:22:33:44:55:66:81
10   10                 2,3   00:11:22:33:44:55:00:82  20:11:22:33:44:55:66:82
11   10                 2,3   00:11:22:33:44:55:00:83  20:11:22:33:44:55:66:83
12   10                 3     00:11:22:33:44:55:00:84  20:11:22:33:44:55:66:84
13   10                 2,3   00:11:22:33:44:55:00:85  20:11:22:33:44:55:66:85
15   10                 2,3   00:11:22:33:44:55:00:86  20:11:22:33:44:55:66:86
```

show.nameServer

Syntax `nameServer DID`

Purpose This command displays information from the nameserver database for devices attached to this switch when DID is not specified. If DID is specified, the local nameserver database entries for the specified domain are displayed. If the parameter is "all", then all of the nameserver database entries for all the domains in the fabric will be displayed. Note that it is possible to have more than one device per port for any public loop devices attached to an FL_Port.

Parameters This command has one optional parameter.

DID	The DID of the switch whose nameserver database information is to be displayed. This parameter can also be *all*.

Command Example

```
Root> show nameServer
```

Output The device information data is displayed as a table that includes the following properties:

DID	The DID of the switch whose nameserver entries are being displayed.
Type	The type of the port (*N*, *NL*, *F/NL*, *F*, *FL*, *E*, *B*).
Port Id	The 24-bit Fibre Channel address.
Port Name	The port WWN of the attached device.
Node Name	The node WWN of the attached device.
COS	The class of service (for example, 1; 2; 3; 4; 5; 6; F; 1,2; 2,3).
FC4 Types	The FC4 types registered for this device. One or more numbers display in this field. The numbers in this field correspond to the list at the bottom of the output example below. Note: There can be multiple FC4 types for each device. Since this is very rare, the CLI may wrap in the event that more than two are registered for this device.

Output Example The output from the *show.nameServer* command appears as follows:

```
Show> nameServer all

DID  Type  PortId  Port Name                Node Name                COS  FC4
---  ----  ------  -----------------------  -----------------------  ---  ---
1    F     613613  50:06:04:8A:CC:C8:61:51  50:06:04:8A:CC:C8:61:51
1    F     613B13  10:00:00:00:C9:20:DB:1F  20:00:00:00:C9:20:DB:1F
21   F     753713  50:06:04:8A:CC:C8:61:50  50:06:04:8A:CC:C8:61:50
28   F     7C3913  10:00:00:00:C9:20:DA:D1  20:00:00:00:C9:20:DA:D1
12   F     6C3A13  10:00:00:00:C9:20:DB:10  20:00:00:00:C9:20:DB:10

FC4 types decode information can be viewed via the show nameserverFC4Types CLI
command

Show> nameServer 1

DID  Type  PortId  Port Name                Node Name                COS  FC4
---  ----  ------  -----------------------  -----------------------  ---  ---
1    F     613613  50:06:04:8A:CC:C8:61:51  50:06:04:8A:CC:C8:61:51
1    F     613B13  10:00:00:00:C9:20:DB:1F  20:00:00:00:C9:20:DB:1F

FC4 types decode information can be viewed via the show nameserverFC4Types CLI
command
```

```
Show> nameServer

DID  Type  PortId  Port Name                Node Name                COS  FC4
---  ----  ------  -----------------------  -----------------------  ---  ---
28   F     7C3913  10:00:00:00:C9:20:DA:D1  20:00:00:00:C9:20:DA:D1

FC4 types decode information can be viewed via the show nameserverFC4Types CLI
command
Show> nameServer 15 (15 is not in the fabric)
No entries in the database for Domain 15.
```

show.nameServerExt

Syntax `nameServerExt`

Purpose This command displays extended information from the nameserver database for devices attached to this switch. The command provides symbolic nameserver information, as well as the same information as the *show.nameServer* command. Multiple devices per port are possible for any public loop device attached to an FL_Port.

NOTE: Because it contains symbolic nameserver information that can be lengthy, the CLI output wraps several times per node. For this reason, this command is supported only in comma-delimited mode. For more information about the comma-delimited mode, see *Using the commaDelim Command* on page 1-19.

Parameters This command has no parameters.

Command Example

```
Root> show nameServerExt
```

Output The device information data is displayed as a table that includes the following properties:

Type	The type (N, NL, F/NL, F, FL, E, B).
Port Id	The 24-bit Fibre Channel address.
Port Name	The port WWN of the attached device.
Node Name	The node WWN of the attached device.
COS	The class of service (for example, 1; 2; 3; 4; 5; 6; F; 1,2; 2,3).

FC4	The FC4 types registered for this device. One or more numbers display in this field. The numbers in this field correspond to the list in the output example for *show.nameServer* on page 2-206.
SymNodeName	255-character representation of the Symbolic Node Name.
SymPortName	255-character representation of the Symbolic Port Name.

Output Example The output from the *show.nameServerExt* command appears as follows:

```
Type, Port Id, Port Name, Node Name, COS, FC4 Types, SymNodeName, SymPortName,
N,  010400, 00:11:22:33:44:55:00:77, 20:11:22:33:44:55:66:77, 2-3, 2, Node Name A, Port Name A,
N,  010500, 00:11:22:33:44:55:01:77, 20:11:22:33:44:55:66:77, 2-3, 0, This Is Symbolic Node Name B,
Symbolic Port Name B Is Slightly Longer
N, 010600, 00:11:22:33:44:55:66:02, 20:11:22:33:44:55:66:77, 2-3, 2, , ,
FL, 000001, 00:11:22:33:44:55:66:03, 20:11:22:33:44:55:66:77, 2, 0, Loop Node 1, Loop Port 7
FL, 000002, 00:11:22:33:44:55:66:04  20:11:22:33:44:55:66:77, 3, 2, Loop Node 2, Loop Port 7,
```

show.nameServerFC4Types

Synopsis `nameServerFC4Types`

Description This command displays the FC4 types.

One or more FC4 types will be displayed in the FC4 field from the nameserver command. These FC4 types will index into the list of FC4 types in the table. Some of the valid FC4 types are displayed in the following *Output Example*.

Parameters This command has no parameters.

Command Example

```
Root> show nameServerFC4Types
```

Output Example

```
Show> nameserverFC4Types
0. ISO/IEC 8802-2 LLC
1. ISO/IEC 8802-2 LLC/SNAP
2. SCSI-FCP
3. SCSI-GPP
4. IPI-3 Master
5. IPI-3 Slave
6. IPI-3 Peer
7. CP IPI-3 Master
8. CP IPI-3 Slave
9. CP IPI-3 Peer
10. SBCCS-Channel
```

```
11. SBCCS-Cntrl Unit
12. FC Srvcs
13. FC-FG
14. FC-XS
15. FC-AL
16. SNMP
17. HIPPI-FP
18. Vendor Unique
```

show.NPIV.config

Syntax `config`

Purpose This command displays the current NPIV configuration for all ports.

NOTE: The command *config.NPIV.show* on page 2-27 has functionality that is identical to this command.

Parameters This command has no parameters.

Command Example

```
Root> show NPIV config
```

Output This command displays the following NPIV configuration data:

NPIV state	The current enabled / disabled state of the NPIV feature.
Max Allowed NPIV Login Table	A table mapping each port number on the switch to a corresponding max number of NPIV logins setting.

Output Example

```
NPIV state:  Enabled
Port  Max Allowed NPIV Logins
----  -----------------------
1     10
2     10
3     10
4     0
5     0
7     130...
```

show.openSysMS.config

Syntax `config`

Purpose This command displays the Open System Management Server (OSMS) state and the Open System Management Server Host Control State.

Parameters This command has no parameters.

Command Example

```
Root> show openSysMS config
```

Output The configuration data is displayed as a table that includes the following properties:

openSysMS State	The Open System Management Server state.
Host Control State	The Open System Management Server Host Control state.

Output Example

```
openSysMS State:    disable
Host Control State: enable
```

show.openSysMS.platformInfo

Synopsis

```
platformInfo type [name]
```

Description This command is used to query the OSMS to find the status of the platform registration process.

Parameters This command has two required parameters. The second parameter is optional.

type	The type of query. Valid query types are: *GPNL – Get Platform Name List* *GPLNL – Get Platform Node Name List for a particular platform* *GPLML – Get Platform Management Address List for a particular platform* *GPLT – Get Platform Type for a particular platform*
name	The platform name. It is a required parameter for *GPLNL*, *GPLML* and *GPLT* queries. There is no name parameter for *GPNL* query.

Command Example `Root> show openSysMS platformInfo GPNL`

Output The configuration data is displayed as a table that includes the following properties:

Platform Name	The list of Platform Name List for GPNL query.
Node Name	The list of Platform Node Name List for GPLNL queries.
Platform Management Address	The Platform Management Address (URL) List for GPLML queries.
Platform Type	The Platform Type for GPLT queries.

Output Example

```
show.openSysMS>platformInfo GPNL
Platfrom Name
-------------------------
Platform 1
Platform 2
Platform 3

show.openSysMS>platformInfo GPLNL "platform 2"
Node Name
----------------------------------
Node name 1
Node name 2

show.oOpenSysMS>platformInfo GPLML "platform 1"
Platform Management Address
--------------------------------
Management Address #1
Management Address #2
show.openSysMS>platformInfo GPLT "platform 3"

Platform Type
-------------
00 00 00 0A
```

show.openTrunking.config

Syntax `config`

Purpose This command displays the trunking configuration for all ports.

Parameters This command has no parameters.

Command Example `show openTrunking config`

Output The device information is displayed as a table that includes the following:

Unresolved Congestion	The current enabled/disabled state of the unresolved congestion trunking feature.
Backpressure	The current enabled/disabled state of the backpressure trunking feature.
Low BB_Credit Threshold	The current threshold setting of the low BB_Credit threshold trunking feature listed as a percentage. If this value is configured to be the default, `(default)` is displayed alongside the threshold value. The default value is 75%.
Congestion Threshold Table	A table mapping each port number on the switch to a corresponding threshold setting. The threshold is listed as a percentage. If this value is configured to be the default, `(default)` is displayed alongside the threshold value. The default value is 60%.

Output Example The output from the *show.openTrunking.config* command appears as follows:

```
Unresolved Congestion:            Enabled
Backpressure:                     Disabled
Low BB_Credit Threshold (%):      75 (default)
Port  Threshold %
----  ------------
1     60 (default)
2     69
3     60 (default)
4     60 (default)
5     90
6     80
...
```

show.openTrunking.rerouteLog

Syntax `reroutelog [clear]`

Purpose This command displays the Open Trunking Re-route Log information.

ATTENTION! If the switch is restarted (as occurs during IPL, IML, configuration reset, feature key installation, or firmware load) or is power cycled, the information in the Open Trunking Re-route Log is lost.

Parameters This command has one optional parameter:

clear	This optional parameter causes all re-route log entries to be cleared.

Command Example

```
show opentrunking reroutelog
```

NOTE: The *clear* parameter also clears the log entries for your SAN management application.

Output The device information data is displayed as a table that includes the following properties:

Date/Time	The date/time when the rerouting event occurred.
Rcv	The port associated with the flow that was rerouted.
Dom	The target domain associated with the flow that was rerouted.
Old	The exit port number on this switch that the flow used to get to the target domain.
New	The exit port number on this switch that the flow now uses to get to the target domain.

Output Example The output from the *show.opentrunking.reroutelog* command appears as follows:

```
Date/Time         RcvPort  Dom  OldExit  NewExit
---------------   -------  ---  -------  -------
04/12/01 10:58A   63       2    41       42
03/23/02 12:01P   4        3    35       36
```

show.port.config

Syntax

```
config
```

Purpose This command shows the port configuration for all ports.

Parameters This command has no parameters.

Command Example

```
Root> show port config
```

Output The port configuration attributes are displayed as a table that includes the following properties:

Port	The port number.
Name	The name of the port as set in the *config.port.name* command.
Blocked	The blocked state of the port as set in the *config.port.blocked* command.
FAN	The configured Fabric Address Notification (FAN) state. (Sphereon 4300, Sphereon 4500, Sphereon 4400, and Sphereon 4700 switches only).
Type	The port type as set in the *config.port.type* command.
Speed	The configured port speed. *1G – 1 Gb/sec* *2G – 2 Gb/sec* *4G – 4 Gb/sec (Sphereon 4400 and Sphereon 4700 only)* *10G – 10 Gb/sec (XPM only)* *Neg – Negotiate* *4G Sust – 4 Gb/sec Sustained (QPM only)* *4G Burst – 4 Gb/sec Burst (QPM only)* *Neg Sust – Negotiate Sustained (QPM only)* *Neg 2G Max – Negotiate 2 Gb/sec Maximum (QPM only)* *Neg B 4G Max – Negotiate Burst 4 Gb/sec Maximum (QPM only)*
Rx Crdts	The number of Rx BB_Credits as set in the *config.port.rxCredits* command.

Output Example The output from the *show.port.config* command appears as follows:

```
Port  Name                      Blocked    Type    Speed           Rx Crdts
----  ------------------------  ---------  ------  --------------  --------
0     port_0_name               Blocked    gxPort  Neg Sust        12
1                               Blocked    gxPort  Neg Burst       12
2                               Blocked    gxPort  Neg Burst       12
3                               Blocked    gxPort  Neg Burst       12
...
```

show.port.exit

Syntax

```
exit destDomainID sourcePort
```

Purpose

This command displays the exit port from a source port to a given destination domain. This command shows the preferred path configuration.

Use *all* for one of the command's parameters to display all configured and actual exit ports for either the destination domain ID or the specified source port. You cannot specify *all* for both parameters. If the destination domain is set to *all*, then all paths from the specified source port are displayed. If the source port is set to *all*, the output shows all source port paths to the specified domain.

Parameters

This command has the following parameters:

destDomainId	Specifies the destination domain ID. Valid domain IDs are in the range 1–31, or, use *all* to show all exit ports to and from the source port specified in the sourcePort parameter.
sourcePort	Specifies the number of the source port. Valid port numbers values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 4700 0–31 for the Sphereon 3032 and 3232 0–31 for the ED-5000 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140 Or, you can specify *all* to show all exit ports to the destination domain ID specified for the *destDomainId* parameter.

Output

The output from *show.port.exit* includes the following parameters:

Destination Domain	The destination domain ID to which a preferred path has been configured. This is displayed only if the destination domain parameter is set to *all*.
Source Port	The source port for which a preferred path to the specified destination domain ID is specified. This is displayed only if the source port parameter is set to *all*.
Exit Port	This is the actual exit port being used for the given path. The value *No Domain* displays when the destination domain doesn't exist in the fabric. The value *No Source* displays when the source port is in an offline state. The value *Fabric Building* displays when the fabric is still building.

Command and Output Examples

The following examples show the output returned by the three methods of specifying the *show.port.exit* command.

Output with single values for both parameters

```
Root> show port exit 21 10
Exit Port:  45
```

Output with destDomainId set to all

```
Root> show port exit all 15
Destination Domain  Exit Port
------------------  ----------------
1                   23
2                   No Domain
3                   23
…
31                  No Domain
```

Output with sourcePort set to all

```
Root> show port exit 1 all
Source Port         Exit Port
------------------  ----------------
0                   No Source
1                   5
2                   No Source
3                   6
…
```

show.port.info

Syntax `info`

Purpose This command displays port information for all ports.

Parameters This command has no parameters.

Command Example `Root> show port info`

Output The port information data is displayed as a table that includes the following properties:

Port	The port number.
WWN	The WWN of the port.
OpSpeed	The current operating speed. Valid values are: *Not Established* *1G – 1 Gb/sec* *2G – 2 Gb/sec* *4G – 4 Gb/sec (Sphereon 4400 and Sphereon 4700 only)* *10G – 10 Gb/sec (XPM only)* *4G Sust – 4 Gb/sec Sustained (QPM only)* *4G Burst – 4 Gb/sec Burst (QPM only)* *For QPM inactive port, it displays "Supports Port number (note: the sustained port number)"*

SpeedCap	The current transceiver capability speed. Valid values are: *1 – 1g* *2 – 2g* *4 – 4g capable (Sphereon 4400 and Sphereon 4700 only)* *Neg – Negotiable speed* *Neg_2 – Negotiable speed up to 2g maximum* *4_B – 4g Burst* *4_S – 4g Sustained* *Neg_S – Negotiable speed in sustained mode* *Neg_B_4 – Negotiable speed in burst mode up to 4g maximum*

Output Example The output from the *show.port.info* command appears as follows:

```
Port  WWN                      OpSpeed    SpeedCap
----  -----------------------  ---------  ---------------------------------------
0     20:10:08:00:88:04:9A:1B  Neg        1  2  4_S  4_B  Neg_S  4_S
1     20:11:08:00:88:04:9A:1B  1          1  2  4_B  Neg_S
2     20:12:08:00:88:04:9A:1B  Neg        1  2  4_S  4_B  Neg_S  Neg_2_Max
3     20:13:08:00:88:04:9A:1B  1          1  2  4_B  Neg_S
4     10:00:80:04:11:22:33:44  2          1  2  Neg
5     10:00:80:05:11:22:33:44  2          1  2  Neg
6     10:00:80:06:11:22:33:44  2          1  2  Neg
7     10:00:80:07:11:22:33:44  2          1  2  Neg
8     10:00:80:08:11:22:33:44  2          1  2  Neg
9     10:00:80:09:11:22:33:44  2          1  2  Neg
10    10:00:80:10:11:22:33:44  1          1  2  Neg
11    10:00:80:11:11:22:33:44  1          1  2  Neg
12    10:00:80:12:11:22:33:44  1          1  2  Neg
13    10:00:80:13:11:22:33:44  1          1  2  Neg
14    10:00:80:14:11:22:33:44  1          1  2  Neg
15    10:00:80:15:11:22:33:44  1          1  2  Neg
```

show.port.nodes

Syntax `nodes portNumber`

Purpose This command displays the loginserver entries for a specified port. This command is valid only on the Sphereon 4300 and Sphereon 4500 switches.

Parameters This command has one parameter:

portNumber	Specifies the port number. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 4700

Command Example

```
Root> show port nodes portNumber
```

Output The port nodes data is displayed as a table that includes the following properties:

FC Addr	The Fibre Channel address of nodes attached to this port. Private devices are assigned address strings of 0000 followed by the two-digit hexadecimal Arbitrated Loop Physical Address (AL_PA), instead of the 6 digit hexadecimal number presented for public devices.
BB Crdt	Represents the maximum number of outstanding frames which can be transmitted without causing a buffer over-run condition at the receiver.
RxFldSz	Buffer-to-buffer Receive Data Field Size from the FLOGI received from the attached N_Port.
COS	Class of service: 1; 2; 3; 4; 5; 6; F; 1,2; 2,3…
Port Name	The port worldwide name of the attached device.
Node Name	The node worldwide name of the attached device.

Output Example The *show.port.nodes* command output for a mix of public and private nodes on a loop appears as follows:

```
FCAddr  BB Crdt  RxFldSz  COS  Port Name                Node Name
------  -------  -------  ---  ----------------------   ----------------------
612902  10                2,3  00:11:22:33:44:55:00:77  20:11:22:33:44:55:66:77
612903  10       2112     2    00:11:22:33:44:55:00:77  20:11:22:33:44:55:66:77
612904  10                2,3  00:11:22:33:44:55:00:77  20:11:22:33:44:55:66:77
612905  10                2,3  00:11:22:33:44:55:00:77  20:11:22:33:44:55:66:77
6129AB  8        2112     2    00:11:22:33:44:55:00:77  20:11:22:33:44:55:66:77
6129AC  10               2,3  00:11:22:33:44:55:00:77  20:11:22:33:44:55:66:77
6129AD  8                2,3  00:11:22:33:44:55:00:77  20:11:22:33:44:55:66:77
6129AE  10               3    00:11:22:33:44:55:00:77  20:11:22:33:44:55:66:77
6129FD  10               2,3  00:11:22:33:44:55:00:77  20:11:22:33:44:55:66:77
6129FE  10               2,3  00:11:22:33:44:55:00:77  20:11:22:33:44:55:66:77
```

show.port.opticData

Syntax `opticData portNumber`

Purpose This command shows the overall optic health, enhanced digital diagnostic data, and the thresholds for the specified port. At the end of this display, it will show which measurements have exceeded their thresholds.

Parameters This command has one parameter.

portNumber	The port number whose data will be displayed. Valid values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 0–31 for the Sphereon 4700 0–63 for the Intrepid 6064 0–143 for the Intrepid 6140 (128–131 are inaccessible)

Command Example

```
Show.Port> opticData 5
```

Output This command displays the following optic data:

Type	The measurement type. Temperature is in celsius, voltage is in volts, power is in mW, and current is in mA.
Value	The value of the measurement.
Low Warning	The lower limit for the warning threshold.
High Warning	The higher limit for the warning threshold.
Low Alarm	The lower limit for the alarm threshold.
High Alarm	The higher limit for the alarm threshold.

Output Example The output from the *show.port.opticData* command appears as follows:

```
Port Number:    5
Overall Health: Alarm
Transceiver:    SFP
Type         Value    Low Warning  High Warning  Low Alarm  High Alarm
-----------  -------  -----------  ------------  ---------  ----------
Temperature  134.600  -40.000       100.000       -45.000    105.000
3.3 Voltage  3.290    3.000         3.600         2.900      3.700
Current      7.460    4.600         14.800        3.100      20.000
TX Power     400.000  112.000       398.000       89.000     501.000
RX Power     17.000   13.000        1000.000      4.000      1259.000
1.8 Voltage  N/A      N/A           N/A           N/A        N/A
5.0 Voltage  N/A      N/A           N/A           N/A        N/A

Temperature High Alarm
TX Power High Warning
```

show.port.opticEDD

Syntax `OpticEDD`

Purpose This command displays Enhanced Digital Diagnostics (EDD) information for all ports. This information is in HEX format. If there is no port connected then “Unk” is displayed. For ports that are connected and does not support predictive optics monitoring feature will display “Unknown”.

Parameters This command has no parameters.

Command Example `Show port opticEDD`

Output The port optic diagnostic data is displayed as a table that includes the following properties.

Port	The port number.
Xcvr	The transceiver type.
Temp	The optic temperature in celsius.
3.3 Voltage	The 3.3 voltage in volts.
Current	The current in mA.
TX Pwr	The transceiver power in uW.
RX Pwr	The receiver power in uW.
1.8 Voltage	The 1.8 voltage in volts.
5.0 Voltage	The 5.0 voltage in volts.

Output Example The *show.port.opticEDD* command output appears as follows:

```
Port  Xvr    Temp   3.3 VoltCurrent  TX Power  RX Power1.8 Volt5.0 Volt
----  ---    -----  --------  -------   --------- ------------------    -------
0     UNK    UnknownUnknownUnknownUnknown  Unknown   UnknownUnknown
1     UNK    UnknownUnknownUnknownUnknown  Unknown   UnknownUnknown
2     UNK    UnknownUnknownUnknownUnknown  Unknown   UnknownUnknown
3     UNK    UnknownUnknownUnknownUnknown  Unknown   UnknownUnknown
4     XFP    36.1053.2565.324    602.100   289.3001.7794.998
```

show.port.opticHealth

Syntax `opticHealth`

Purpose This command shows the overall optic health for all ports that support Enhanced Digital Diagnostics (EDD).

NOTE: At unit startup, the health of the optics will be read at roughly one optic per second, and once it reaches the last port, it start from the beginning and update any changes.

Parameters This command has no parameters.

Output This command displays the following optic data:

Port	The port number.
Overall Health	The overall health of the optic. Possible values are list below according to priority.
Alarm	One or more alarm threshold has been exceeded.
Warning	One or more warning threshold has been exceeded.
Normal	All measurements are within thresholds.
No Info	The optic does not support enhanced digital diagnostics or the state has not been updated yet.

NOTE: If an *Alarm* and a *Warning* threshold have both been exceeded, then the *Alarm* state will be displayed because it is of high priority.

Command Example
```
Root> Show Port opticHealth
```

Output Example The *show.port.opticHealth* command output appears as follows:

```
Port  Transceiver  Overall Health
----  -----------  --------------
0     XPM          Normal
1     (Unaddressable)
2     (Unaddressable)
3     (Unaddressable)
4     SFP          Normal
5     Unk          No Info
6     Unk          No info
7     SFP          Warning
8     SFP          Alarm
...
```

show.port.opticInfo

Syntax
```
OpticInfo
```

Purpose This command displays information about the optic.

Parameters This command has no parameters.

Command Example
```
Root> show port opticInfo
```

Output The port optic data is displayed as a table that includes the following properties:

Port Number	The port number.
Transceiver	The transceiver type.
Vendor Name	The vender name.
Serial Number	The serial number.
Part Number,	The part number.
Revision Level	The revision level.
Supported Link Length	The Supported link length.
Extended Identifier	The extended identifier.
Date and Lot	The data and lot.

Output Example The *show.port.opticInfo* command output appears as follows:

```
Port Number,Tranceiver,Vendor Name,Serial Number,Part Number,Revision
   Level,Supported Link Length,Extended Identifier,Date and Lot#,
0,SFP,E2O COMMS INC   ,36U1348         ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/03/03 Lot#   ,
1,SFP,E2O COMMS INC   ,36U3682         ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/04/03 Lot#   ,
2,SFP,E2O COMMS INC   ,36U1343         ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/03/03 Lot#   ,
3,SFP,E2O COMMS INC   ,36U1344         ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/03/03 Lot#   ,
4,SFP,E2O COMMS INC   ,36U1349         ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/03/03 Lot#   ,
5,SFP,E2O COMMS INC   ,36U1346         ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/03/03 Lot#   ,
6,SFP,E2O COMMS INC   ,35C6334         ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,05/24/03 Lot#   ,
7,SFP,E2O COMMS INC   ,36U3677         ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/04/03 Lot#   ,
8,SFP,E2O COMMS INC   ,36U1350         ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/03/03 Lot#   ,
9,SFP,E2O COMMS INC   ,35D2220         ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,05/16/03 Lot#   ,
10,SFP,E2O COMMS INC   ,36U1345         ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/03/03 Lot#   ,
11,SFP,E2O COMMS INC   ,36U3681         ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/04/03 Lot#   ,
```

```
12,SFP,E2O COMMS INC   ,3770978          ,EM212-LP3TA-MT  ,4R  ,0   0   30
   15,4,07/09/03 Lot#   ,
13,SFP,E2O COMMS INC   ,36U1338          ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/03/03 Lot#   ,
14,SFP,E2O COMMS INC   ,36U1347          ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/03/03 Lot#   ,
15,SFP,E2O COMMS INC   ,36U1332          ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/03/03 Lot#   ,
16,SFP,E2O COMMS INC   ,36U3676          ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/04/03 Lot#   ,
17,SFP,E2O COMMS INC   ,476PM46          ,EMA2G-LD3TA-MT  ,2   ,0   0   30
   15,4,07/07/04 Lot#   ,
18,SFP,E2O COMMS INC   ,3161215          ,EM212-LP3TA-MB  ,4   ,0   0   30
   15,4,01/16/03 Lot#   ,
19,SFP,E2O COMMS INC   ,477P560          ,EMA2G-LD3TA-MT  ,2   ,0   0   30
   15,4,07/08/04 Lot#   ,
20,SFP,E2O COMMS INC   ,36U1331          ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/03/03 Lot#   ,
21,SFP,E2O COMMS INC   ,36U1335          ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/03/03 Lot#   ,
22,SFP,E2O COMMS INC   ,36U1339          ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/03/03 Lot#   ,
23,SFP,E2O COMMS INC   ,36U1341          ,EM212-LP3TA-MT  ,4   ,0   0   30
   15,4,07/03/03 Lot#
```

show.port.profile

Syntax `show port profile`

Purpose This command displays the port configuration for the specified port.

Parameters This command has one parameter:

portNumber	Specifies the port number. Valid values are: 0–15 for the Sphereon 3016 0–16 for the Sphereon 4400 0–23 for the Sphereon 4500 0–31 for the Sphereon 3032 0–32 for the Sphereon 4700 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140

Command Example

```
Root> show port profile portNumber 138
```

Output

The port profile information is displayed as a single output for an individual port.

Port Number	Port number.
Name	Configured port name.
Blocked	Blocked state. Valid values are true and false.
Blocked Reason	Blocked reason. Valid values are "*Blocked temporarily, Internal*","*Blocked by user*","*Blocked by hardware type change*","*Blocked by port fencing*".
Operating Type	Operating port type.
Operating Speed	Operating port speed. Valid values are *Not Established* *1G – 1 Gb/sec* *2G – 2 Gb/sec* *4G – 4 Gb/sec (Sphereon 4400 and Sphereon 4700 only)* *10G – 10 Gb/sec (XPM only)* *4G Sust – 4 Gb/sec Sustained (QPM only)* *4G Burst – 4 Gb/sec Burst (QPM only)* *For QPM inactive port, it displays "Supports Port number (note: the sustained port number)"*
Port WWN	Port WWN.
Configured Type	Configured port type.

Configured Speed	Configured port speed. *1G - 1 Gb/sec* *2G - 2 Gb/sec* *4G - 4 Gb/sec (Sphereon 4400 and Sphereon 4700 only)* *10G - 10 Gb/sec (XPM only)* *Neg - Negotiate* *4G Sust - 4 Gb/sec Sustained (QPM only)* *4G Burst - 4 Gb/sec Burst (QPM only)* *Neg Sust - Negotiate Sustained (QPM only)* *Neg 2G Max - Negotiate 2 Gb/sec Maximum (QPM only)* *Neg B 4G Max - Negotiate Burst 4 Gb/sec Maximum (QPM only)*
Beaconing	Beaconing state.
FAN	FAN state.
FC Address	The Port Fibre Channel address.
Attached WWN	The node WWN of the device at the remote end of the link. A loop port will display the first attached loop device.
Operational State	The operational state of the port.
Reason	The reason that the port operational state is not "online".
Rx BB_Credits	Then number of configured Rx BB_Credits.
Connector Type	Optic connector type.
Transceiver	Optic transceiver type.
Distance Capability	Optic distance capability.
Media Type	Optic media type.
Speed Capability	Optic speed capability.
10G FC Compliance	Optic 10G FC Compliance code.

Output Example The output from the *show.port.profile* command appears as follows:

```
Port Number:              4
Name:                     Sam's tape drive
Blocked:                  False
Blocked Reason:
Operating Type:           FL Port
Operating Speed:          2G
Port WWN:                 A2:33:15:C3:3F:00:00:0A
Configured Type:          Gx_Port
Configured Speed:         Neg
Beaconing:                Disabled
FAN:                      Disabled
FC Address:               034FA2
Attached WWN:             F0:01:02:A1:B0:22:00:12
Operational State:        Online
Reason:                   None
Rx BB_Credits:            12
Connector Type:           LC
Transceiver:              Long LC
Distance Capability:      Long
Media Type:               M-M 50um
Speed Capability:         2 Gb/sec
10G FC Compliance:        None
```

show.port.showPortAddr

Syntax `showPortAddr`

Purpose This command displays the port address configuration for all ports.

NOTE: The *config.port.showPortAddr* on page 2-36 has functionality that is identical to this command.

Parameters This command has no parameters.

Command Example

```
Root> show port showPortAddr
```

Output The port configuration is shown as a table of properties. The following properties are displayed:

Port	The port number.

Original Addr	The original port address of the port.
Current Addr	The current port address of the port.
Swapped Port Num	If the port is swapped with another port, it will show the port number of the port it is swapped with.

Output Example

```
Port  Original Addr    Current Addr  SwappedPort Num
----  -------------    ------------  ---------------
0     4                4
1     5                5
2     6                7             3
3     7                6             2
4     8                8
5     9                9
6     a                a
7     b                b
8     c                c
...
```

show.port.status

Syntax `status`

Purpose This command displays port status for all ports.

Parameters This command has no parameters.

Command Example `Root> show port status`

Output The port status data is displayed as a table that includes the following properties:

Port	The port number.
State	The port state (for example, Segmented E_Port, Invalid Attachment, Not Installed, Online, Offline, Not Operational, No Light, Testing, Port Failure, Link Reset, or Inactive).

Type	The operational port type. If the configured port type is F_Port or E_Port, this value will match the configured type. If the configured type is G_Port, this value can be E_Port, F_Port, or G_Port, depending on what is connected to the port. On the Sphereon 4300 and Sphereon 4500, if the configured port type is Fx_Port, the operational port type can include FL_Port in addition to the values noted above for F_Port. If the configured port type is Gx_Port, then the operational port type can include FL_Port in addition to the values noted above for G_Port.
Attached WWN	The WWN of the device or switch attached to the port, if one is attached.
Beaconing	The beaconing state for the port (Off or On).

Reason	An optional message number that indicates whether the port has a segmented ISL, if a port binding violation has occurred, or if the port is inactive. The message description for this message number is provided at the bottom of the table. If the operational state is *Segmented E_Port*, only the following messages can be generated: • 01: Segment Not Defined • 02: Incompatible Operating Parameters • 03: Duplicate Domain ID(s) • 04: Incompatible Zoning Configurations • 05: Build Fabric Protocol Error • 06: No Principal Switch • 07: No Response from Attached Switch • 08: ELP Retransmission Failure Timeout If the operational state is *Invalid Attachment* only the following messages can be generated: • 09: Unknown • 10: ISL connection not allowed on this port • 11: ELP rejected by the attached switch • 12: Incompatible switch at other end of the ISL • 13: External loopback adapter connected to the port • 14: N_Port connection not allowed on this port • 15: Non-McDATA switch at other end of the ISL • 16: ISL connection not allowed on this port • 17: ISL connection not allowed to external Fabrics • 18: Port binding violation - unauthorized WWN • 19: Unresponsive Node Connected to Port • 20: Incompatible security attributes • 21: Fabric Binding violation • 22: Authorization failure • 23: Switch Binding violation
Reason (cont.)	If the operational state is *Inactive* only the following messages can be generated: • 24: Inactive - RC 0 • 25: No Serial Number • 26: Feature Not Enabled • 27: Switch Speed Conflict

Output Example The output from the *show.port.status* command appears as follows:

```
Port State              Type   Attached WWN             Beaconing  Reason
   ---- ----------------  -----  ----------------------  ---------  ------
   0    Online            fPort  10:00:80:00:11:22:33:44  Off
   1    Online            gPort  10:00:80:00:11:22:33:45  On
   2    No Light          fPort  10:00:80:00:11:22:33:55  On
   3    Offline           ePort  10:00:80:00:11:22:33:00  Off
   4    Online            gPort  10:00:80:00:11:22:33:57  Off
   5    Port Failure      fPort  10:00:80:00:11:22:33:46  Off
   6    Link Reset        gPort  10:00:80:00:11:22:33:63  Off
   7    Segmented E_Port  ePort  10:00:80:00:11:22:33:47  Off        02
   8    Online            ePort  10:00:80:00:11:22:33:88  Off
   9    Offline           fPort  10:00:80:00:11:22:33:49  Off
   10   Inactive          ePort  10:00:80:00:11:22:33:50  Off        26
   11   Online            fPort  10:00:80:00:11:22:33:53  Off
   12   No Light          fPort  10:00:80:00:11:22:33:56  Off
   13   Online            fPort  10:00:80:00:11:22:33:59  Off
   14   Invalid Attachment fPort  10:00:80:00:11:22:33:64  Off        15
   15   Online            fPort  10:00:80:00:11:22:33:66  Off

   02: Duplicate Domain ID(s)
   03: Switch Speed Conflict
   07: ISL connection not allowed on this port
```

show.port.technology

Syntax `technology`

Purpose This command displays port technology information for all ports.

Parameters This command has no parameters.

Command Example `Root> show port technology`

Output The port technology data is displayed as a table that includes the following properties:

Port	The port number.
Connectr	The port connector type (LC, MT_RJ, MU, Internal).
Transcvr	The transceiver type (Long LC, Short, Short OFC, Long LL, Long Dist).
Distance	The distances supported (Short, Intermediate, Long, Very Long).

Media	The media type (M-M 62.5um, M-M 50um, M-M 50,62.5um, S-M 9um, Copper).

Output Example

The output from the show.port.technology command appears as follows:

```
Port Connectr Transcvr  Distance     Media
---- -------- --------- ------------ -----------
0    LC       Long LC   Long         M-M 50um
1    LC       Long LC   Long         M-M 50um
2    LC       Long LC   Long         M-M 50um
3    MT_RJ    Long LC   Long         M-M 50um
4    MT_RJ    Long LC   Long         M-M 50um
5    MT_RJ    Long LC   Long         M-M 50um
6    LC       Long LC   Long         M-M 50um
7    LC       Long LC   Long         M-M 50um
8    LC       Long LC   Long         M-M 50um
9    LC       Long LC   Long         M-M 50um
10   LC       Long LC   Long         M-M 50um
11   LC       Long LC   Long         M-M 50um
12   LC       Long LC   Long         M-M 50um
13   LC       Long LC   Long         M-M 50um
14   LC       Long LC   Long         M-M 50um
15   LC       Long LC   Long         M-M 50um
```

show.preferredPath.showPath

Syntax

```
showPath destDomainID sourcePort
```

Purpose

This command displays the specified preferred path configuration and the actual path used by the system. The output shows both the exit port as configured for the preferredPath feature and the actual exit port currently being used for traffic.

Use *all* for one of the command's parameters to display all configured and actual exit ports for either the destination domain ID or the specified source port. You cannot specify *all* for both parameters. If the destination domain is set to *all*, all paths from the specified source port are displayed. If the source port is set to *all*, the output shows all source port paths to the specified domain.

Parameters This command has the following parameters:

destDomainId	Specifies the destination domain ID. Valid domain IDs are in the range 1–31 or *all*, which shows all paths to and from the source port specified in the sourcePort parameter.
sourcePort	Specifies the number of the source port. Valid port numbers values are: 0–11 for the Sphereon 4300 0–15 for the Sphereon 3016 and 3216 0–15 for the Sphereon 4400 0–23 for the Sphereon 4500 0-31 for the Sphereon 4700 0–31 for the Sphereon 3032 and 3232 0–31 for the ED-5000 0–63 for the Intrepid 6064 0–127 and 132–143 for the Intrepid 6140 Or, you can specify *all* to show all paths to the destination domain ID specified for the destDomainId parameter.

Output The output from the *show.preferredPath.showPath* command includes the following parameters:

Destination Domain	The destination domain ID to which a preferred path has been configured. This is displayed only if the destination domain parameter is set to *all*.
Source Port	The source port for which a preferred path to the specified destination domain ID is specified. This is displayed only if the source port parameter is set to *all*.
Preferred Exit Port	The configured preferred path exit port. This value can be any port number, or blank to indicate that no preferred path has been configured.
Actual Exit Port	This is the actual exit port being used for the given path.

Command and Output Examples

The following examples show the output returned by the three methods of specifying the *show.preferredPath.showPath* command.

Single values for both parameters

```
Root> show preferredPath showPath 21 10
Preferred Path State: Enabled
Preferred Exit Port:  Not Configured
Actual Exit Port:     45
```

destDomainId set to all

```
Root> show preferredPath showPath all 15
Preferred Path State: Enabled
Destination Domain  Preferred Exit Port  Actual Exit Port
------------------  -------------------  ----------------
1                   23                   23
3                   24                   No Path
4                   23                   23
17                  12                   No Source
```

sourcePort set to all

```
Root> show preferredPath showPath 1 all
Preferred Path State: Enabled
Source Port         Preferred Exit Port  Actual Exit Port
------------------  -------------------  ----------------
0                   2                    No Source
2                   5                    5
3                   17                   No Path
22                  5                    6
```

show.preferredPath.showState

Syntax `showState`

Purpose This command displays the state of the preferred path.

Parameters This command has one parameter:

Preferred Path State	Indicates the state of the preferred path (Enabled or Disabled).

Command Example

```
Root> show.preferredPath.showState
```

show.security.fabricBinding

Syntax `fabricBinding`

Purpose This command displays the fabric binding configuration saved on the fabric. The command performs the same function as the command See *config.security.fabricBinding.showActive* on page 2-66..

Parameters This command has no parameters.

Command Example

```
Root> show security fabricBinding
```

Output The fabric binding configuration data is displayed as a table that includes the following properties:

Domain ID	The domain ID of the Fabric Binding Membership List (FBML) member. Valid domain IDs range from 1 to 239.
WWN	The world wide name (WWN) of the FBML member in colon-delimited hexadecimal notation.
Attachment Status	Indicates whether the FBML member is Local, Attached, or Unattached. For more information, see *Fabric Binding Membership Terminology* on page 2-62.

Output Example The output from the *show.security.fabricBinding* command appears as follows:

```
Domain 1  (20:30:40:50:60:70:8F:1A) (Local)
Domain 3  (00:11:22:33:44:55:66:77) (Unattached)
Domain 2  (88:99:AA:BB:CC:DD:EE:FF) (Attached)
Domain 14 (11:55:35:45:24:78:98:FA) (Attached)
```

show.security.log

Syntax `log [clear]`

Purpose This command shows the contents of the security log as maintained in NV-RAM on the director or switch.

Parameters This command has one parameter:

clear	This optional parameter causes all security log entries to be cleared.

Command Example `Root> show security log`

Output The security log data are displayed as a table that includes the following properties:

Reason	The reason code for the security event.
Date/Time	The date and time when the event occurred.
Trigger Level	The trigger level of the event. Possible values are *Informational, Security Change, or Error*.
Category	The event category message. Possible values are *Successful Connection, Disconnection, Configuration Change, Authorization Failure, Authentication Failure, or Reserved.*
Count	A cumulative count of events within a known period.
Desc	A formatted string containing a description of the event.
Data	A formatted string containing additional or event-specific data.

Output Example The output from the *show.security.log* command appears as follows:

```
Reason  Date/Time        Trigger Level    Category                Count
------  --------------  --------------  ----------------------  -----
10000   04/12/01 10:58A  Informational    Successful Connection   375
  Desc: EWS User Connected
  Data: Usr=Administrator IPaddr=001.002.003.004 Role=admin
10305   04/11/01 01:03A  Error            Authorization Failure   1
  Desc: IP Access Control List Violation
  Data: IPaddr=172.072.016.097 SrcPort=0072 DestPort=0124
10300   04/02/01 08:30P  Error            Authorization Failure   3
  Desc: Fabric Binding Mismatch
  Data: Prt=0100 NbrW=02:15:F4:2A:11:0F:11:00 NbrDID=004 ErrDID=001
10411   03/31/01 02:24A  Error            Authentication Failure  1
  Desc: OS Management Server Authentication Not Provided
  Data: Port=0100 WWN=01:02:03:04:05:06:07:08
```

show.security.portBinding

Syntax `portBinding`

Purpose This command shows the port binding configuration for all ports.

Parameters This command has no parameters.

Command Example

```
Root> show security portBinding
```

Output The port binding configuration data is displayed as a table that includes the following properties:

Port	The port number.
WWN Binding	The state of port binding for the specified port (active or inactive).
Bound WWN	The WWN of the device that is bound to the specified port. If this field is blank, no device is bound to the specified port.

Output Example The output from the *show.security.portBinding* command appears as follows:

```
Port      WWN Binding      Bound WWN
----      -----------      ----------------------
0         Active           AA:00:AA:00:AA:00:AA:00
1         Inactive         00:00:00:00:00:00:00:00
2         Inactive         CC:33:44:55:CC:33:44:55
3         Active           00:00:00:00:00:00:00:00
4         Inactive         00:00:00:00:00:00:00:00
5         Inactive         00:00:00:00:00:00:00:00
6         Inactive         00:00:00:00:00:00:00:00
7         Inactive         00:00:00:00:00:00:00:00
8         Inactive         00:00:00:00:00:00:00:00
9         Inactive         00:00:00:00:00:00:00:00
10        Inactive         00:00:00:00:00:00:00:00
11        Inactive         00:00:00:00:00:00:00:00
12        Inactive         00:00:00:00:00:00:00:00
13        Inactive         00:00:00:00:00:00:00:00
14        Inactive         00:00:00:00:00:00:00:00
15        Inactive         00:00:00:00:00:00:00:00
```

show.security.switchAcl

Syntax

```
switchAcl
```

Purpose This command displays the contents of the Switch Access Control List.

Parameters This command has no parameters.

Command Example

```
Root> show security switchACL
```

Output The data is displayed as a table that includes the following properties:

Switch ACL State	The enabled state of the switch access control list.
Starting IP Address	The starting IP address of a range in the access control list.
Ending IP Address	The ending IP address of a range in the access control list.

Output Example

```
ACL State:  Disabled
Starting IP Address          Ending IP Address
-------------------          -----------------
110.80.1.1                   110.80.255.255
110.81.1.10                  110.81.1.255
200.11.15.1                  200.11.255.128
```

show.security.switchBinding

Syntax `switchBinding`

Purpose This command displays the switch binding configuration.

Parameters This command has no parameters.

Command Example

```
Root> show security switchBinding
```

Output The switch binding configuration data is displayed as a table that includes the following properties:

Switch Binding State	The switch binding state, which can have the following values: *Disabled* *Enabled and Restricting F_Ports* *Enabled and Restricting E_Ports* *Enabled and Restricting All Ports*
Switch Binding Membership List	The WWNs of the members of the active SBML.

Output Example The output from the *show.security.switchBinding* command appears as follows:

```
Switch Binding State:   Enabled and Restricting E Ports
00:11:22:33:44:55:66:77
88:99:AA:BB:CC:DD:EE:FF
11:55:35:45:24:78:98:FA
```

show.snmp.accessTable

Syntax `accessTable [index]`

Purpose This command displays the configured values for the Access Table.

Parameters This command has one optional parameter.

Command Example

```
Root> show snmp accessTable
```

Output Example The output from the *show.snmp.accessTable* command appears as follows:

```
SNMPv3 State:    Enabled
Index  Group Name
-----  ----------
1      group1
2
3
4      v1Group
5
6
7      v2Group
8
9
10     usmGroup
11     usmGroup
12
```

If the optional parameter, *index* is specified, the output from this command contains the following information:

SNMPv3 State	Indicates the status of SNMPv3 (Enabled or Disabled).
Index	Index of the access entry. Valid values are 1 to 6.
Group Name	The group name.

Security Model	The security model.
Security Level	The security level.
Read View	The read view name.
Write View	The write view name.
Notify View	The notify view name.

```
Config.SNMP> showAccessTable 1
Index:              1
Security Model:     Any
Security Level:     None
Group Name:         group1
Read View:          fcmgmt_3_1
Write View:         fceos
Notify View:        internet
```

NOTE: The command *config.snmp.showAccessTable* on page 22-97 has the functionality that is the same as this command.

show.snmp.targetTable

Syntax `tagetTable [index]`

Purpose This command displays the configured values for the Target Table.

Parameters This command has one optional parameter:

Command Example

```
Root> show snmp tagetTable
```

Output Example The output from the *show.snmp.targetTable* command appears as follows:

```
SNMPv3 State:    Enabled
Index  Target IP      UDP Port  Community                          MP Model
-----  -------------  --------  ---------------------------------  --------
1      172.19.16.169  162       public                             SNMPv1
2
3
4
5
6
```

If the optional parameter, *index*, is specified, the output from this command contains the following information:

SNMPv3 State	Indicates the status of SNMPv3 (Enabled or Disabled).
Index	The index number.
Target IP	The trap recipient IP.
UDP Port	The UDP port for the trap recipient
Community	The community name.
MP Model	The messaging model.
Security Name	The security name (username).
Security Model	The security model.
Security Level	The security level.

```
Config.SNMP> showTargetTable 1

Index:              1
Target IP:          172.19.16.169
UDP Port:           162
Community Name:     public
MP Model:           SNMPv1
Security Name:      user1
Security Model:     V1
Security Level:     No Authentication and No Privacy
```

show.snmp.userTable

Syntax `userTable [index]`

Purpose This command displays the users configured presently in the USM Table.

Parameters This command has no parameters.

Command Example `Root> show snmp userTable`

Output This command displays the following switch configuration data:

SNMPv3 State	Indicates the status of SNMPv3 (Enabled or Disabled).
Index	The index number.
Username	The username.
Auth Protocol	The Authentication Protocol.
Privacy Protocol	The Privacy Protocol.

Output Example The output from the *show.snmp.userTable* command appears as follows:

```
SNMPv3 State:    Enabled
Index  Username                          Auth Protocol      Privacy Protocol
-----  --------------------------------  -----------------  ----------------
1      User1                             No Authentication  No Privacy
2      User2                             HMAC-MD5           No Privacy
3      User3                             HMAC-SHA           DES
4
5
6
```

NOTE: This command and the command *config.snmp.showUserTable* on page 22-100 has the same functionality.

show.snmp.V3GroupTable

Syntax `V3GroupTable`

Purpose Displays the Security-to-Group table.

Parameters This command has no parameters.

Command Example

```
Root> show snmp v3GroupTable
```

Output This command displays the following switch configuration data:

SNMPv3 State	Indicates the status of SNMPv3 (Enabled or Disabled).
Index	The index number.
Username	The username.
Model	The security model.
Group Name	The group name.

Output Example The output from the *show.snmp.V3GroupTable* command appears as follows:

```
SNMPv3 State:    Enabled
Index  Username                          Model  Group Name
-----  --------------------------------  -----  ----------
1      User1                             V1     Group1
2
3
4
5
6
```

show.snmp.viewTable

Syntax `viewTable`

Purpose This command displays the values for the VACM views that are presently configured.

Parameters This command has no parameters.

Command Example `Root> show snmp viewTable`

Output This command displays the following switch configuration data:

View Name	The name of the view.
Type	The type of the view.
Object ID	The object ID.

Output Example The output from the *show.snmp.viewTable* command appears as follows:

```
View Name                          Type                Object ID
---------------------------------  ------------------  ---------
no_access                          View Excluded       .1.3.6.1
internet                           View Included       .1.3.6.1
management                         View Included       .1.3.6.1.2
experimental                       View Included       .1.3.6.1.3
private                            View Included       .1.3.6.1.4
snmpv3                             View Included       .1.3.6.1.6
fceos                              View Included       .1.3.6.1.4.1.289
fcmgmt_3_1                         View Included       .1.3.6.1.2.1.8888
fcmgmt_3_0                         View Included       .1.3.6.1.3.94
fcfe                               View Included       .1.3.6.1.3.42
system                             View Included       .1.3.6.1.2.1.1
ip                                 View Included       .1.3.6.1.2.1.4
```

NOTE: The command *config.snmp.showViewTable* on page 22-101 has functionality that is the same as this command.

show.snmp.config

Syntax `config`

Purpose This command displays the switch SNMP configuration.

Parameters This command has no parameters.

NOTE: The command *config.snmp.show* on page 2-96 has functionality that is identical to this command.

Command Example

```
Root> show snmp config
```

Output The switch configuration data is displayed as a table that includes the following properties:

SNMP Agent State	Displays the state of the SNMP agent. If it is disabled, then the SNMP state will not respond to any requests, nor will it produce any traps.
SNMPv3 State	The SNMPv3 state.
FA MIB Version Number	Version of the Fibre Alliance MIB (FA MIB) that the SNMP agent is configured to use.

Authentication Traps	Displays the state of authentication traps to be sent to SNMP management stations when unauthorized stations try to access SNMP information from the switch or director.
Index	Index in the community table.
Community. Name	Displays the community name.
WriteAuth	The write authorization state of the community.
Trap Recipient	Protocol description of the trap recipient.
UDP Port	UDP port number to which the switch or director will send traps for each recipient. This value is expressed in decimal and the default value is 162.

Output Example The output from the *show.snmp.config* command appears as follows:

```
SNMP Agent State:          Enabled
SNMPv3 State:              Disabled
FA MIB Version Number:     3.0
Authentication Traps:      Enabled
Index  Community Name                      WriteAuth  Trap Recipient   UDP Port
-----  ----------------------------------  ---------  ---------------  --------
1      CommunityName1                      Enabled    123.123.123.123  162
2      CommunityName2                      Enabled    10.25.25.10      144
3      CommunityName3                      Disabled   132.44.85.224    162
4      public                              Enabled                     162
5
6
```

show.switch

Syntax `switch`

Purpose This command displays the switch attributes.

Parameters This command has no parameters.

Command Example `Root> show switch`

Output The switch attributes data is displayed as a table that includes the following properties:

State	The state of the switch (for example, online or offline).
R_A_TOV	The resource allocation timeout value (R_A_TOV) as set in the *config.switch.raTOV* command.
E_D_TOV	The error detect timeout value (E_D_TOV) as set in the *config.switch.edTOV* command.
Preferred Domain Id	The domain ID as set in the *config.switch.prefDomainId* command.
Switch Priority	The switch priority as set in the *config.switch.priority* command. For more information, see *config.switch.priority* on page 2-111.
Speed	The switch speed as set in the config.switch.speed command. (This command is only applicable for the Intrepid 6064 and So this information is only available in intrepid 6064.) For more information, see *config.switch.speed* on page 2-114.
Rerouting Delay	The rerouting delay as set in the *config.switch.rerouteDelay* command. For more information, see *config.switch.rerouteDelay* on page 2-112.
Interop Mode	The interoperability mode as set in the *config.switch.interopMode* command. For more information, see *config.switch.interopMode* on page 2-109.
Active Domain Id	The active domain ID of the switch or director. This ID may or may not be the same as the preferred domain ID.
World Wide Name	The WWN for the switch or director.
Insistent Domain Id	Configured insistent domain ID state as set in the *config.switch.insistDomainId* command. For more information, see *config.switch.insistDomainId* on page 2-108.
Domain RSCN	Configured domain RSCN state as set in the *config.switch.domainRSCN* command. For more information, see *config.switch.domainRSCN* on page 2-107.
Zoning RSCN	Configured Zoning RSCN state as set in the *config.switch.zoningRSCN* command. For more information, see *config.switch.webState* on page 2-116.

FC Address Domain Id	The domain ID of the switch derived from the Fibre Channel Address.
Limited Fabric RSCN	When enabled, fabric RSCNs are suppressed after an IPL.
Isolate Zone RSCN	When set to fabric filtering, fabric RSCNs will only be sent to those members that need notification. When set to No Filtering, RSCNs will be set to everyone when zoning information changes.
Safe Zoning	Safe zoning state.
ISL FSPF Cost	The method for computing the FSPF cost for ISLs.
Web Enable	The enabled state of web.
API Enable	The enabled state of API.
API Management IP	IP address for of where the application that is managing the switch or director resides. If there is no application managing the switch, this will be the IP address of the switch.
HA Mode	The enabled state of HA mode.
Domain ID Offset	The configured Domain ID offset of the switch
Password Exp. Time	The configured password expiration time for the management interface users of the switch.

Output Example

The output from the *show.switch* command appears as follows:

Show> switch

```
State:                  Online
R_A_TOV:                20
E_D_TOV:                4
Preferred Domain Id:    1
Switch Priority:        Default
Speed:                  2 Gb/sec
Rerouting Delay:        Enabled
Interop Mode:           Open Fabric 1.0
Active Domain Id:       1
World Wide Name:        10:00:08:00:88:00:21:07
Insistent Domain Id:    Enabled
Domain RSCN:            Enabled
Zoning RSCN:            Disabled
FC Address Domain Id:   67 (hexadecimal)
Limited Fabric RSCN:    Disabled
Safe Zoning:            Enabled
ISL FSPF Cost:          By Port Speed
```

```
Web Enabled:              Enabled
API Enabled:              Enabled
HA Mode:                  Disalbed
API Management IP:        100.0.0.1
Domain ID offset:         96
Password Exp. Time:       365
```

show.system

Syntax `system`

Purpose This command displays a set of system attributes.

Parameters This command has no parameters.

Command Example `Root> show system`

Output The system attributes are displayed as a table that includes the following properties.

Name	The system name. For more information, see *config.system.name* on page 2-122.
Contact	The system contact as set in the *config.system.contact* command. For more information, see *config.syslog* on page 2-117.
Description	The system description. For more information, see *config.system.description* on page 2-121.
Location	The system description. For more information, see *config.system.location* on page 2-122.
Serial Number	The serial number for the system.
Type Number	The type number for the system.
Model Name	The model name for the system (for example, Sphereon 4500).
Model Number	The model number for the system. All products have the model number *001*, except 1 Gb sheet metal units, which are *002*.
EC Level	The engineering change level installed.

Firmware Version	The current firmware version installed.
Beaconing	The enabled state of unit beaconing (enabled or disabled) as set in the maint.system.beacon command.
Date/Time	The system date and time as set in the config.system.date command. For more information, see *config.system.date* on page 2-121.

Output Example The output from the *show.system* command appears as follows:

```
System Information
Name:              Joe's Switch
Description:       McDATA ED-6064 Fibre Channel Director
Contact:           Joe
Location:          Everywhere
Date/Time:         04/16/2001  10:34:01AM
Serial Number:     82420481
Type Number:       006064
Model Name:        ED-6064
Model Number:      001
EC Level:          1011231
Firmware Version: 04.01.00 Build 23
Beaconing:        Disabled
```

show.syslog

Syntax syslog

Purpose This command displays the syslog configuration

Parameters This command has no parameters.

Output The syslog configuration is shown as a table of properties. The following properties are displayed:

Log	The index number of the server.
State	Reports if syslog support is enabled.
Index	The index number of the server.
IP Address	The IP address of the server.
Facility	The facility level for the server. Values are *Local 0 - Local 7*.

Command Example

```
Root> Config Syslog show
Syslog State:    Disabled
Index  IP Address       Facility
-----  ---------------  --------
1      172.16.22.23     Local 0
2
3      180.77.66.55     Local 5

Log                          State
---------------------------  --------
Event Log                    Enabled
Open Trunking Re-Route Log   Disabled
Link Incident Log            Disabled
Security Log                 Enabled
Audit Log                    Enabled
Fabric Log                   Enabled
Embedded Port Frame Log      Disabled
```

show.thresholdAlerts.alerts

Syntax `alerts`

Purpose This command provides the name, type, and enabled state of each configured threshold alert, including both counter threshold alerts (CTAs) and throughput threshold alerts (TTAs).

Parameters This command has no parameters.

Command Example

```
Root> show thresholdAlerts alerts
```

Output The threshold alert data appears as a table that includes the following properties:

Name	The name of the threshold alert, truncated to 45 characters.	
Type	The trigger statistic or threshold type of the alert (abbreviated to 17 characters). These include:	
	Tx Util	TTA - Transmit Utilization.
	Rx Util	TTA - Receive Utilization.
	Tx/Rx Util	TTA - Transmit or Receive Utilization.
	Link Resets Sent	CTA - Link Resets Sent.
	Link Resets Received	CTA - Link Resets Received.

OLS Sent	CTA - OLS Sent.
OLS Received	CTA - OLS Received.
Link Failures	CTA - Link Failures.
Sync Losses	CTA - Sync Losses.
Signal Losses	CTA - Signal Losses.
Protocol Errors	CTA - Primitive Sequence Errors/Protocol Errors.
Invalid Tx Words	CTA - Invalid Tx Words.
CRC Errors	CTA - CRC Errors.
Discarded Frames	CTA - Discarded Frames.
Frames Too Short	CTA - Frames Too Short.
Delimiter Errors	CTA - Delimiter Errors.
Address ID Errors	CTA - Address ID Errors.
Cls2 BusiedFrms	CTA - Class 2 Busied Frames.
Cls2 RejectedFrms	CTA - Class 2 Rejected Frames.
Cls3 DiscardFrms	CTA - Class 3 Discarded Frames.
Phys Lnk Err Set	CTA - Physical Link Errors Summed Set.
Lnk Seq Cnt Set	CTA - Link Sequence Counts Summed Set.
Logic Lnk Err Set	CTA - Logical Link Errors Summed Set.
LIPS Detected	CTA - Loop Initialization Primitives detected (Sphereon 4300 and 4500 only).
LIPS Generated	CTA - Loop Initialization Primitives Generated (Sphereon 4300 and 4500 only).

State — The enabled state of the CTA, either *enabled* or *disabled*.

Output Example The output from the *show.thresholdAlerts.alerts* command appears as follows:

```
Name                                  Type                 State
------------------------------------  -----------------    --------
Throughput Threshold #1               Rx Util              Enable
Threshold for CRC                     CRC Errors           Disabled
Safety #2                             Logic Lnk Err Set    Enabled
Safety #1                             Cls2 BusiedFrms      Disabled
```

show.thresholdAlerts.log

Syntax `log [clear]`

Purpose This command shows the contents of the threshold alert log. This log shows all the threshold alerts that have been triggered, including both counter threshold alerts (CTAs) and throughput threshold alerts (TTAs).

ATTENTION! If the switch is restarted (as occurs during IPL, IML, configuration reset, feature key installation, or firmware load) or is power cycled, the information in the threshold alert log is lost.

Parameters This command has one parameter:

clear	This optional parameter causes all threshold log entries to be cleared.

Command Example `Root> show thresholdAlerts log`

Output The threshold alert log data appears as a table that includes the following properties:

Date/Time	The date and time of the alert.	
Name	The name of the threshold alert, truncated to 22 characters.	
Port	The type of threshold alert (CTAs only).	
Type	The trigger statistic or threshold type of the alert (abbreviated to 17 characters). These include:	
	Tx Util	TTA - Transmit Utilization.
	Rx Util	TTA - Receive Utilization.

Tx/Rx Util	TTA - Transmit or Receive Utilization.
Link Resets Sent	CTA - Link Resets Sent.
Link Resets Received	CTA - Link Resets Received.
OLS Sent	CTA - OLS Sent.
OLS Received	CTA - OLS Received.
Link Failures	CTA - Link Failures.
Sync Losses	CTA - Sync Losses.
Signal Losses	CTA - Signal Losses.
Protocol Errors	CTA - Primitive Sequence Errors/Protocol Errors.
Invalid Tx Words	CTA - Invalid Tx Words.
CRC Errors	CTA - CRC Errors.
Discarded Frames	CTA - Discarded Frames.
Frames Too Short	CTA - Frames Too Short.
Delimiter Errors	CTA - Delimiter Errors.
Address ID Errors	CTA - Address ID Errors.
Cls2 BusiedFrms	CTA - Class 2 Busied Frames.
Cls2 RejectedFrms	CTA - Class 2 Rejected Frames.
Cls3 DiscardFrms	CTA - Class 3 Discarded Frames.
Phys Lnk Err Set	CTA - Physical Link Errors Summed Set.
Lnk Seq Cnt Set	CTA - Link Sequence Counts Set.
Logic Lnk Err Set	CTA - Logical Link Error Set.
LIPS Detected	CTA - Loop Initialization Primitives Detected (Sphereon 4300 and 4500 only).

	LIPS Generated	CTA - Loop Initialization Primitives Generated (Sphereon 4300 and 4500 only).
Value	The increment or utilization value of the alert.	
Interval	The time interval of the alert.	

Output Example The output from the *show.thresholdAlerts.log* command appears as follows:

```
Date/Time          Name           Port   Type               Value  Int
-----------------  -------------  -----  -----------------  -----  ---
05/26/02  10:58A   CTA Alert #4   2      Cls3 DiscardFrms   250     10
05/24/02  12:01A   CTA Alert #4   2      Cls3 DiscardFrms   250     10
05/22/02  10:58A   My test CTA    43     CRC Errors         35      30
05/20/02  08:01P   TTA Test #3    2      Tx Util            85     120
03/01/02  02:58A   CTA Alert #1   130    CRC Errors         100     60
```

show.zoning

Syntax `zoning`

Purpose This command shows the zoning configuration saved on the fabric.

Parameters This command has no parameters.

Command Example `Root> show zoning`

Output The zoning configuration data is displayed as a table that includes the following properties.

Active ZoneSet	The enabled status, name, and member zones of the zone set.

Output Example The output from the *show.zoning* command appears as follows:

```
Active Zone Set
Default Zone Enabled:  False
ZoneSet:  TheUltimateZoneSet
    Zone:  TheUltimateZone
           ZoneMember: Domain 10, Port 6
           ZoneMember: Domain 15, Port 2
           ZoneMember: Domain 2, Port 63
           ZoneMember: 10:00:00:00:C9:22:9B:64
           ZoneMember: 10:00:00:00:C9:22:9B:BD
    Zone:  TheNotSoUltimateZone
           ZoneMember: 10:00:00:00:C9:22:9B:AB
           ZoneMember: 10:00:00:00:C9:22:9B:C6
           ZoneMember: 10:00:00:00:C9:22:9B:AB
    Zone:  TheNotUltimateAtAllZone
           ZoneMember: Domain 2, Port 63
```

A

Error Messages

This appendix lists and explains error messages for the Command Line Interface (CLI). Any error numbers that are not listed are reserved for future use.

The message that is returned is a string that includes the error number and the text of the message.

Message **Error 005: Busy**

Description The switch cannot process any requests at this time.

Action Re-submit the request.

Message **Error 007: Not Authorized**

Description You are unable to get write authorization to save the configuration.

Action Try again later.

Message **Error 008: Invalid Switch Name**

Description The value entered for the switch name is invalid.

Action The name for the director or switch may contain 0–24 characters. Enter a name with 0–24 characters and re-submit. If spaces are used, enclose the name in quotation marks.

Message **Error 009: Invalid Switch Description**

Description The value entered for the switch Description is invalid.

Action The description for the director or switch may contain 0–255 characters. Enter a description with 0–255 characters and re-submit. If spaces are used, enclose the description in quotation marks.

Message **Error 010: Invalid Switch Location**

Description The value entered for the switch location is invalid.

Action The location for the director or switch may contain 0–255 characters. Enter a location with 0–255 characters and re-submit. If spaces are used, enclose the location in quotation marks.

Message **Error 011: Invalid Switch Contact**

Description The value entered for the switch contact is invalid.

Action The contact for the director or switch may contain 0–255 characters. Enter a contact with 0–255 characters and re-submit. If spaces are used, enclose the contact in quotation marks.

Message **Error 012: Invalid Port Address**

Description The value entered for the port address is invalid.

Action Enter a valid port address.

Message **Error 013: Invalid Port Number**

Description The value entered for the port number is invalid.

Action Enter a port number within the range supported by your director or switch.

Message **Error 014: Invalid Port Name**

Description The value entered for the port name is invalid.

Action The port name for the individual port may contain 0–24 characters. Enter a name with 0–24 characters and re-submit. If spaces are used, enclose the name in quotation marks.

Message **Error 015: Invalid BB Credit**

Description The value entered for the buffer-to-buffer credit is invalid.

Action The buffer-to-buffer credit must be an integer in the range of 1–60.

Message **Error 016: Invalid R_A_TOV**

Description The value entered for the resource allocation time-out value is invalid.

Action The R_A_TOV is entered in tenths of a second and must be entered as an integer in the range 10–1200 (1 second to 120 seconds). The R_A_TOV value must be larger than the E_D_TOV value. Check to be sure that all conditions are met and re-submit.

Message **Error 017: Invalid E_D_TOV**

Description The value entered for the error detection time-out value is invalid.

Action The E_D_TOV is entered in tenths of a second and must be entered as an integer in the range 2–600 (0.2 second to 60 seconds). The E_D_TOV must be smaller than the R_A_TOV. Check to be sure that all conditions are met and re-submit.

Message **Error 018: Invalid TOV**

Description The E_D_TOV and R_A_TOV values are not compatible.

Action Enter a valid E_D_TOV / R_A_TOV combination. The E_D_TOV must be smaller than the R_A_TOV.

Message **Error 020: Invalid Preferred Domain ID**

Description The value entered for the preferred domain ID for the director or switch is invalid.

Action The preferred domain ID must be an integer in the range 1–31. Enter an appropriate value and re-submit.

Message **Error 021: Invalid Switch Priority**

Description The value entered for the switch priority is invalid.

Action The switch priority entered for the director or switch must be one of the following: principal, neverprincipal, or default. Enter an appropriate value and re-submit. (Refer to the description of the command in *config.switch.priority* on page 2-111.)

Message **Error 029: Invalid Gateway Address**

Description The value entered for the gateway address is invalid.

Action The new gateway address for the Ethernet interface must be entered in dotted decimal format (e.g. 0.0.0.0). Enter an appropriate gateway address and re-submit.

Message **Error 030: Invalid IP Address**

Description The value entered for the IP Address is invalid.

Action The new IP address for the Ethernet interface must be entered in dotted decimal format (e.g. 10.0.0.0). Enter an appropriate IP address and re-submit.

Message **Error 031: Invalid Subnet Mask**

Description The value entered for the subnet mask is invalid.

Action The new subnet mask for the Ethernet interface must be entered in dotted decimal format (e.g. 255.0.0.0). Enter an appropriate subnet mask and re-submit.

Message **Error 032: Invalid SNMP Community Name**

Description The value entered for the SNMP community name is invalid.

Action The community name must not exceed 32 characters in length. Duplicate community names are allowed, but corresponding write authorizations must match. Enter an appropriate SNMP community name and re-submit.

Message **Error 033: Invalid SNMP Trap Address**

Description The value entered for the SNMP trap address is invalid.

Action The new SNMP trap address for the SNMP interface must be entered in dotted decimal format (e.g. 10.0.0.0). Enter an appropriate SNMP trap address and re-submit.

Message **Error 034: Duplicate Community Names Require Identical Write Authorization**

Description Two or more community names have been recognized as being identical, but their corresponding write authorizations are not identical.

Action Enter unique SNMP community names or force write authorizations for duplicate community names to be identical and re-submit.

Message **Error 036: Port Already Swapped**

Description The port has already been swapped with another port and cannot be swapped again.

Action Unswap the port before swapping it with another port.

Message **Error 037: Invalid Month**

Description The value of the month entered for the new system date is invalid.

Action The format of the date parameter must be mm:dd:yyyy or mm/dd/yyyy. The month must contain an integer in the range 1–12. Enter an appropriate date and re-submit.

Message **Error 038: Invalid Day**

Description The value of the day entered for the new system date is invalid.

Action The format of the date parameter must be mm:dd:yyyy or mm/dd/yyyy. The day must contain an integer in the range 1–31. Enter an appropriate date and re-submit.

Message **Error 039: Invalid Year**

Description The value of the year entered for the new system date is invalid.

Action The format of the date parameter must be mm:dd:yyyy or mm/dd/yyyy. The year must contain an integer greater than 1980. Enter an appropriate date and re-submit.

Message **Error 040: Invalid Hour**

Description The value of the hour entered for the new system time is invalid.

Action The format of the time parameter must be hh:mm:ss. The hour can contain an integer in the range 0–23. Enter an appropriate time and re-submit.

Message **Error 041: Invalid Minute**

Description The value of the minute entered for the new system time is invalid.

Action The format of the time parameter must be hh:mm:ss. The minute can contain an integer in the range 0–59. Enter an appropriate time and re-submit.

Message **Error 042: Invalid Second**

Description The value of the second entered for the new system time is invalid.

Action The format of the time parameter must be hh:mm:ss. The second can contain an integer in the range 0–59. Enter an appropriate time and re-submit.

Message **Error 044: Max SNMP Communities Defined**

Description A new SNMP community may not be defined without removing an existing community from the list.

Action A total of 6 communities may be defined for SNMP. A new community can be added only after a current community is removed. Make the appropriate changes and re-submit.

Message **Error 045: Not Allowed While Switch Online**

Description The entered command requires that the director or switch be set offline.

Action Set the switch offline and re-submit the command.

Message **Error 047: LIC install Active**

Description Cannot perform the specified action while a firmware download is in progress.

Action Wait until the firmware download is complete and try again.

Message **Error 049: Invalid RADIUS Server UDP Port Number**

Description The RADIUS server UDP port number entered is invalid.

Action Enter a valid UDP port. Valid values are 1 to 65535.

Message **Error 050: Invalid RADIUS Server Timeout Value**

Description The RADIUS server Timeout value entered is invalid.

Action Enter a valid Timeout value. Valid values are 1 to 1000.

Message **Error 051: Invalid RADIUS Server Transmit Attempts Value**

Description The RADIUS server Retransmit value entered is invalid.

Action Enter a valid Retransmit value. Valid values are 1 to 100.

Message **Error 052: Invalid RADIUS Server Deadtime Value**

Description The RADIUS server Deadtime entered is invalid.

Action Enter a valid Deadtime value. Valid values are 0 to 1440.

Message **Error 053: Invalid RADIUS Key**

Description The RADIUS key entered is invalid.

Action Enter a valid RADIUS key. Key length must be no more than 256 characters.

Message **Error 054: Buffer Limit Exceeded**

Description The total number of BB Credits configured cannot exceed the BB Credit buffer pool limit.

Action Configure the total number of BB Credits for this switch to be less than or equal to the buffer pool limit.

Message **Error 055: Invalid Zone Name**

Description The value entered for the zone name is invalid.

Action The zone name must be unique and contain 1–64 characters. The valid character set for the zone name can be found under *config.zoning.renameZoneSet* on page 2-130. Make the appropriate changes to the zone name and re-submit.

Message **Error 057: Duplicate Zone**

Description Two or more zone names in the zone set are identical.

Action All zone names must be unique. Make the appropriate changes and re-submit.

Message **Error 059: Zone Name in Use**

Description Two or more zone names in the zone set are identical.

Action All zone names must be unique. Make the appropriate changes and re-submit.

Message **Error 060: Invalid Number of Zone Members**

Description The entered command tried to add more zone members than the zone can hold.

Action Reduce the number of zone members in the zone and re-submit the command.

Message **Error 061: Invalid Zone Member Type**

Description A zone member was entered that is neither a WWN nor a Domain, Port pair.

Action Zone members must be expressed in WWN format or as a Domain, Port pair. Make the appropriate changes and re-submit. For more information, see *config.zoning.clearZone* on page 2-127 and *config.zoning.addPortMem* on page 2-125.

Message **Error 062: Invalid Zone Set Name**

Description The value entered for the zone set name is invalid.

Action The zone set name must be contain 1–64 characters. The valid character set for the zone name can be found in *config.zoning.renameZoneSet* on page 2-130. Make the appropriate changes to the zone set name and re-submit.

Message **Error 064: Configuration changes have been limited to the API interface**

Description The API interface has restricted this interface from making configuration changes.

Action To make configuration changes from this interface, the API interface will need to update to allow this interface to make changes.

Message **Error 065: Cannot remove the last CLI user with Administrator rights**

Description There has to be at least one CLI user with Administrator rights.

Action To remove this user, add another CLI Administrator and then delete this user.

Message **Error 068: The Switch IP Access Control List is Full**

Description The list being activated has an invalid number of IP pairs.

Action Make sure there is at least one IP address in the Access Control List.

Message **Error 069: Duplicate Port Name**

Description Two or more port names are identical.

Action Port names must be unique. Make appropriate changes and re-submit. For more information, see *config.port.name* on page 2-32.

Message **Error 070: Invalid FRU Type**

Description The requested FRU does not exist on this product.

Action Consult the installation/service manual for this product to find appropriate FRU names.

Message **Error 071: FRU Not Installed**

Description The requested FRU is not installed.

Action Consult the installation/service manual for this product for appropriate action.

Message **Error 072: No Backup FRU**

Description The FRU swap cannot be performed because a backup FRU is not installed.

Action Insert a backup FRU and re-submit the request or consult the installation/service manual for this product for appropriate action.

Message **Error 073: Port Not Installed**

Description The port specified is not installed on this product.

Action Consult the installation/service manual on installing a port optic.

Message **Error 074: Invalid Number of Zones**

Description The specified zone set contains less than one zone or more than the maximum number of zones allowed for this product.

Action A zone set must contain at least one zone to be considered valid. Add or remove zones accordingly to meet specified requirements.

Message **Error 075: Invalid Zone Set Size**

Description The zone set entered exceeds switch NVRAM limitations.

Action Reduce the size of the zone set to meet specified requirements. This can be a reduction in the number of zones in the zone set, a reduction of members in a zone, or a reduction of zone name lengths.

Message **Error 076: Invalid Number of Unique Zone Members**

Description The zone entered contains more than the maximum number of zone members allowed per zone set for this product.

Action Reduce the number of members in one or more zones and re-submit the command.

Message **Error 077: Not Allowed While Port Is Failed**

Description The port selected is in a failed or inactive state, or is in need of service.

Action Consult the installation/service manual for appropriate action.

Message **Error 078: System Error Light On**

Description This unit is not able to beacon because the system error light is on.

Action You must clear the system error light before unit beaconing may be enabled. Consult the installation/service manual for appropriate action.

Message **Error 079: FRU Failed**

Description The specified FRU has failed.

Action Consult the installation/service manual for appropriate action.

Message **Error 081: Default Zone Enabled**

Description The request cannot be completed because the default zone is enabled.

Action Disable the default zone and re-submit the command.

Message **Error 082: Invalid Interop Mode**

Description The value entered for the interoperability mode is not valid.

Action The interoperability mode for the director or switch must be mcdata (McDATA Fabric 1.0) or open (Open Fabric 1.0). Make the appropriate changes and re-submit the command.

Message **Error 083: Not Allowed in Open Fabric Mode**

Description This request cannot be completed while this switch is operating in Open Fabric 1.0 mode.

Action Configure the interop mode to McDATA Fabric 1.0 mode.

Message **Error 088: Invalid Feature Key Length**

Description The feature key installed is longer than the maximum length allowed.

Action Be sure that the key has been entered correctly and re-submit. Contact your sales representative with any further problems.

Message **Error 090: Invalid Port Type**

Description The port type configured is invalid.

Action A port may be configured to be an eport, gport, or fport. Be sure the port is configured appropriately and re-submit the command.

Message **Error 091: E_Port Type Configured**

Description Ports are not allowed to be configured as E_Ports in S/390 mode.

Action Configure the port as either a fport or gport and resubmit the command.

Message **Error 092: Not Allowed While Port Is Unblocked**

Description The port must be blocked to complete this request.

Action Block the port and re-submit the command.

Message **Error 093: Not Allowed While FICON MS Is Installed**

Description This request cannot be completed because FICON Management Server is installed.

Action This operation is not supported. No action necessary.

Message **Error 094: Invalid Feature Combination**

Description The features requested cannot be installed at the same time on one switch or director.

Action Contact your sales representative.

Message **Error 099: Preferred Domain ID Cannot Be Zero**

Description This product cannot be configured to have a preferred domain ID equal to zero (0).

Action Ensure that the ID is expressed as an integer in the range 1–31 and re-submit.

Message **Error 101: Command Not Supported on This Product**

Description This product does not support the requested command.

Action Command not supported. No action necessary.

Message **Error 102: Switch Not Operational**

Description The request cannot be completed because the switch is not operational.

Action Consult the installation/service manual and contact your service representative.

Message **Error 103: Port Diagnostic In Progress**

Description The request cannot be completed because a port diagnostic is running.

Action Wait for the diagnostic to complete.

Message **Error 104: System Diagnostic In Progress**

Description The request cannot be completed because a system diagnostic is running.

Action Wait for the diagnostic to complete.

Message **Error 105: Max Threshold Definitions Reached**

Description The maximum number of total threshold alerts has already been reached.

Action Remove a threshold alert before adding the new threshold alert. A total of 16 counter and throughput threshold alerts is allowed.

Message **Error 106: Invalid Threshold Scope**

Description The scope of a threshold alert is not set to a valid state before the user activates an alert.

Action Set the scope of the threshold alert, then try to activate the alert.

Message **Error 107: Invalid Threshold State**

Description The scope of a threshold alert must be set before the user activates an alert.

Action Set the scope of the threshold alert, then try to activate the alert.

Message **Error 108: Invalid TTA Type**

Description The type of the throughput threshold alert has not been set.

Action Set the type of the TTA, then try to activate the alert.

Message **Error 109: Invalid CTA Type**

Description The type of the counter threshold alert has not been set.

Action Set the type of the CTA, then try to activate the alert.

Message **Error 110: Invalid Percent Utilization**

Description The type of the throughput threshold alert has not been set.

Action Set the type of the TTA, then try to activate the alert.

Message **Error 111: Invalid Threshold Type**

Description The type of the threshold alert is not valid.

Action Configure the type of the throughput threshold alert to one of the types found in the enumerated table for TTAs.

Message **Error 112: No Threshold Definition Given**

Description The threshold value for the alert was not configured before the user attempted to activate the alert.

Action Set the threshold value, then try to activate the alert.

Message **Error 115: Invalid Switch Speed**

Description The request cannot be completed because the switch is not capable of operating at the configured speed.

Action Consult the installation/service manual to determine the speed capabilities of your product.

Message **Error 116: Switch Not Capable of 2 Gb/sec**

Description The request cannot be completed because the switch is not capable of operating at 2 Gb/sec.

Action Consult the installation/service manual to determine the speed capabilities of your product.

Message **Error 117: Port Speeds Cannot be Set at Higher Data Rate than Switch Speed**

Description This request cannot be completed because the requested port speed is faster than the currently-configured switch speed.

Action The switch speed should first be configured to accommodate changes in the configured port speed. The ports cannot operate at a faster rate than the switch, itself. Update the switch speed and re-submit the request. For more information, see *config.switch.speed* on page 2-114 and *config.port.show* on page 2-34.

Message **Error 118: Invalid Port Speed**

Description This request cannot be completed because the requested port speed is not recognized for this product.

Action Port speeds may be set to 1 Gb/s or 2 Gb/s. Update the port speed and re-submit the request.

Message **Error 119: Switch Speed Not 2 Gb/sec**

Description This request cannot be completed because the switch speed has not been set to 2 Gb/s.

Action The switch speed must be set to 2 Gb/s in order to accommodate a port speed of 2 Gb/s. Update the switch speed and re-submit the request.

Message **Error 121: Invalid Credit Starvation Threshold**

Description An invalid credit starvation threshold has been entered.

Action Submit the request with a valid value. The credit starvation threshold must be in the range 1-99.

Message **Error 122: Invalid Port Congestion Threshold**

Description An invalid port congestion threshold has been entered.

Action Submit the request with a valid value. The port congestion threshold must be in the range 1-99.

Message **Error 134: Invalid Membership List**

Description Generic message to indicate a problem in either the switch binding or fabric binding membership list.

Action Be sure that the membership list submitted does not isolate a switch already in the fabric. If this is not the case, the user needs to be aware of all fabric security rules and make sure that the list submitted adheres appropriately.

Message **Error 135: Invalid Number of Fabric Membership List Entries**

Description The number of fabric members submitted exceeds the maximum allowable entries of 31.

Action The number of entries in the fabric membership list is limited to the total number of domain IDs available to the fabric. Make sure that the list (including the managed switch) contains no more than 31 entries.

Message **Error 136: Invalid Number of Switch Binding Membership List Entries**

Description The number of switch members submitted exceeds the maximum allowable entries of 256.

Action The number of entries in the Switch Binding Membership List is limited to 256. Make sure that the list (including the managed switch) contains no more than 256 entries.

Message **Error 137: Invalid Fabric Binding State**

Description The fabric binding state submitted is not recognized by the CLI.

Action The fabric binding state must be set to either "inactive" or "restrict." See *config.security.fabricBinding* on page 2-61 for clarification on these states.

Message **Error 138: Invalid Switch Binding State**

Description The switch binding state submitted is not recognized by the CLI.

Action The switch binding state must be set to one of the following: *disable*, *erestrict*, *frestrict*, or *allrestrict*. See *config.security.switchBinding* on page 2-76 for clarification on these states.

Message **Error 139: Insistent Domain ID's Must Be Enabled When Fabric Binding Active**

Description The user attempted to disable insistent domain IDs while fabric binding was active.

Action Insistent domain IDs must remain enabled while fabric binding is active. If fabric binding is set to inactive, the insistent domain ID state may be changed. It should be noted, however, that this can be disruptive to the fabric.

Message **Error 140: Invalid Insistent Domain ID State**

Description The request cannot be completed because an invalid insistent domain ID state has been submitted.

Action The insistent domain ID state must be set to either *enable* or *disable*. For more information, see *config.switch.insistDomainId* on page 2-108.

Message **Error 141: Invalid Enterprise Fabric Mode**

Description The request cannot be completed because an invalid enterprise fabric mode has been submitted.

Action The enterprise fabric mode must be set to either *activate* or *deactivate*. For more information, see *config.enterpriseFabMode.setState* on page 2-8.

Message **Error 142: Invalid Domain RSCN State**

Description The request cannot be completed because an invalid domain RSCN state has been submitted.

Action The domain RSCN state must be set to either *enable* or *disable*. For more information, see *config.switch.domainRSCN* on page 2-107.

Message **Error 143: Domain RSCNs Must Be Enabled When Enterprise Fabric Mode Active**

Description The user attempted to disable domain RSCN's while enterprise fabric mode was active.

Action Domain RSCNs must remain enabled while the enterprise fabric mode is active. If enterprise fabric mode is set to inactive, the domain RSCN state may be changed. It should be noted, however, that this can be disruptive to the fabric.

Message **Error 144: The SANtegrity Feature Has Not Been Installed**

Description The user attempted to activate a change to the fabric security configuration without first installing the SANtegrity feature key.

Action If this key has not been installed, contact your sales representative.

Message **Error 146: Fabric Binding May Not Be Deactivated While Enterprise Fabric Mode Active**

Description The user attempted to deactivate fabric binding while enterprise fabric mode was active.

Action Fabric binding must be active while operating in enterprise fabric mode. The fabric binding state may be changed if enterprise fabric mode is deactivated. It should be noted, however, that this can be disruptive to the fabric.

Message **Error 148: Not Allowed While Switch Offline**

Description The switch must be online to complete this request.

Action Change the state of the switch to ONLINE and re-submit the request.

Message **Error 149: Not Allowed While Enterprise Fabric Mode Enabled and Switch Active**

Description The request cannot be completed while the switch is online and enterprise fabric mode is Active.

Action This operation will be valid if the switch state is set to offline and enterprise fabric mode to inactive. It should be noted, however, that this can be disruptive to the fabric.

Message **Error 151: Invalid Open Systems Management Server State**

Description The request cannot be completed because the OSMS state submitted is invalid.

Action The OSMS state may be set to either *enable* or *disable*. For more information, see *config.features.openSysMS* on page 2-11.

Message **Error 152: Invalid FICON Management Server State**

Description The request cannot be completed because the FICON MS state submitted is invalid.

Action The FICON MS state may be set to either *enable* or *disable*. For more information, see *config.ficonMS.setMIHPTO* on page 2-22.

Message **Error 153: Feature Key Not Installed**

Description The request cannot be completed because the required feature key has not been installed to the firmware.

Action Contact your sales representative.

Message **Error 154: Invalid Membership List WWN**

Description The request cannot be completed because the WWN does not exist in the switch binding membership list.

Action Make sure that the WWN deleted matches the WWN in the Switch Binding Membership List. Make appropriate changes and re-submit the request.

Message **Error 155: Cannot Remove Active Member From List**

Description This member cannot be removed from the fabric security list because it is currently logged in.

Action Fabric security rules prohibit any device or switch from being isolated from the fabric via a membership list change. If it is truly the intention of the user to remove the device in question from the membership list, then there are several approaches to take. This request may be completed most non-disruptively by blocking the port (or physically removing the device from the managed switch) to which this device is attached and resubmitting the request.

Message **Error 156: Cannot Complete While Switch is Online and Fabric Binding Active**

Description The switch must be offline and Fabric Binding must be inactive before this feature can be disabled.

Action Deactivating this feature can be disruptive to Fabric operations. Take the switch offline and make sure deactivate fabric binding before disabling this feature.

Message **Error 157: Access Control List is Disabled**

Description The switch must be offline and Fabric Binding must be inactive before this feature can be disabled.

Action Deactivating this feature can be disruptive to Fabric operations. Take the switch offline and deactivate fabric binding before disabling this feature.

Message **Error 158: Invalid Switch IP Access Control List IP Address Range**

Description The pair of IP addresses are invalid and cannot be added to the list.

Action Make sure the IP addresses are valid and the first IP is lower than the second.

Message **Error 159: Invalid IP Access Control List Pairs Count Value**

Description The list being activated has an invalid number of IP pairs.

Action Make sure there is at least one IP address in the Access Control List.

Message **Error 161: The Switch IP Access Control List is Empty**

Description The management interface IP address is not in the list.

Action The management IP must be in the list or the current connection would be lost.

Message **Error 162: List is full**

Description There is no more room for new entries in the list.

Action Remove a different entry and try again.

Message **Error 163: FICON MS feature key must be installed**

Description The command is not available without the FICON MS feature key.

Action Install the FICON MS feature key.

Message **Error 164: FICON CUP Zoning feature key must be uninstalled**

Description The operation cannot be completed with the FICON CUP Zoning key installed.

Action Remove the FICON CUP Zoning feature key.

Message **Error 165: CUP Zoning feature key must be installed**

Description The command is not available without the FICON CUP Zoning feature key.

Action Install the FICON CUP zoning feature key.

Message **Error 166: CUP Zoning feature must be enabled**

Description The command cannot be completed with the CUP Zoning feature enabled.

Action Enable FICON CUP Zoning.

Message **Error 167: Diagnostics can not be run on inactive port**

Description The port is in the inactive state and diagnostics cannot be run.

Action The port state must change out of the inactive state.

Message **Error 168: Duplicate member in the list**

Description The member is already in the list.

Action Duplicate members are not allowed in the list.

Message **Error 169: Cannot enable CNT feature**

Description CNT support is in the wrong state.

Action The enabled state for CNT support must be changed.

Message **Error 170: Duplicate IP Address range in the switch IP Access Control List**

Description Duplicate IP address pairs are not allowed in the Access Control List.

Action This command is redundant, the member already exists in the list.

Message **Error 171: Invalid username**

Description The username is invalid.

Action Enter a unique username using only the allowed characters and proper length.

Message **Error 172: Invalid list size**

Description The number of entries in the list is invalid.

Action Make sure the list has at least one entry.

Message **Error 173: Invalid value**

Description The value being entered is invalid.

Action Enter a valid value.

Message **Error 174: Invalid list data**

Description The list data is invalid.

Action Correct the list to make it a valid list.

Message **Error 175: Invalid list index (the user should not see this error)**

Description The index in the list is incorrect.

Action Correct the index.

Message **Error 176: Entry not found in the list**

Description The desired entry in the list does not exist.

Action Make sure the desired entry is in the list and it is being typed correctly.

Message **Error 177: Cannot remove the last Web user with Administrator rights**

Description At least one Administrator user must exist for each management interface.

Action Add a new Administrator and then try again.

Message **Error 178: Invalid password**

Description The entered password is invalid.

Action Enter a password using valid characters and a proper length.

Message **Error 179: Insistent Domain IDs must be enabled**

Description To complete this command, Insistent Domain IDs must be enabled.

Action Enabled Insistent Domain IDs.

Message **Error 180: Too many management interface users**

Description Only 25 management users can be added to the user database.

Action Remove other management users in order to make room for a new one.

Message **Error 181: Preferred path must be disabled**

Description The Preferred Path feature must be disabled.

Action Disable the Preferred Path feature.

Message **Error 182: Invalid fencing policy state**

Description The current fencing state is invalid.

Action Enter a valid fencing state.

Message **Error 183: Invalid Enable Status**

Description The enable status is invalid.

Action Enter a valid enable status.

Message **Error 184: Invalid Fencing Policy Time Period**

Description The entered period is invalid.

Action Enter a valid period.

Message **Error 185: Invalid Limit Value for this Fencing Policy Type**

Description The entered limit is invalid.

Action Enter a valid limit.

Message **Error 186: Cannot Block this Port**

Description Port is not blockable.

Action Enter a valid port number.

Message **Error 187: Cannot Beacon this Port**

Description Cannot enable beaconing on this port.

Action Enter a valid port number.

Message **Error 188: Port Swap Classification is not Identical**

Description Cannot swap ports because the port swap classification is not identical.

Action Swap different ports or install a FRU with the same port classification.

Message **Error 189: Invalid Fencing Policy Type**

Description Invalid fencing policy type.

Action Enter a valid fencing policy type.

Message **Error 190: Invalid Fencing Policy Port Type**

Description Invalid fencing policy port type.

Action Enter a valid port or port type.

Message **Error 191: Max Fencing Policy Definitions Reached**

Description A new port fencing policy may not be defined without removing an existing port fencing policy from the list.

Action A total of 14 policies may be defined for port fencing. A new policy can be added only after a current policy is removed. Make the appropriate changes and re-submit.

Message **Error 192: Invalid Fencing Policy Name**

Description Port fencing name is invalid.

Action Configure a valid port fencing name.

Message **Error 193: Cannot Modify an Enabled Fencing Policy**

Description The policy is cannot be modified while it is enabled.

Action Disabled the policy before modifying.

Message **Error 194: Cannot enable two policies of the same type that contain the same ports**

Description Two policies of the same type cannot be enabled if they have ports that are in both lists.

Action Make sure the policy that is being enabled doesn't have the same port number as a policy that is enabled

Message **Error 195: Cannot enable two policies of the same type that contain same port scope**

Description Two policies of the same type cannot be enabled if they have the same port type.

Action Make sure the policy that is being enabled doesn't have the same port type as a policy that is enabled.

Message **Error 196: Cannot enable two policies of the same type that contain default scope**

Description Two policies of the same type cannot be enabled if they are both using the default ports.

Action Enable only one policy that is using the default ports.

Message **Error 197: Port list contains no ports**

Description The policy port list must contain ports or a port scope.

Action Add ports or a port scope to the policy.

Message **Error 198: Duplicate Authentication Name**

Description Authentication names must be unique.

Action Configure a unique authentication name.

Message **Error 201: Change Authorization Request Failed**

Description The switch did not accept the request to make a change to NVRAM.

Action Be sure all parameters have been entered correctly and re-submit. Contact your service representative with further problems.

Message **Error 202: Invalid Change Authorization ID**

Description The switch will not accept a change request from this particular client.

Action Be sure all parameters have been entered correctly and re-submit. Contact your service representative with further problems.

Message **Error 203: Another Client Has Change Authorization**

Description Another user is currently making changes to this switch.

Action Be sure all parameters have been entered correctly and re-submit.

Message **Error 207: Change Request Failed**

Description The switch did not accept the request.

Action Be sure all parameters have been entered correctly and re-submit. Contact your service representative with further problems.

Message **Error 208: Change Request Timed Out**

Description Authorization time to make NVRAM changes has expired.

Action Be sure all parameters have been entered correctly and re-submit. Contact your service representative with further problems.

Message **Error 209: Change Request Aborted**

Description The switch did not accept the request.

Action Be sure all parameters have been entered correctly and re-submit. Contact your service representative with further problems.

Message **Error 210: Busy Processing Another Request**

Description A different switch in the Fabric was busy processing another request and could not complete the command.

Action Be sure all parameters have been entered correctly and re-submit. Contact your service representative with continued problems.

Message **Error 211: Duplicate Zone**

Description Two or more zone names in the local zone set are identical.

Action All zone names must be unique. Make the appropriate changes and re-submit.

Message **Error 212: Duplicate Zone Member**

Description A member was added that already exists in the zone.

Action No action necessary.

Message **Error 213: Number of Zones Is Zero**

Description You are attempting to activate and empty zone set.

Action The zone set must have at least one zone to be considered valid. Add a valid zone to the zone set and re-submit.

Message **Error 214: A Zone Contains Zero Members**

Description You are attempting to activate a zone set that contains at least one zone with zero members.

Action Each zone in the zone set must contain at least one member. Add a valid member to the empty zone and re-submit.

Message **Error 215: Zone Set Size Exceeded**

Description The local work area zone set has outgrown the size limitations imposed by the Command Line Interface.

Action Reduce the size of the zone set to meet CLI requirements. This can be a reduction in the number of zones in the zone set, a reduction of members in a zone, or a reduction of zone name lengths.

Message **Error 216: No Attached Nodes Exist**

Description There are no attached nodes.

Action To add more members, attach more devices to the switch or add the members by WWN or Domain ID and port.

Message **Error 217: All Attached Nodes are in the Zone**

Description All the attached nodes are already in the zone.

Action To add more members, attach more devices to the switch or add the members by WWN or Domain ID and port.

Message **Error 218: Invalid Port Number**

Description The value entered for the port number is invalid

Action Enter a port number within the range supported by your director or switch.

Message **Error 219: Invalid Port Type**

Description The port type configured is invalid.

Action A port may be configured to be an eport, gport, or fport. Be sure the port is configured appropriately and re-submit the command. On the Sphereon 4300 and Sphereon 4500 only, fxport and gxport types are also supported. On the Sphereon 4300, the Fabric Capable feature must be installed to configure a E_Port, G_Port, or Gx_Port.

Message **Error 220: Cannot run diagnostics while a device is logged in to the port**

Description Diagnostics cannot be run while a device is logged into the port.

Action Block the port to run diagnostics.

Message **Error 221: Cannot run diagnostics on an active E Port**

Description Diagnostics cannot be run on an active E Port.

Action Block the port to run diagnostics.

Message **Error 222: Invalid SNMP Community Index**

Description The value entered for the SNMP community index is invalid.

Action The SNMP community index must be an integer in the range 1–6. Make the appropriate changes and re-submit the command.

Message **Error 223: Unknown Error**

Description The switch did not accept the request.

Action Contact your service representative.

Message **Error 224: Invalid Argument**

Description One or more parameters are invalid for this command.

Action Consult this manual (Chapter 2, CLI Commands) for appropriate parameter names. Parameters must be typed exactly to specification to be recognized correctly by the CLI.

Message **Error 226: Argument Is Too Long**

Description One or more parameters are invalid for this command.

Action For the appropriate parameters, see the section of the manual that corresponds to the attempted command. Parameters must be typed exactly to specification to be recognized correctly by the CLI.

Message **Error 227: Invalid SNMP Community Name**

Description The value entered for the SNMP community name is invalid.

Action The community name must not exceed 32 characters in length. Duplicate community names are allowed, but corresponding write authorizations must match. Enter an appropriate SNMP community name and re-submit.

Message **Error 228: Invalid Write Authorization Argument**

Description The writeAuthorization parameter does not contain a valid value.

Action Parameters must be typed exactly to specification to be recognized correctly by the CLI. For more information, see *config.security.ssl.setAPIState* on page 2-82.

Message **Error 229: Invalid UDP Port Number**

Description The udpPortNum parameter does not contain a valid value.

Action Parameters must be typed exactly to specification to be recognized correctly by the CLI. For more information, see *config.switch.insistDomainId* on page 2-108.

Message **Error 230: Invalid WWN**

Description The wwn parameter does not contain a valid value.

Action For the appropriate parameters, see the section of the manual that corresponds to the attempted command. Parameters must be typed exactly to specification to be recognized correctly by the CLI.

Message **Error 231: Invalid Port number**

Description The portNum parameter does not contain a valid value.

Action For the appropriate parameters, see the section of the manual that corresponds to the attempted command. Parameters must be typed exactly to specification to be recognized correctly by the CLI.

Message **Error 232: Invalid Domain ID**

Description The domainID parameter does not contain a valid value.

Action For the appropriate parameters, see the section of the manual that corresponds to the attempted command. Parameters must be typed exactly to specification to be recognized correctly by the CLI.

Message **Error 233: Invalid Member**

Description The zone member added is not valid.

Action For the appropriate parameters, see the section of the manual that corresponds to the attempted command. Parameters must be typed exactly to specification to be recognized correctly by the CLI.

Message **Error 234: Invalid Command**

Description The CLI cannot associate an action with the submitted command. The command may be misspelled, required parameters may be missing, or the request may not be applicable to the branch of the CLI tree from which it was submitted.

Action Consult the documentation for the command to be sure this command was entered correctly, all parameters are valid and present, and that the syntax is correct.

Message **Error 235: Unrecognized Command**

Description The CLI does not recognize the command and cannot perform the help '?' command as requested.

Action The entered command is misspelled or the prompt is not positioned at the right place in the CLI command tree for this command. For the appropriate syntax, see the section of the manual that corresponds to the attempted command.

Message **Error 236: Ambiguous Command**

Description The CLI does not recognize the command issued.

Action The CLI cannot interpret the command because a unique match cannot be identified. For the appropriate syntax, see the section of the

manual that corresponds to the attempted command. Enter the complete command and re-submit.

Message **Error 237: Invalid Zoning Database**

Description There was an unidentifiable problem in the local zone set work area.

Action Verify all parameters are entered correctly and re-submit. Otherwise, the pending zone set should be cleared and reconstructed.

Message **Error 238: Invalid Feature Key**

Description The feature key entered is invalid.

Action Verify that the feature key was entered correctly and re-submit. Contact your service representative with further difficulties.

Message **Error 239: Fabric binding entry not found**

Description The user requested to remove a fabric binding entry that is not in the pending fabric membership list.

Action Verify that the correct entry (both WWN and Domain ID) is being requested for removal from the list and re-submit the request.

Message **Error 240: Duplicate fabric binding member**

Description The user requested to add an entry to the fabric binding list that is already a member of the list.

Action Verify that the correct entry (both WWN and Domain ID) is being requested for addition to the list and re-submit the request.

Message **Error 241: Comma-delimited mode must be active**

Description Comma-delimited mode must be active to execute this command

Action Some commands require that comma-delimited mode be active (e.g. show.nameserverExt). Enable comma-delimited mode and re-issue the command.

Message **Error 244: Not allowed when Enterprise Fabric Mode is Active and Switch is Online**

Description This operation is not allowed while the switch is in Enterprise Fabric Mode and the switch is Online.

Action Make sure Enterprise Fabric Mode is not enabled and the switch is offline.

Message **Error 245: Invalid increment value**

Description The increment value specified is not between 1 and 70560.

Action Make sure the increment value given is between 1 and 70560.

Message **Error 246: Invalid interval value**

Description The interval value specified is not between 5 and 70560 minutes.

Action Make sure the increment value given is between 5 and 70560 minutes.

Message **Error 247: Invalid counter number**

Description The counter specified is not a valid number.

Action Use the table output by the command *perf.thresholdAlerts.counter.showStatisticTable* on page 2-166 to find a valid counter value.

Message **Error 248: A counter must be assigned to this threshold alert**

Description A counter must be assigned to an alert before it is enabled.

Action Use the command *perf.thresholdAlerts.counter.setCounter* on page 2-164 to set a counter before the alert is enabled.

Message **Error 249: At least one port or port type must be added to this threshold alert**

Description A port or port type must be assigned to an alert before it is enabled.

Action Use the command *perf.thresholdAlerts.counter.addPort* on page 2-162 to add a port before the alert is enabled.

Message **Error 250: Invalid counter threshold alert name**

Description The name specified for the alert is not valid.

Action Specify a counter threshold alert name that has already been created.

Message **Error 251: The threshold alert must be disabled**

Description The counter threshold alert to be modified/deleted is already enabled.

Action Disable the threshold alert and then try the command again.

Message **Error 253: Cannot Remove a Member Currently Interacting with the Fabric**

Description Current members of the fabric must be included in the Fabric Binding List.

Action Do not remove active fabric members from the pending Fabric Binding Membership List.

Message **Error 254: A utilization type must be assigned to this threshold alert**

Description A utilization type must be set before activating this threshold alert.

Action Add a utilization type and then the threshold alert can be activated.

Message **Error 255: Invalid throughput threshold alert name**

Description The name of the threshold alert is incorrect.

Action Either the name does not exist, or the new name cannot be used because it is illegal or a duplicate.

Message **Error 256: Invalid utilization type number**

Description The utilization type number does not exist.

Action Select a valid utilization type number.

Message **Error 257: Invalid utilization percentage value**

Description The utilization percentage value is out of range.

Action Select a valid utilization percentage value.

Message **Error 258: Invalid duration value**

Description The duration value in minutes is out of range.

Action Select a valid duration value.

Message **Error 259: Invalid threshold alert name**

Description The name of the threshold alert is incorrect.

Action The threshold alert name does not exist.

Message **Error 260: Not Allowed when SANtegrity feature is not installed on remote switch**

Description All switches in the fabric must have the SANtegrity feature key installed.

Action Install the SANtegrity feature key on all switches in the fabric.

Message **Error 261: No Attached Members Exist**

Description There are no members attached to the switch.

Action Check all connections and make sure attached devices are present.

Message **Error 262: All Attached Members are in the Membership List**

Description All attached fabric members are already in the membership list.

Action This action is redundant, all members are already in the list.

Message **Error 263: The SANtegrity Authentication feature key is not installed**

Description The SANtegrity Authentication feature key is not installed.

Action Install the SANtegrity Authentication feature key.

Message **Error 264: The Preferred Path feature key is not installed**

Description The preferred path feature key must be installed.

Action Install the preferred path feature key.

Message **Error 265: Duplicate threshold alert name**

Description The desired name for the threshold alert is already in use.

Action Use a different name for the threshold alert.

Message **Error 266: Attached members cannot be added while fabric is building**

Description Attached members cannot be added while the fabric is building.

Action The fabric is still building, wait a couple of seconds until it is complete.

Message **Error 268: RADIUS key too long**

Description The desired RADIUS key is too long.

Action Use a shorter RADIUS key.

Message **Error 269: Invalid retransmit attempts. Must be between 1 and 100**

Description The desired retransmit attempt value is invalid.

Action Select a retransmit value between 1 and 100.

Message **Error 270: Invalid timeout value. Must be between 1 and 1000**

Description The desired retransmit value is invalid.

Action Select a timeout value between 1 and 10000.

Message **Error 271: Invalid deadtime value. Must be between 0 and 1440 minutes**

Description The desired deadtime value is invalid.

Action Select a deadtime value between 0 and 1440.

Message **Error 272: Invalid IP address and port combination**

Description The desired host name and port combination doesn't exist in the database or it is invalid.

Action Select a valid host name and port combination.

Message **Error 273: Passwords do not match**

Description The password does not match the confirm password.

Action Re-enter the command and enter matching passwords.

Message **Error 274: Invalid interface combination**

Description The desired interface is not a valid interface.

Action Select a valid interface value.

Message **Error 275: Invalid authentication role**

Description The desired role is not a valid role.

Action Select a valid role. Valid roles are administrator and operator.

Message **Error 276: Invalid sequence authentication combination**

Description The desired sequence is not a valid sequence.

Action Select a valid sequence. Valid sequences are RADIUS, local, and RADIUS local.

Message **Error 277: Roles cannot be assigned to a username with this interface**

Description The role of the selected username is not configurable.

Action This operation is not supported. No action necessary.

Message **Error 278: CHAP authenticated passwords must be exactly 16 bytes**

Description The CHAP authentication password bust be exactly 16 bytes.

Action Enter a CHAP authentication password that is exactly 16 bytes.

Message **Error 280: Zone Member doesn't exist**

Description The desired zone member doesn't exist.

Action Select a valid zone member.

Message **Error 281: Zone doesn't exist**

Description The desired zone doesn't exist.

Action Select a valid zone name.

Message **Error 282: Conflicting Domain ID for the specified WWN**

Description The desired Domain ID is already in use.

Action Select a different Domain ID.

Message **Error 283: Conflicting WWN for the specified Domain ID**

Description The WWN is already in use.

Action Select a different WWN.

Message **Error 284: FICON CUP Zoning host control list is full**

Description A new host may not be entered without removing an existing host from the list.

Action A total of 8 hosts may be defined for the FICON CUP Zoning host control list. A new host can be added only after a current host is removed. Make the appropriate changes and re-submit.

Message **Error 285: WWN not found in host control list**

Description The desired WWN is not in the host control list.

Action Select a WWN that is in the host control list.

Message **Error 286: Invalid number of NPIV allowed logins**

Description The desired value for NPIV allowed logins is invalid.

Action Select a value between 1 and 256.

Message **Error 287: Port is unaddressable**

Description The desired port cannot be configured because it is unadressable.

Action This operation is not supported. No action necessary.

Message **Error 288: The NPIV feature key must be installed**

Description The NPIV feature key must be installed to complete this operation.

Action Install the NPIV feature key.

Message **Error 289: Duplicate policy name**

Description A policy cannot be added if it has the same name as an existing policy.

Action Select a different policy name.

Message **Error 290: No Optic Installed**

Description There is not an optic in the port for the specified port number.

Action Select a different port number, or plug in an optic.

Message **Error 291: Port Inaccessible**

Description There port in inaccessible for the given port number.

Action Select a different port number.

Message **Error 292: Port Number out of Range**

Description The specified port number if out of range for the given switch/director.

Action Select a different port number.

Message **Error 294: Invalid RADIUS Index**

Description The specified RADIUS index is invalid.

Action Enter a valid RADIUS index. Valid indexes are 1 to 3.

Message **Error 295: Invalid MIHPTO value**

Description The MIHPTO value is invalid.

Action Enter a valid MIHPTO value.

Message **Error 296: Cannot delete last EPort user with current authentication setting**

Description You cannot remove the last EPort user with the current authentication settings.

Action Modify the EPort authentication settings.

Message **Error 297: Cannot delete last N_Port user with current setting authentication setting**

Description You cannot remove the last Port user with the current authentication settings.

Action Modify the Nport authentication settings.

Message **Error 298: Cannot delete last API user with current authentication setting**

Description You cannot remove the last API user with the current authentication settings.

Action Modify the API authentication settings.

Message **Error 299: Chap secret not defined**

Description The Chap secret must be defined (for Open Systems Management Server before enabling Outgoing Authentication.)

Action Define a Chap Secret (for Open Systems Management Server).

Message **Error 300: No user defined for this Interface**

Description You cannot perform the specified action unless a user is defined for the interface.

Action Create a user for the interface.

Message **Error 301: RADIUS server undefined**

Description You cannot perform the operation until a RADIUS server is configured. (You cannot enable RADIUS Authentication if there is not RADIUS server configured.)

Action Configure a RADIUS server (before enabling RADIUS Authentication).

Message **Error 302: Pending Default Zone Member Count Exceeds Threshold**

Description You cannot enable default zoning if the there are more than 64 devices not being zoned.

Action Bring the number of unzoned devices down to 64.

Message **Error 303: Invalid Preferred Path**

Description The preferred path entered is invalid. (One reason the preferred path could be invalid is if the destination domain ID is the same as the local switch's.)

Action Enter a valid preferred path.

Message **Error 304: Radius Authentication Present. Cannot remove all Radius Servers**

Description You cannot remove all the RADIUS Server configurations if RADIUS Authentication is enabled on any interface.

Action Disabled RADIUS Authentication on all interfaces and then remove the last RADIUS server configuration.

Message **Error 305: Operating mode is not OSMS**

Description You cannot enable CT Outgoing Authentication when Open Systems Management Server is disabled.

Action Enabled Open Systems Management Server before enabling CT Outgoing Authentication.

Message **Error 306: CT Outgoing Authentication is enabled**

Description You cannot disable Open Systems Management Server when CT Outgoing Authentication is enabled.

Action Disabled CT Outgoing Authentication before disabling Open Systems Management Server.

Message **Error 307: The preferred path does not exist**

Description You tried to clear a path that does not exist.

Action None

Message **Error 308: Invalid line speed combination**

Description The ethernet speed/duplex combination is invalid.

Action Enter a valid ethernet speed/duplex combination.

Message **Error 310: FICON Management Server must be enabled**

Description You cannot perform this operation until the FICON Management Server is enabled.

Action Enable the FICON Management Server.

Message **Error 311: FICON CUP Zoning must be disabled**

Description You cannot perform this operation until the FICON Management Server is disabled.

Action Disable the FICON Management Server.

Message **Error 321: Invalid syslog facility number**

Description The syslog facility number is invalid

Action Select a valid syslog facility number.

Message **Error 323: Invalid trigger start offset**

Description The trigger start offset value is invalid.

Action Select a valid trigger start offset value.

Message **Error 324: Invalid trigger start bit pattern**

Description The trigger start bit pattern is invalid.

Action Select a valid trigger start bit pattern.

Message **Error 325: Invalid trigger end offset**

Description The trigger end offset value is invalid.

Action Select a valid trigger end offset value.

Message **Error 326: Invalid trigger end bit pattern**

Description The trigger end bit pattern is invalid.

Action Select a valid trigger end bit pattern.

Message **Error 327: Invalid trigger**

Description The trigger is invalid.

Action Enter a valid trigger value.

Message **Error 328: Invalid syslog index**

Description The syslog index is invalid.

Action Select a valid syslog index.

Message **Error 330: Invalid trace route source**

Description The trace route source value is invalid.

Action Select a valid WWN or Port ID for the trace route source.

Message **Error 331: Invalid trace route destination**

Description The trace route destination value is invalid.

Action Select a valid WWN or Port ID for the trace route destination.

Message **Error 332: Unable to run a trace route at this time**

Description The trace route is unable to run.

Action Wait a little while and run the trace route again.

Message **Error 333: Invalid Port ID**

Description The Port ID is invalid.

Action Enter a valid Port ID.

Message **Error 336: Invalid SSL renegotiation megabyte value**

Description The SSL renegotiation megabyte value is invalid

Action Enter a valid SSL renegotiation megabyte value

Message **Error 337: Invalid SNMP table index**

Description The SNMP table index is invalid

Action Select a valid index.

Message **Error 339: Invalid SNMPv3 user table index**

Description The user table index is invalid.

Action Enter a valid index.

Message **Error 340: Invalid SNMPv3 username**

Description The username is invalid.

Action Select a valid username.

Message **Error 341: Invalid SNMPv3 authentication protocol**

Description The authentication protocol is invalid.

Action Select a valid authentication protocol.

Message **Error 342: Invalid SNMPv3 authentication key**

Description The authentication key is invalid.

Action Select a valid authentication key.

Message **Error 343: Invalid SNMPv3 privacy protocol**

Description The privacy protocol is invalid.

Action Select a valid privacy protocol.

Message **Error 344: Invalid SNMPv3 privacy key**

Description The privacy key is invalid.

Action Select a valid privacy key.

Message **Error 345: Invalid SNMPv3 target table index**

Description The target table index is invalid.

Action Select a valid index.

Message **Error 346: Invalid SNMPv3 target IP**

Description The Target IP Address is invalid.

Action Enter a valid IP Address.

Message **Error 347: Invalid SNMPv3 UDP port number**

Description The UDP Port number is invalid.

Action Select a valid UDP port number.

Message **Error 348: Invalid SNMPv3 community name**

Description The community name is invalid.

Action Enter a valid community name.

Message **Error 349: Invalid SNMPv3 MP model**

Description The MP model is invalid.

Action Enter a valid MP model.

Message **Error 350: Invalid SNMPv3 security name**

Description The security name is invalid.

Action Enter a valid security name.

Message **Error 351: Invalid SNMPv3 group name**

Description The group name is invalid.

Action Enter a valid group name.

Message **Error 352: Invalid SNMPv3 security model**

Description The security model is invalid.

Action Enter a valid security model.

Message **Error 353: Invalid SNMPv3 security level**

Description The security level is invalid.

Action Enter a valid security level.

Message **Error 354: Invalid SNMPv3 access table index**

Description The access table index is invalid.

Action Enter a valid index.

Message **Error 360: The number of days for key generation is out of range.**

Description The number of days for the key generation is invalid.

Action Enter a valid number of days for key generation.

Message **Error 361: An internal error occurred when generating the key.**

Description An error occurred while generating the SSL key.

Action None

Message **Error 362: Duplicate SNMPv3 user name**

Description You can't have two SNMPv3 usernames that are the same.

Action Enter a different value for the username.

Message **Error 363: Invalid SNMPv3 group table index**

Description The group table index is invalid.

Action Enter a valid index.

Message **Error 364: SNMPv3 group name conflict**

Description The group name, security name, security model combination must be unique.

Action Enter a valid group name, security name, and security model combination.

Message **Error 367: Invalid SNMPv3 access group name**

Description The access group name is invalid.

Action Enter a valid access group name.

Message **Error 371: Unable to set HA mode**

Description The HA mode cannot be set.

Action Contact your service representative.

Message **Error 372: The IP ACL pair does not exist in the Switch Access Control List**

Description The IP ACL pair is already not in the list.

Action None

Message **Error 373: Configuration not allowed while SNMPv3 is enabled**

Description You can't perform the desired operation while SNMPv3 is enabled.

Action Disable SNMPv3 before continuing.

Message **Error 374: Invalid SNMPv3 securitytogroup index**

Description The security to group table index is invalid.

Action Enter a valid index.

Message **Error 376: The Local Switch WWN or DID conflicts with another member**

Description There is a member in the FBML that has the same WWN or DID as the local switch.

Action Remove the conflicting entry and then add the local switch to the list.

Message **Error 377: HA Mode cannot be turned off with both Power Supply connected**

Description When both power supplies are connected, the HA Mode cannot be disabled.

Action None

Message **Error 378: Duplicate IP address setting**

Description The IP address already exists.

Action Choose a different IP Address or remove the existing entry.

Message **Error 379: Changing of QPM port mode can only start with an even numbered port**

Description Only even numbered ports can be configured.

Action Specify the complementary port of the port that is specified to configure the mode of the port

Message **Error 380: Invalid Domain ID offset**

Description The offset value specified is invalid.

Action Specify a different domain ID offset value.

Message **Error 381: Invalid PORT Mode specified**

Description The mode of operation specified is invalid.

Action Specify the mode of operation of the port as Burst or Sustained

Message **Error 382: Blade is not a QPM**

Description The port that is being configured is not a QPM.

Action The mode of operation of a port can be configured only for ports on a QPM.

Message **Error 383: Invalid Password Expiry Limit**

Description The password expiration time specified is invalid

Action

The password expiration time should be in the range 0-3650.

Message **Error 384: Count specified to ping a destination is invalid**

Description The ping count specified is invalid.

Action The count can have a value from 1 to 10

Message **Error 385: Timeout value specified for ping is invalid**

Description The ping response timeout specified is invalid.

Action The timeout can have a value from 1 to 10

Message **Error 386: Unable to complete ping request at this time**

Description Ping could not be completed.

Action None

Message **Error 387: Snapshot Database not Available**

Description Snapshot database was not saved previously

Action Issue the saveSnapshot command and then re-issue the command.

Message **Error 388: Could not save Name Server snapshot**

Description The snapshot of the Name Server database could not be saved

Action Issue the saveSnapshot command again.

Message **Error 389: There is no Name Server snapshot saved**

Description The snapshot of the Name Server database was not saved

Action

Use the saveSnapshot command and then re-issue this command

Message **Error 390: Invalid Login Banner Line Index**

Description The line number specified for the banner text is invalid

Action The line number can have a value between 0-24.

Message **Error 391: Invalid destination domain specified**

Description The destination domain ID specified is invalid

Action The domain Id can have a value between 1-31.

Message **Error 392: Invalid Source Port specified**

Description The port number specified is invalid

Action Specify a valid port number.

Message **Error 393: Invalid SSH renegotiation megabyte value**

Description The renegotiation megabyte value that was specified is invalid.

Action The renegotiation value can have a value between 1-1000.

Message **Error 394: Password must be different from last 3 passwords**

Description The new password is the same as one of the previous 3 passwords.

Action Specify the new password to be different from the previous three passwords.

Message **Error 395: Port Address Is Out Of Range**

Description The port address specified is invalid.

Action Specify a valid port address when issuing the command.

Message **Error 396: logical error**

Description An internal logical error has occurred.

Action None.

Message **Error 397: Unable to respond to the request**

Description The destination was not able to respond to the ping request.

Action None.

Message **Error 398: Resource unavailable**

Description A resource that was needed for completing this request was not available.

Action None.

Message **Error 399: Source not in fabric**

Description The specified port is not in fabric.

Action Specify a valid port.

Message **Error 400: Command to remote switch timed out**

Description Did not get a response within the specified timeout.

Action None.

Message **Error 401: Port no longer online**

Description The specified port is not online.

Action None.

Message **Error 402: Proxy transaction aborted**

Description The operation was aborted

Action None.

Message **Error 402: Proxy received, but invalid response**

Description A response was received, but an invalid response

Action None.

Message **Error 402: Proxy transaction aborted**

Description The operation was aborted

Action None.

Message **Error 404: Good response, but invalid payload**

Description A response was received, however the response contained an invalid response.

Action None.

Message **Error 405: Logical error in proxy response**

Description An error occurred in the ping response

Action None.

Message **Error 406: Destination not logged in**

Description The destination specified was not online.

Action Make the destination switch online and then re-issue the ping request.

Message **Error 407: No path to the destination from the source**

Description There is no path from the specified source to the destination

Action None

Message **Error 408: Invalid CIDR log event specified**

Description The log setting specified is invalid

Action Specify a valid log setting.

Message **Error 409: An association already exists**

Description An association already exists

Action Specify a different association – nickname and WWN combination

Message **Error 410: Could not find the existing association**

Description The specified association is not in the pending association list

Action Specify a different association.

Message **Error 411: The pending associations could not be saved**

Description The save operation for Nickname associations failed.

Action None

Message **Error 411: Invalid alias**

Description An invalid alias was specified.

Action Assign a valid alias for the WWN.

Message **Error 414: No aliases associations available**

Description The association list is empty.

Action None.

Message **Error 415: The active associations could not be loaded**

Description The active association list could not be copied to the pending association list

Action None.

Message **Error 416: The Association list has not been updated with the active associations**

Description The active associations were updated by an external source.

Action Use the replacePending command and re-issue all the changes.

Message **Error 417: Invalid WWN or alias specified**

Description The specified WWN or alias was not found in the active association list.

Action None

Message **Error 418: Maximum Associations count has been reached**

Description Only 250 associations are possible and the limit has been reached.

Action None

Message **Error 419: The Associations have been modified externally**

Description The associations have been modified in a different switch in the fabric and have been synchronized fabric wide and hence the checksum has changed.

Action Update the pending list and re-issue the commands

Message **Error 420: Unable to handle request at this time**

Description An internal error occurred.

Action None

Message **Error 421: Nickname cannot be a WWN**

Description An alias cannot be a WWN

Action Assign a different alias to the WWN.

Message **Error 422: Invalid FCID**

Description The FCID specified is invalid

Action Specify a valid FCID.

Message **Error 423: Duplicate Radius server entry**

Description The specified radius already exists in the configured list of servers

Action Specify a new valid server.

Message **Error 424: Unable to set default zone state**

Description The operation to set the default zone state failed.

Action None.

Message **Error 425: Invalid login banner length.**

Description The login banner line length is too long.

Action Enter a login banner line of 80 characters or less.

Message **Error 426: Invalid ping destination.**

Description An invalid FCID was entered.

Action Specify a valid FCID.

Message **Error 427: Invalid snmp udp port number.**

Description The SNMP udp port number is not correct.

Action Specify the valid SNMP udp port.

Message **Error 428: Invalid Login Banner text.**

Description The text of the login banner is invalid.

Action Specify a valid text for the login banner.

Message **Error 429: Invalid POM log event specified.**

Description The event specified is invalid.

Action Specify a valid event for POM Report logging.

Message **Error 430: Invalid Port Type and Speed combination**

Description "Negotiate Burst 4 Max" and "4 Burst" can be set with F ports only.

Action For QPM card, change the port type to F port for speed setting of "Negotiate Burst 4 Max" and "4 Burst".

Message **Error 431: Ping to well-known address is disallowed**

Description A well-known FCID is entered.

Action Specify a valid FCID other than the well-known address.

Message **Error 432: Not allowed while fabric not operational**

Description The operation is not allowed while fabric is not operational.

Action Try again after fabric becomes operational.

B

Commands and Corresponding Releases

Table B-1, *Commands and Releases*, shows the commands that are valid in the Enterprise Operating System (E/OS) Command Line Interface (CLI) and the release in which the command was added to the CLI. The commands are organized by release, and are in alphabetical order within the release.

Table B-1 Commands and Releases

First E/OS Release	Command
9.1	*config.alias*
9.1	*config.alias.activatePending*
9.1	*config.alias.add*
9.1	*config.alias.clearPending*
9.1	*config.alias.delete*
9.1	*config.alias.replacePending*
9.1	*config.alias.setCLIState*
9.1	*config.alias.setWebState*
9.1	*config.alias.showActive*
9.1	*config.alias.showPending*
9.1	*show.activeAlias*
9.1	*show.openSysMS.platformInfo*

Table B-1 Commands and Releases (Continued)

First E/OS Release	Command
9.0	*config.NSTools*
9.0	*config.NSTools.clearSnapshot*
9.0	*config.NSTools.saveSnapshot*
9.0	*config.NSTools.showSnapDiff*
9.0	*config.NSTools.showSnapshot*
9.0	*config.security.authentication.user.passExpTime*
9.0	*config.security.ssh.setRenegotiationMB*
9.0	*config.snmp.sendTestTrap*
9.0	*config.switch.banner*
9.0	*config.switch.banner.bannerText*
9.0	*config.switch.banner.setCLIState*
9.0	*config.switch.banner.setWebState*
9.0	*config.switch.banner.show*
9.0	*config.switch.domainIDOffset*
9.0	*perf.AFD*
9.0	*perf.AFD.HDDReport*
9.0	*perf.AFD.POMReport*
9.0	*perf.AFD.show*
9.0	*show.epFrameLog.removeFilterPort*
9.0	*show.fabric.ping*
9.0	*show.fabric.showRouteTable*
9.0	*show.nameServerFC4Types*
8.0	*config.security.ssl.generateKeys*
8.0	*config.security.ssl.resetKeys*
8.0	*config.security.ssl.setAPIState*

Table B-1 Commands and Releases (Continued)

First E/OS Release	Command
8.0	*config.security.ssl.setRenegotiationMB*
8.0	*config.security.ssl.setWebState*
8.0	*config.security.ssl.show*
8.0	*config.snmp.addAccessEntry*
8.0	*config.snmp.deleteAccessEntry*
8.0	*config.snmp.addTargetParams*
8.0	*config.snmp.addUserEntry*
8.0	*config.snmp.addV1Target*
8.0	*config.snmp.addV2Target*
8.0	*config.snmp.addV3Group*
8.0	*config.snmp.addV3Target*
8.0	*config.snmp.deleteAccessEntry*
8.0	*config.snmp.setSNMPv3State*
8.0	*config.snmp.deleteUserEntry*
8.0	*config.snmp.deleteV3Group*
8.0	*config.snmp.setSNMPv3State*
8.0	*config.snmp.showAccessTable*
8.0	*config.snmp.showTargetTable*
8.0	*config.snmp.showUserTable*
8.0	*config.snmp.showV3GroupTable*
8.0	*config.snmp.showViewTable*
8.0	*config.snmp.validateUser*
8.0	*config.switch.apiState*
8.0	*config.switch.haMode*
8.0	*config.switch.webState*

Table B-1 Commands and Releases (Continued)

First E/OS Release	Command
8.0	*config.switch.apiState*
8.0	*config.switch.safeZoning*
8.0	*config.switch.islFSPFCost*
8.0	*config.syslog*
8.0	*config.syslog.addServer*
8.0	*config.syslog.deleteServer*
8.0	*config.syslog.setLogConfig*
8.0	*config.syslog.setState*
8.0	*config.syslog.show*
8.0	*config.system.contact*
8.0	*show.epFrameLog.disableTrigger*
8.0	*show.epFrameLog.setTrigger*
8.0	*show.fabric.traceRoute*
8.0	*show.port.opticData*
8.0	*show.port.opticHealth*
8.0	*show.snmp.accessTable*
8.0	*show.snmp.targetTable*
8.0	*show.snmp.userTable*
8.0	*show.snmp.V3GroupTable*
8.0	*show.snmp.viewTable*
8.0	*show.syslog*
7.0	*config.features.NPIV*
7.0	*config.fencing.addPolicy*
7.0	*config.fencing.addPort*
7.0	*config.fencing.deletePolicy*

Table B-1 Commands and Releases (Continued)

First E/OS Release	Command
7.0	*config.fencing.removePort*
7.0	*config.fencing.setParams*
7.0	*config.fencing.setState*
7.0	*config.fencing.show*
7.0	*config.fencing.showTypeTable*
7.0	*config.ficonCUPZoning.addControlHost*
7.0	*config.ficonCUPZoning.deleteControlHost*
7.0	*config.ficonCUPZoning.setState*
7.0	*config.ficonCUPZoning.show*
7.0	*config.ficonMS.setMIHPTO*
7.0	*config.ficonMS.show*
7.0	*config.ip.lineSpeed*
7.0	*config.NPIV.maxPortIDs*
7.0	*config.NPIV.setState*
7.0	*config.NPIV.show*
7.0	*config.openSysMS.setHostCtrlState*
7.0	*config.port.rxCredits*
7.0	*config.port.show*
7.0	*config.port.showPortAddr*
7.0	*config.port.swapPortByAddr*
7.0	*config.port.swapPortByNum*
7.0	*config.security.authentication.interface.api.outgoing*
7.0	*config.security.authentication.interface.api.sequence*
7.0	*config.security.authentication.interface.cli.sequence*
7.0	*config.security.authentication.interface.eport.outgoing*

Table B-1 Commands and Releases (Continued)

First E/OS Release	Command
7.0	*config.security.authentication.interface.eport.sequence*
7.0	*config.security.authentication.interface.nport.outgoing*
7.0	*config.security.authentication.interface.nport.sequence*
7.0	*config.security.authentication.interface.osms.outgoing*
7.0	*config.security.authentication.interface.osms.setKey*
7.0	*config.security.authentication.interface.serial.enhancedAuth*
7.0	*config.security.authentication.interface.show*
7.0	*config.security.authentication.interface.web.sequence*
7.0	*config.security.authentication.port.override*
7.0	*config.security.authentication.port.show*
7.0	*config.security.authentication.RADIUS.attempts*
7.0	*config.security.authentication.RADIUS.deadtime*
7.0	*config.security.authentication.RADIUS.deleteServer*
7.0	*config.security.authentication.RADIUS.server*
7.0	*config.security.authentication.RADIUS.show*
7.0	*config.security.authentication.RADIUS.timeout*
7.0	*config.security.authentication.switch.setSecret*
7.0	*config.security.authentication.user*
7.0	*config.security.authentication.user.add*
7.0	*config.security.authentication.user.delete*
7.0	*config.security.authentication.user.modify*
7.0	*Command Example*
7.0	*config.security.authentication.user.show*
7.0	*config.security.ssh.resetKeys*
7.0	*Command Example*

Table B-1 Commands and Releases (Continued)

First E/OS Release	Command
7.0	*config.security.ssh.show*
7.0	*config.security.switchAcl.addRange*
7.0	*config.security.switchAcl.deleteRange*
7.0	*config.security.switchAcl.setState*
7.0	*config.security.switchAcl.show*
7.0	*config.switch.apiState*
7.0	*perf.preferredPath.showPath*
7.0	*perf.thresholdAlerts.show*
7.0	*show.auditLog*
7.0	*show.epFrameLog.config*
7.0	*show.epFrameLog.filterClassFFrames*
7.0	*show.epFrameLog.noWrap*
7.0	*show.epFrameLog.noWrap*
7.0	*show.epFrameLog.wrap*
7.0	*show.fabricLog.noWrap*
7.0	*show.fabricLog.wrap*
7.0	*show.fabric.principal*
7.0	*show.fencing.policies*
7.0	*show.ficonCUPZoning*
7.0	*show.ficonMS*
7.0	*show.NPIV.config*
7.0	*show.openSysMS.config*
7.0	*show.port.config*
7.0	*show.port.opticEDD*
7.0	*show.port.opticInfo*

Table B-1 Commands and Releases (Continued)

First E/OS Release	Command
7.0	*show.port.profile*
7.0	*show.port.showPortAddr*
7.0	*show.security.switchAcl*
7.0	*show.security.log*
6.1	*config.snmp.setFaMibVersion*
6.1	*config.snmp.setState*
6.1	*perf.preferredPath.clearPath*
6.1	*perf.preferredPath.setPath*
6.1	*perf.preferredPath.setState*
6.1	*perf.preferredPath.showPath*
6.1	*show.all*
6.1	*show.fabric.nodes*
6.1	*show.fabric.topology*
6.1	*show.linkIncidentLog*
6.1	*show.port.exit*
6.1	*show.preferredPath.showPath*
6.1	*show.syslog*
6.1	*show.thresholdAlerts.log*
5.3	*config.enterpriseFabMode.setState*
5.3	*config.features.openTrunking*
5.3	*config.ficonMS.setMIHPTO*
5.3	*config.NPIV.maxPortIDs*
5.3	*config.switch.ltdFabRSCN*
5.3	*config.switch.webState*
5.3	*perf.openTrunking.backPressure*

Table B-1 Commands and Releases (Continued)

First E/OS Release	Command
5.3	*perf.openTrunking.congestionThresh*
5.3	*perf.openTrunking.lowBBCreditThresh*
5.3	*perf.openTrunking.setState*
5.3	*perf.openTrunking.show*
5.3	*perf.openTrunking.unresCongestion*
5.3	*perf.thresholdAlerts*
5.3	*show.openTrunking.config*
5.3	*show.openTrunking.rerouteLog*
4.0	*config.features.enterpriseFabMode*
4.0	*config.features.ficonMS*
4.0	*config.features.installKey*
4.0	*config.features.openSysMS*
4.0	*config.features.show*
4.0	*config.ip.ethernet*
4.0	*config.ip.show*
4.0	*config.port.blocked*
4.0	*config.port.fan*
4.0	*config.port.name*
4.0	*config.port.show*
4.0	*config.port.speed*
4.0	*config.port.type*
4.0	*config.security.fabricBinding*
4.0	*config.security.portBinding*
4.0	*config.security.switchBinding*
4.0	*config.snmp.authTraps*

Table B-1 Commands and Releases (Continued)

First E/OS Release	Command
4.0	*config.snmp.deleteCommunity*
4.0	*config.snmp.show*
4.0	*config.switch*
4.0	*config.switch.domainRSCN*
4.0	*config.switch.edTOV*
4.0	*config.switch.insistDomainId*
4.0	*config.switch.interopMode*
4.0	*config.switch.prefDomainId*
4.0	*config.switch.priority*
4.0	*config.switch.raTOV*
4.0	*config.switch.rerouteDelay*
4.0	*config.switch.show*
4.0	*config.switch.speed*
4.0	*config.system.date*
4.0	*config.system.description*
4.0	*config.system.location*
4.0	*config.system.name*
4.0	*config.system.show*
4.0	*config.zoning.activateZoneSet*
4.0	*config.zoning.addPortMem*
4.0	*config.zoning.clearZone*
4.0	*config.zoning.renameZoneSet*
4.0	*config.zoning.clearZone*
4.0	*config.zoning.renameZoneSet*
4.0	*config.zoning.deactivateZoneSet*

Table B-1 Commands and Releases (Continued)

First E/OS Release	Command
4.0	*config.zoning.deletePortMem*
4.0	*config.zoning.renameZone*
4.0	*config.zoning.renameZoneSet*
4.0	*config.zoning.renameZone*
4.0	*config.zoning.renameZoneSet*
4.0	*config.zoning.replaceZoneSet*
4.0	*config.zoning.setDefZoneState*
4.0	*config.zoning.showActive*
4.0	*config.zoning.showPending*
4.0	*maint.port.beacon*
4.0	*maint.port.reset*
4.0	*maint.system.beacon*
4.0	*maint.system.clearSysError*
4.0	*maint.system.ipl*
4.0	*maint.system.resetConfig*
4.0	*maint.system.setOnlineState*
4.0	*perf.class2*
4.0	*perf.class3*
4.0	*perf.clearStats*
4.0	*perf.errors*
4.0	*perf.link*
4.0	*perf.traffic*
4.0	*show.eventLog*
4.0	*show.features*
4.0	*show.frus*

Table B-1 Commands and Releases (Continued)

First E/OS Release	Command
4.0	*show.ip.ethernet*
4.0	*show.loginServer*
4.0	*show.nameServer*
4.0	*show.nameServerExt*
4.0	*show.port.config*
4.0	*show.port.info*
4.0	*show.port.nodes*
4.0	*show.port.status*
4.0	*show.port.technology*
4.0	*show.preferredPath.showState*
4.0	*show.security.portBinding*
4.0	*show.security.switchBinding*
4.0	*show.switch*
4.0	*show.system*
4.0	*show.zoning*

Glossary

This glossary includes terms and definitions from:

- *American National Standard Dictionary for Information Systems* (ANSI X3.172-1990), copyright 1990 by the American National Standards Institute (ANSI). Copies can be purchased from the American National Standards Institute, 25 West 42nd Street, New York, NY 10036. Definitions from this text are identified by *(A).*
- *ANSI/EIA Standard - 440A: Fiber Optic Terminology*, copyright 1989 by the Electronic Industries Association (EIA). Copies can be purchased from the Electronic Industries Association, 2001 Pennsylvania Avenue N.W., Washington, D.C. 20006. Definitions from this text are identified by *(E).*
- *IBM Dictionary of Computing* (ZC20-1699). Definitions from this text are identified by *(D).*
- *Information Technology Vocabulary*, developed by Subcommittee 1 (SC1), Joint Technical Committee 1 (JTC1), of the International Organization for Standardization (ISO) and the International Electrotechnical Commission (IEC). Definitions of published parts of this vocabulary are identified by *(I).* Definitions taken from draft international standards, committee drafts, and working papers developed by ISO/IEC SC1/JTC1 are identified by *(T),* indicating that final agreement has not been reached among the participating national bodies of SC1.

The following cross-references are used in this glossary:

Contrast with. This refers to a term that has an opposite or substantively different meaning.

See. This refers the reader to another keyword or phrase for the same term.

See also. This refers the reader to definite additional information contained in another entry.

A

access control A list of all devices that can access other devices across the network and the permissions associated with that access. *See also* persistent binding.

active field-replaceable unit Active FRU. A FRU that is currently operating as the active, and not the backup FRU. *See also* backup field-replaceable unit.

active zone set A single zone set that is active in a multiswitch fabric and is created when a specific zone set is enabled. This zone set is compiled by checking for undefined zones or aliases. *See also* zone; zone set.

AL_PA *See* arbitrated loop physical address.

arbitrated loop physical address AL_PA. A 1-byte value used in the arbitrated loop topology that identifies loop ports (L_Ports). This value then becomes the last byte of the address identified for each public L_Port on the loop.

B

backup field-replaceable unit Backup FRU. When an active FRU fails, an identical backup FRU takes over operation automatically (failover) to maintain director or switch and Fibre Channel link operation. *See also* active field-replaceable unit.

backup FRU *See* backup field-replaceable unit.

beaconing Use of light-emitting diodes (LEDs) on ports, port cards, field-replaceable units (FRUs), and directors to aid in the fault-isolation process. When enabled, active beaconing will cause LEDs to flash in order for the user to locate field-replaceable units (FRU's), switches, or directors in cabinets or computer rooms.

BB_Credit *See* buffer-to-buffer credit.

blocked port In a director or switch, the attribute that when set, removes the communication capability of a specific port. A blocked port continuously transmits the offline sequence.

buffer Storage area for data in transit. Buffers compensate for differences in processing speeds between devices. *See* buffer-to-buffer credit.

buffer-to-buffer credit BB_Credit. (1) The maximum number of receive buffers allocated to a transmitting node port (N_Port) or fabric port (F_Port). Credit represents the maximum number of outstanding frames that can be transmitted by that N_Port or F_Port without causing a buffer overrun condition at the receiver. (2) The maximum number of frames a port can transmit without receiving a receive ready signal from the receiving device. BB_Credit can be adjustable to provide different levels of compensation.

C

channel A point-to-point link that transports data from one point to the other.

Class 2 Fibre Channel service Provides a connectionless (not dedicated) service with notification of delivery or nondelivery between two node ports (N_Ports).

Class 3 Fibre Channel service Provides a connectionless (not dedicated) service without notification of delivery or nondelivery between two node ports (N_Ports). *Synonymous with* datagram.

Class F Fibre Channel service Used by switches to communicate across interswitch links (ISLs) to configure, control, and coordinate a multiswitch fabric.

Class of Fibre Channel service Defines the level of connection, dedication, acknowledgment, and other characteristics of a connection.

community profile Information that specifies which management objects are available to what management domain or simple network management protocol (SNMP) community name.

configuration data The collection of data that results from configuring product and system operating parameters. For example, configuring operating parameters, simple network management protocol (SNMP) agent,

zoning configurations, and port configurations through the Element Manager application results in a collection of configuration data. Configuration data includes identification data, port configuration data, operating parameters, simple network management protocol (SNMP) configuration, and zoning configuration.

connectionless Nondedicated link. Typically used to describe a link between nodes which allows the switch to forward Class 2 or Class 3 frames as resources (ports) allow. Contrast this to the dedicated bandwidth that is required in a Class 1 Fibre Channel Service point-to-point link.

connector *Synonym for* optical fiber connector.

control processor card CTP card. Circuit card that contains the director or switch microprocessor. The CTP card also initializes hardware components of the system after power-on. The card may contain an RJ-45 twisted pair connector.

control unit A hardware unit that controls the reading, writing, or displaying of data at one or more input/output units.

control unit port CUP. An internal director or switch port on the control processor (CTP) card (labelled FE) that communicates with channels to report error conditions and link initialization *(D)*.

CRC *See* cyclic redundancy check.

CTP card *See* control processor card.

cyclic redundancy check CRC. System of error checking performed at both the sending and receiving station using the value of a particular character generated by a cyclic algorithm. When the values generated at each station are identical, data integrity is confirmed.

D

datagram *Synonym for* Class 3 Fibre Channel service.

default Pertaining to an attribute, value, or option that is assumed by a system when none is explicitly specified *(D, I)*.

default zone A zone that contains all of the devices attached to a fabric that are not members of at least one of the zones of the activated zone set.

device (1) Mechanical, electrical, or electronic hardware with a specific purpose *(D)*. *See also* managed product.

(2) *See* node.

dialog box A pop-up window in the user interface with informational messages or fields to be modified or completed with desired options.

domain A Fibre Channel term describing the most significant byte in the node port (N_Port) identifier for the Fibre Channel device. It is not used in the Fibre Channel small computer system interface (FC-SCSI) hardware path ID. It is required to be the same for all SCSI targets logically connected to a Fibre Channel adapter.

domain ID Domain identifier. A number that uniquely identifies a switch in a multiswitch fabric. A distinct domain ID is automatically allocated to each switch in the fabric by the principal switch. The preferred domain ID is the domain ID value that a switch requests from the principal switch. If the value has not been allocated to another switch in the fabric, it will be granted by the principal switch and will become the requesting switch's active domain ID. The active domain ID is the domain ID that has been assigned by the principal switch and that a switch is currently using.

domain name server In TCP/IP, a server program that supplies name-to-address translation by mapping domain name to internet addresses. *(D)*

E

E_D_TOV *See* error-detect time-out value.

E_Port *See* expansion port.

Element Manager application Application that implements the management user interface for a director or switch. (1) In your SAN management application application, the software component that provides a graphical user interface for managing and monitoring switch products. When a product instance is opened from your SAN management application, the corresponding Element Manager application is invoked.

embedded web server With director or switch firmware version 1.2 (or later) installed, administrators or operators with a browser-capable PC and an Internet connection can monitor and manage the director or switch through an embedded web server interface, called the EFCM Basic interface. The interface provides a GUI similar to the Element Manager application, and supports director configuration, statistics monitoring, and basic operation.

error-detect time-out value E_D_TOV. The time the switch waits for an expected response before declaring an error condition.

error message Indication that an error has been detected *(D)*. *See also* information message; warning message.

Ethernet A widely implemented local area network (LAN) protocol that uses a bus or star topology and serves as the basis for the Institute of Electrical and Electronics Engineers (IEEE) 802.3 standard, which specifies the physical and software layers.

exchange fabric membership data An SW_ILS that ensures that merging switches have the same fabric membership list during initialization.

expansion port E_Port. Physical interface on a Fibre Channel switch within a fabric, that attaches to an E_Port on another Fibre Channel switch through an interswitch link (ISL) to form a multiswitch fabric. *See also* segmented E_Port.

F

F_Port *See* fabric port.

fabric Entity that interconnects node ports (N_Ports) and is capable of routing (switching) Fibre Channel frames, using the destination ID information in the Fibre Channel frame header accompanying the frames. A switch is the smallest entity that can function as a complete switched fabric topology.

fabric binding A security feature that limits the switches that can join a fabric, by specifying the WWN and Domain ID of the allowed switches in the fabric membership list.

fabric loop port FL_Port. A fabric port (F_Port) that contains arbitrated loop (AL) functions associated with the Fibre Channel arbitrated loop (FC-AL) topology. The access point of the fabric for physically connecting an arbitrated loop of node loop ports (NL_Ports).

fabric port F_Port. Physical interface within the fabric that connects to a node port (N_Port) through a point-to-point full duplex connection.

fabric membership list The list of switches, specified by Domain ID and WWN, that will be exchanged during Exchange Fabric Membership Data.

failover Automatic and nondisruptive transition of functions from an active field-replaceable unit (FRU) that has failed to a backup FRU.

FAN Fabric address notification.

FCP A standard Fibre Channel protocol used to run SCSI over Fibre Channel.

fiber The fiber-optic cable made from thin strands of glass through which data in the form of light pulses is transmitted. It is used for high-speed transmissions over medium (200 m) to long (10 km) distances.

Fibre Channel FC. Integrated set of standards recognized by American National Standards Institute (ANSI) which defines specific protocols for flexible information transfer. Logically, a point-to-point serial data channel, structured for high performance.

Fibre Channel address A 3-byte node port (N_Port) identifier which is unique within the address domain of a fabric. Each port may choose its own identifier, or the identifier may be assigned automatically during fabric login.

field-replaceable unit FRU. Assembly removed and replaced in its entirety when any one of its components fails *(D)*. *See* active field-replaceable unit.

firmware Embedded program code that resides and runs on, for example, directors, switches, and hubs.

FL_Port *See* fabric loop port.

FX_Port A port configuration allowing a port to transition operationally to either an F_Port or an FL_Port. Only the Sphereon 4500 Switch supports the configuration of this port type.

FRU *See* field-replaceable unit.

G

G_Port *See* generic port.

gateway A multi-homed host used to route network traffic from one network to another, and to pass network traffic from one protocol to another.

gateway address (1) In transmission control protocol/Internet protocol (TCP/IP), a device that connects two systems that use the same or different protocols. (2) In TCP/IP, the address of a router to which a device sends frames destined for addresses not on the same physical network (for example, not on the same Ethernet) as the sender. The hexadecimal format for the gateway address is XXX.XXX.XXX.XXX.

Gb/s Acronym for gigabits per second.

generic port G_Port. Physical interface on a director or switch that can function either as a fabric port (F_Port) or an expansion port (E_Port), depending on the port type to which it connects.

GPM *See* G_Port Module.

G_Port Module An individual FRU that provides the physical attachment point for Fibre Channel devices.

Gx_Port A port configuration allowing a port to transition operationally to FL_Port as well as to the port operational states described for a G_Port. Only the Sphereon 4500 Switch supports the configuration of this port type.

H

hop (1) Data transfer from one node to another node. (2) Describes the number of switches that handle a data frame from its origination point through its destination point.

hop count The number of hops a unit of information traverses in a fabric.

hub (1) In Fibre Channel protocol, a device that connects nodes into a logical loop by using a physical star topology. (2) In Ethernet, a device used to connect the server platform and the directors or switches it manages.

I

information message Message notifying a user that a function is performing normally or has completed normally. *See also* error message; warning message.

initial program load IPL. The process of initializing the device and causing the operating system to start. An IPL may be initiated through a menu option or a hardware button.

interface (1) A shared boundary between two functional units, defined by functional, signal, or other characteristics. The concept includes the specification of the connection of two devices having different functions *(T)*. (2) Hardware, software, or both, that link systems, programs, or devices *(D)*.

Internet protocol IP. Network layer for the transmission control protocol/Internet protocol (TCP/IP) protocol used on Ethernet networks. IP provides packet routing, fragmentation, and reassembly through the data link layer *(D)*.

Internet protocol address IP address. Unique string of numbers (in the format xxx.xxx.xxx.xxx) that identifies a device on a network.

interoperability Ability to communicate, execute programs, or transfer data between various functional units over a network.

interswitch link ISL. Physical expansion port (E_Port) connection between two directors or switches in a fabric.

IP *See* Internet protocol.

IP address *See* Internet protocol address.

IPL *See* initial program load.

ISL *See* interswitch link.

L

LAN *See* local area network.

LIN *See* link incident.

link Physical connection between two devices on a switched fabric. A link consists of two conductors, one used for sending and the other for receiving, thereby providing a duplex communication path.

link incident LIN. Interruption to link due to loss of light or other causes. *See also* link incident alerts.

link incident alerts A user notification, such as a graphic symbol in the Element Manager application *Hardware View* that indicates that a link incident has occurred. *See also* link incident.

LIPS Loop Initialization Primitives. *See* loop initialization primitive.

local area network LAN. A computer network in a localized geographical area (for example, a building or campus), whose communications technology provides a high-bandwidth medium to which many nodes are connected *(D)*. *See also* storage area network.

loopback test Test that checks attachment or control unit circuitry, without checking the mechanism itself, by returning the output of the mechanism as input.

loop initialization primitive LIP. In an arbitrated loop device, a process by which devices connected to hub ports (H_Ports) on the arbitrated loop device notify other devices and the switch of the presence in the loop by sending LIP sequences and subsequent frames through the loop. This process allows linked arbitrated loop devices to perform fabric loop port (FL_Port) arbitration as they link through hub ports.

M

managed product Hardware product that can be managed with the Element Manager application. Most directors and switches are managed products. *See also* device.

multiswitch fabric A Fibre Channel fabric created by linking more than one director or fabric switching device within a fabric.

N

N_Port *See* node port.

name server (1) In TCP/IP, *see* domain name server. (2) In Fibre Channel protocol, a server that allows node ports (N_Ports) to register information about themselves. This information allows N_Ports to discover and learn about each other by sending queries to the name server.

network address Name or address that identifies a device on a transmission control protocol/Internet protocol (TCP/IP) network. The network address can be either an IP address in dotted-decimal notation (composed of four three-digit octets in the format xxx.xxx.xxx.xxx) or a domain name (as administered on a customer network).

node In Fibre Channel protocol, an end device (server or storage device) that is or can be connected to a switched fabric. *See also* device.

node port N_Port. Physical interface within an end device that can connect to an fabric port (F_Port) on a switched fabric or directly to another N_Port (in point-to-point communications).

O

offline sequence OLS. (1) Sequence sent by the transmitting port to indicate that it is attempting to initialize a link and has detected a problem in doing so. (2) Sequence sent by the transmitting port to indicate that it is offline.

offline state When the switch or director is in the offline state, all the installed ports are offline. The ports transmit an offline sequence (OLS) and they cannot accept a login got connection from an attached device. *Contrast with* online state.

OLS *See* offline sequence.

online state

When the switch or director is in the online state, all of the unblocked ports are allowed to log in to the fabric and begin communicating. Devices can connect to the switch or director if the port is not blocked and can communicate with another attached device if both devices are in the same zone, or if the default zone is enabled. *Contrast with* offline state.

operating state (director or switch)

The operating states are described as follows:

Online - when the director or switch is set online, an attached device can log in to the director if the port is not blocked. Attached devices can communicate with each other if they are configured in the same zone.

Offline - when the director or switch is set offline, all ports are set offline. The director or switch transmits the offline sequence (OLS) to attached devices, and the devices cannot log in to the director or switch.

operating state (port)

Valid states are:

- Online, offline, or testing.
- Beaconing.
- Invalid attachment.
- Link incident or link reset.
- No light, not operational, or port failure.
- Segmented E_Port.

optical fiber connector

Hardware component that transfers optical power between two optical fibers or bundles and is designed to be repeatedly connected and disconnected.

out-of-band management

Transmission of management information, using frequencies or channels other than those routinely used for information transfer.

P

password

Unique string of characters known to the computer system and to a user who must specify it to gain full or limited access to a system and to the information stored within it.

path In a network, any route between any two ports.

persistent binding A form of server-level access control that uses configuration information to bind a server to a specific Fibre Channel storage volume (or logical device), using a unit number. *See also* access control.

port Receptacle on a device to which a cable leading to another device can be attached. Ports provide Fibre Channel connections *(D)*.

port address name A user-defined symbolic name of 24 characters or less that identifies a particular port address.

port card Field-replaceable hardware component that provides the port connections for fiber cables and performs specific device-dependent logic functions.

port card map Map showing port numbers and port card slot numbers inside a hardware cabinet.

port name Name that the user assigns to a particular port through the Element Manager application.

preferred domain ID Configured value that a switch will request from the Principal Switch. If the preferred value is already in use, the Principal Switch will assign a different value.

principal switch In a multiswitch fabric, the switch that allocates domain IDs to itself and to all other switches in the fabric. There is always one principal switch in a fabric. If a switch is not connected to any other switches, it acts as its own principal switch.

R

R_A_TOV *See* resource allocation time-out value.

redundancy Performance characteristic of a system or product whose integral components are backed up by identical components to which operations will automatically failover in the event of a component failure. Redundancy is a vital characteristic of virtually all high-availability (24 hours/7 days per week) computer systems and networks.

resource allocation time-out value R_A_TOV. R_A_TOV is a value used to time-out operations that depend on the maximum possible time that a frame could be delayed in a fabric and still be delivered.

S

SAN *See* storage area network; system area network.

SAN management application (1) Software application that is the system management framework providing the user interface for managing Fibre Channel switch products. (2) The software application that implements the management user interface for all managed hardware products. The SAN management application can run both locally on a server platform and on a remote computer running client software.

EFCM Basic interface The interface provides a graphical user interface (GUI) similar to the Element Manager application, and supports director or switch configuration, statistics monitoring, and basic operations. With director or switch firmware installed, administrators or operators with a browser-capable personal computer (PC) and an Internet connection can monitor and manage the director or switch through an embedded web server interface.

SBAR *See* serial crossbar assembly.

segmented E_Port *See* segmented expansion port.

segmented expansion port Segmented E_Port. E_Port that has ceased to function as an E_Port within a multiswitch fabric due to an incompatibility between the fabrics that it joins.

SEL System error light.

serial crossbar assembly SBAR. The assembly is responsible for Fibre Channel frame transmission from any director or switch port to any other director or switch port. Connections are established without software intervention.

serial port A full-duplex channel that sends and receives data at the same time. It consists of three wires: two that move data one bit at a time in opposite directions, and a third wire that is a common signal ground wire.

server A computer that provides shared resources, such as files and printers, to the network. Used primarily to store data, providing access to shared resources. Usually contains a network operating system.

simple network management protocol SNMP. A transmission control protocol/Internet protocol (TCP/IP)-derived protocol governing network management and monitoring of network devices.

simple network management protocol community SNMP community. Also known as SNMP community string. SNMP community is a cluster of managed products (in SNMP terminology, hosts) to which the server or managed product running the SNMP agent belongs.

simple network management protocol community name SNMP community name. The name assigned to a given SNMP community. Queries from an SNMP management station to a device running an SNMP agent will only elicit a response if those queries are addressed with the correct SNMP community name.

simple network management protocol management station SNMP management station. An SNMP workstation personal computer (PC) used to oversee the SNMP network.

SNMP *See* simple network management protocol.

SNMP community *See* simple network management protocol community.

SNMP community name *See* simple network management protocol community name.

SNMP management station *See* simple network management protocol management station.

storage area network SAN. A high-performance data communications environment that interconnects computing and storage resources so that the resources can be effectively shared and consolidated. *See also* local area network.

subnet mask A mask used by a computer to determine whether another computer with which it needs to communicate is located on a local or remote network. The network mask depends upon the class of networks to which the computer is connecting. The mask indicates which digits to look at in a longer network address and allows the router to avoid handling the entire address. Subnet masking allows routers to move

the packets more quickly. Typically, a subnet may represent all the machines at one geographic location, in one building, or on the same local area network.

switch A device that connects, filters and forwards packets between local area network (LAN) segments or storage area network (SAN) nodes or devices.

switch binding A security method that limits the devices that can log in to a switch, by specifying the node WWN of the allowed devices in the Switch Membership List.

Switch Membership List The list of devices, specified by WWN, that can log in to a switch.

switch priority Value configured into each switch in a fabric that determines its relative likelihood of becoming the fabric's principal switch. Lower values indicate higher likelihood of becoming the principal switch. A value of 1 indicates the highest priority; 225 is the lowest priority. A value of 225 indicates that the switch is not capable of acting as the principal switch. The value 0 is illegal.

T

telnet A protocol designed to provide general, bi-directional, eight-bit byte oriented communication. It is a standard method of interfacing terminal devices and terminal-oriented processes to each other.

topology The logical, physical, or both arrangement of stations on a network.

trap Unsolicited notification of an event originating from a simple network management protocol (SNMP) managed device and directed to an SNMP network management station.

U

UPM *See* universal port module.

uniform resource locator URL. A URL is the address of a document or other resource on the Internet.

universal port module A flexible 1 gigabit-per-second or 2 gigabit-per-second module that contains four generic ports (G_Ports).

URL *See* uniform resource locator.

user datagram protocol UDP. A connectionless protocol that runs on top of Internet protocol (IP) networks. User datagram protocol/Internet protocol (UDP/IP) offers very few error recovery services, instead providing a direct way to send and receive datagrams over an IP network. UDP/IP is primarily used for broadcasting messages over an entire network.

W

warning message A message that indicates a possible error has been detected. *See also* error message; information message.

World Wide Names WWN. Eight-byte string that uniquely identifies a Fibre Channel entity (that is, a port, a node, a switch, a fabric), even on global networks.

WWN *See* World Wide Names.

Z

zone Set of devices that can access one another. All connected devices may be configured into one or more zones. Devices in the same zone can see each other. Those devices that occupy different zones cannot. *See also* active zone set; zone set.

zone member Specification of a device to be included in a zone. A zone member can be identified by the port number of the director or switch to which it is attached or by its port World Wide Name (WWN). In multiswitch fabrics, identification of end-devices or nodes by WWN is preferable.

zone set A collection of zones that may be activated as a unit. *See also* active zone set; zone.

Index

Symbols

" 1-15
? 1-20

Numerics

60 characters in history log 1-15
80-column output 1-16

A

access control list 2-74
    adding a range 2-74
    delete a range 2-75
    disable 2-75
    enable 2-75
    show 2-75
access rights
    relationship to other products 1-18
active zoning configuration 2-132
add
    access control list 2-74
    alias to WWN 2-5
address
    port 2-36
AFD 2-138
    HDD report 2-138
    POM report 2-139
    show 2-139
alerts, threshold 2-157
alias 2-3
    activate pending 2-4
    add 2-5
    clear pending 2-5
    delete 2-5
    enabling CLI 2-6
    replace pending 2-8
    show active 2-7
    show pending 2-8
ASCII character set 2-3
asynchronous commands 1-3
attached
    fabric binding terminology 2-62
audit log
    show 2-181
authentication
    configuring E port 2-44, 2-45
    configuring interface 2-44
    configuring N port 2-45, 2-46
    configuring Open Systems 2-47
    configuring outgoing 2-43
    configuring port 2-50
    configuring sequence 2-43
    configuring serial 2-48
    configuring Web 2-49
    showing settings 2-48
authorization traps, SNMP 2-93

B

back pressure state
    OpenTrunking 2-146
backslash 1-15
BB_credits
    configuring 2-33
beaconing
    port 2-134
    unit 2-135

block port 2-31

C

cable, replacing 1-23
character set 2-3
class 2 counters 2-140
class 3 counters 2-141
CLI 1-2
  command tree 1-4
  ED-5000 Director 1-22
  errors, handling 1-19
  globally available commands 1-4
  help 1-20
  logging in or out 1-16
  lost 2-136
  navigation conventions 1-3
  output 1-16
  parameters 1-15
  purpose 1-2
  root> prompt 1-14
  using 1-2
commaDelim command
  globally available 1-4
command line interface 1-2
  command tree 1-4
  ED-5000 1-22
  errors, handling 1-19
  globally available commands 1-4
  help 1-20
  logging in or out 1-16
  lost 2-136
  navigation conventions 1-3
  output 1-16
  parameters 1-15
  purpose 1-2
  root> prompt 1-14
  using 1-2
command tree 1-4
  limitations on movements within 1-15
  navigation of 1-14
commands
  asynchronous 1-3
  config 2-3
  ED-5000 1-22
  login 1-17
  logout 1-18
  maint 2-134
  name server information 2-208
  perf 2-138
  periods in 1-2
  show 2-179
  that take effect immediately 2-62, 2-123
config command 2-3
configuration data, resetting 2-134
configuration, resetting 2-136
congestion
  unresolved 2-150
congestion threshold
  OpenTrunking 2-147
connection loss, ethernet 1-23
conventions
  documentation 1-2
  navigation 1-3
  used in manual xvii
counter data 2-140, 2-141
counter threshold alert
  activating 2-157
  types 2-159
counter threshold alerts 2-157
CTA 2-157
CUP zoning 2-21, 2-22

D

data transfers, disruption of 2-38, 2-114
date and time, system 2-121
deactivate fabric binding 2-65
default values, resetting 2-136
default zone 2-131
delete
  access control list 2-75
  alias 2-5
  preferred path 2-152
dependencies 2-8
disable
  access control list 2-75
  OpenTrunking 2-148
  SNMP agent 2-96
disabling
  enterprise fabric mode 2-8
documentation conventions 1-2
documentation, related xvi
Domain ID

state 2-108
domain ID, port member
adding 2-125
deleting 2-128
domain RSCN state 2-87, 2-90, 2-91, 2-92, 2-94, 2-107

E

e_d_tov 2-88, 2-108
E_port, setting 2-40
ED-5000 Director 1-22
Embedded Frame Log
show configuration 2-182
view 2-183, 2-187
enable
access control list 2-75
OpenTrunking 2-148
SNMP agent 2-96
enabling 2-9
enterprise fabric mode 2-8, 2-9
feature set 2-10
NPIV 2-11
enbling
FICON Management Server 2-10
Enterprise Fabric Mode
activating 2-8, 2-9
deactivating 2-8, 2-9
enterprise fabric mode 2-9
disabling 2-8
enabling 2-8
error counters, port 2-143
error light, system, clearing 2-136
escape character 1-15
ethernet attributes 2-203
ethernet cable, replacing 1-23
ethernet connection, loss of 1-23
event log 2-189
exit port
set 2-153

F

F frames
configuring logging 2-183
F_port, setting 2-40
fabric address notification (FAN)
setting state 2-32
fabric binding
activate 2-63
active configuration 2-66
active FBML
show 2-66
add members 2-64
deactivate 2-65
delete members 2-65
membership list 2-64, 2-65
delete member 2-65
online state functions 2-63
pending configuration
activate 2-63
add attached members 2-64
pending FBML
show 2-67
replace pending 2-66
replace pending FBML 2-66
security 2-61
show 2-236, 2-237
show pending 2-67
terms
attached 2-62
local 2-62
unattached 2-62
fabric binding membership list
active 2-66
add member 2-64
clear 2-65
deactivate 2-65
delete member 2-65
pending
show 2-67
replace pending FBML 2-66
fabric log
view 2-190, 2-191
fabric nodes
list 2-192
show 2-192
fabric topology
list 2-195
show 2-195
factory settings, resetting 2-134, 2-136
feature
enabling 2-10
Enterprise Fabric Mode 2-8, 2-9
FICON Management Server 2-10, 2-23

list 2-199
NPIV 2-11
Open Systems Management Server 2-11, 2-30
OpenTrunking 2-12, 2-148
SANtegrity 2-8, 2-9
show 2-199
feature key
NPIV 2-11
feature keys 2-10
resetting 2-136
features
preferred path 2-151
fencing policies
show 2-200
Fibre Alliance MIB
SNMP 2-95
FICON
enabling management server 2-10
FICON CUP
show zoning 2-201
zoning 2-21, 2-22
FICON Management Server 2-10, 2-23
FICON MS
show 2-202
ficonms 2-10, 2-23
FRU information 2-202

G

G_port, setting 2-40
gateway address 2-24
globally available commands 1-4
graphical user interface 1-2
GUI 1-2

H

help command 1-20
help, technical support xviii
history log 1-15
clearing 1-15
HTTP 1-2

I

inactive operational state 2-232
inactive state reasons 2-232
insistent Domain ID
state 2-108
interactive interfaces 1-2
interoperability mode 2-109
invalid attachment state reasons 2-232
IP address, ethernet 2-24
IP configuration, showing 2-25
IP line speed, ethernet 2-24
IPL 2-136

K

keys
for feature sets 2-10
resetting 2-136

L

Latin-1 character set 2-3
limitations, history log 1-15
limited fabric RSCN 2-110
link counters 2-144
link incident log 2-204
link sequence counts 2-161
local
fabric binding terminology 2-62
log
Embedded Frame
settings 2-183
threshold alert 2-254
view 2-189
logging in 1-16
logging out 1-16
logical link errors 2-161
login command 1-17
globally available 1-4
login server 2-205
logout command 1-18
globally available 1-4
low BB credit threshold 2-147

M

maint command 2-134
management server
enabling 2-10
Management Style
FICON 2-10
manual

conventions xvii
using this xvi
McDATA
product publications, ordering xix
technical support xviii
web site xvi
membership list
fabric binding 2-65
add attached 2-64
add member 2-64
clear 2-65
switch binding 2-76

N

name server 2-206, 2-208
names, for ports 2-32
navigating the command tree 1-14
limitations 1-15
navigation conventions 1-3
NPIV
configuring port IDs 2-25, 2-26
disable 2-11
enable 2-11
enabling 2-11
set state 2-11
setting state 2-27
showing configuration 2-27
NSTools 2-28
clear snapshot 2-28
save snapshot 2-28
show snapdiff 2-29
show snapshot 2-29
null strings 1-16
NV-RAM configuration parameters, reset 2-136

O

offline, setting switches for configuration 2-88
Open Systems
setting state 2-30
Open Systems Management Server 2-11, 2-30
OpenTrunking
back pressure state 2-146
congestion threshold 2-147
low BB credit threshold 2-147
show 2-149
configuration 2-212
reroute log 2-213
state 2-12, 2-148
unresolved congestion 2-150
operational state 2-232
ordering product publications xix
OSMS state 2-11, 2-30
output 1-16
order of displayed values 1-13

P

parameters 1-15
passwords
format 1-16
perf command 2-138
performance alerts 2-157
performance services 2-138
periods in command names 1-2
physical link errors 2-160
port
address, show 2-229
beaconing 2-134
binding 2-68, 2-238
binding, state 2-68
block 2-31
configuration 2-214
configuration, show 2-226
configuring BB_credits 2-33
configuring WWN, binding 2-70
error counters 2-143
IDs, NPIV 2-25, 2-26
information 2-218
link counters 2-144
name 2-32
nodes 2-219
optical diagnostics 2-222
port statistics 2-142
port technology information 2-233
QPM mode setting 2-32
resetting 2-135
show configuration 2-214
show exit 2-216
show nodes 2-219
show optic 2-224
showing address configuration 2-36
showing authentication state 2-51
showing configuration 2-34

speed 2-38
statistics, clearing 2-142
status 2-230
swapping 2-40
threshold alert 2-162, 2-163
traffic counters 2-177
type 2-40
port binding state 2-68
port number, zone member
adding 2-125
deleting 2-128
port statistics, resetting 2-142
preferred domain ID 2-110
preferred path
clear 2-152
delete 2-152
destination 2-155, 2-234
disable 2-154
enable 2-154
feature overview 2-151
set exit port 2-153
show 2-234
show exit port 2-216
show path 2-155
show state 2-157
source port 2-155, 2-234
state 2-154
principal switch 2-111
priority, of switches 2-111
publications
McDATA products, ordering xviii
related xvi
updates xvi

Q

QPM
setting mode 2-32
quotation marks
for spaces 1-15
in strings 1-15

R

r_a_tov 2-112
RADIUS server
adding 2-53
configuring deadtime 2-52
configuring timeout 2-54
deleting 2-52
showing configuration 2-54
range
access control list 2-74, 2-75
registered trademarks xix
related documentation xvi
reroute log, OpenTrunking 2-213
rerouting delay 2-112
root> prompt 1-14
RSCN
fabric 2-110

S

SANtegrity
Enterprise Fabric Mode 2-8, 2-9
scripting environments 1-2
secret
setting 2-55
secrets
format 1-16
secure shell
keys 2-72
set state 2-72
show state 2-73
security
adding RADIUS server 2-53
adding users to database 2-56
configuring 2-42
configuring authentication interface 2-44
configuring authentication sequence 2-43
configuring E port authentication 2-44, 2-45
configuring N port authentication 2-45, 2-46
configuring Open Systems authentication 2-47
configuring outgoing authentication 2-43
configuring port state 2-50
configuring RADIUS server deadtime 2-52
configuring serial authentication 2-48
configuring transmission attempts 2-51
configuring users 2-56
configuring Web authentication 2-49
deleting RADIUS server 2-52
deleting users from database 2-57
fabric binding 2-61
activate 2-63

active configuration 2-66
add members 2-64
deactivate 2-65
delete members 2-65
replace pending 2-66
show pending 2-67
modifying users 2-58
port binding 2-68
reset SSH keys 2-72
set SSH renegotiation MB 2-72
set SSH state 2-72
setting secret 2-55
setting user role 2-60
show SSH state 2-73
showing port 2-51
showing RADIUS server 2-54
showing state 2-48
showing user 2-60
switch binding 2-76
adding member 2-77
deleting member 2-77
setting state 2-78
showing configuration 2-78
timeout
RADIUS server 2-54
security log 2-237
segmented E_Port 2-232
segmented E_port
state reasons 2-232
service, technical support xviii
setting online or offline 2-137
settings
threshold alert settings 2-175
show
access control list 2-75
all 2-180
ethernet attributes 2-203
event log 2-189
fabric binding 2-236, 2-237
fabric nodes 2-192
fabric ping 2-192
fabric show route table 2-194
fabric topology 2-195
fabric trace route 2-196
features list 2-199
fencing policies 2-200
FICON CUP zoning 2-201
FICON MS 2-202
FRU information 2-202
link incident log 2-204
login server 2-205
name server 2-206
nameserver FC4 types 2-209
open trunking configuration 2-212
OpenTrunking
configuration 2-212
rerouteLog 2-213
OpenTrunking information 2-149
port address 2-229
port binding for all ports 2-238
port configuration 2-214, 2-226
port exit 2-216
port information 2-218
port nodes 2-219
port optic 2-224
port optical diagnostics 2-222
port status 2-230
port technology information 2-233
preferred path 2-234
preferred path exit port 2-216
security log 2-237
switch access control list 2-239
switch attributes 2-247
switch binding 2-240
Switch Binding Membership List 2-79
system attributes 2-250
threshold alert list 2-252
threshold alert log 2-254
threshold alert settings 2-175
WWN 2-193
show commands
active zoning configuration 2-132
all 2-180
configuration for port 2-34
features 2-12
order of output 1-13
pending zoning configuration 2-133
port
show binding 2-69
show branch 2-179
SNMP configuration
config.snmp.show 2-96
snmp.show 2-246
switch configuration 2-114

system configuration 2-122
SNMP
authorization traps 2-93
community
adding 2-86
deleting 2-93
disable agent 2-96
enable agent 2-96
Fibre Alliance MIB version 2-95
send test trap 2-95
set state 2-96
spaces, quotation marks required 1-15
speeds
port 2-38
switches 2-114
state
back pressure 2-146
OpenTrunking 2-12, 2-148
setting NPIV 2-27
SNMP 2-96
Zone Flex Pars 2-104
statistic table, threshold alert 2-166
statistics, port, clearing 2-142
strings, null 1-16
strings, quotation marks in 1-15
subnet mask 2-24
summed sets 2-160
swap ports
by address 2-40
by number 2-40
switch attributes, displaying 2-247
Switch Binding
add SBML member 2-77
configuration 2-76
delete SBML member 2-77
show configuration 2-78
switch binding 2-240
adding member 2-77
delete member 2-77
online state functions 2-76
set state 2-78
show configuration 2-78
show SBML 2-79
Switch Binding Membership List 2-79
add member 2-77
delete member 2-77
overview 2-76
show 2-79
switches 2-137
banner 2-104
banner text 2-104
set CLI state 2-105
set web state 2-105
show 2-106
configuring IP address 2-24
configuring IP line speed 2-24
configuring, set offline 2-88
domain ID offset 2-106
e_d_tov 2-88, 2-108
event log 2-189
FRU information 2-202
interoperability mode 2-109
IPL 2-136
login server database 2-205
name server database 2-206, 2-208
preferred domain ID 2-110
principal 2-111
priority 2-111
r_a_tov 2-112
rerouting delay 2-112
security log 2-237
showing LAN configuration 2-25
speed 2-114
system contact 2-120
system description 2-121
system location 2-122
system name 2-122
system attributes, displaying 2-250
system contact attribute 2-120
system date and time 2-121
system description 2-121
system error light, clearing 2-136
system location 2-122
system name 2-122

T

technical support xviii
Telnet client session 1-2
connection, loss of 1-23
threshold alert
activate 2-168
add alert 2-161
add port 2-171

add throughput alert 2-170
alert list 2-252
counter
setting 2-164
deactivate 2-168
delete alert 2-168
disable 2-168
enable 2-168
list 2-252
log 2-254
name 2-166
parameters 2-165, 2-175
port
add 2-162, 2-171
remove 2-163, 2-172
remove port 2-172
set parameters 2-175
settings
show 2-175
show 2-168, 2-175
show utilization types 2-176
statistic table, show 2-166
throughput
add alert 2-170
trigger
percentage 2-174
trigger type 2-173
utilization percentage 2-174
utilization type 2-173
utilization types 2-176
threshold alerts
overview 2-157
summed sets 2-160
throughput alert
add 2-170
port 2-171, 2-172
set parameters 2-175
show settings 2-175
show utilization types 2-176
utilization percentage 2-174
utilization type 2-173
Throughput Threshold Alert
activating 2-158
throughput threshold alert 2-157
types 2-159
time, system 2-121
trademarks xix
traffic counters 2-177
traversing the command tree 1-14
trunking
congestion 2-147, 2-150
TTAs 2-157
types, port 2-40

U

UDP 2-87, 2-97
unattached
fabric binding terminology 2-62
unit beaconing 2-135
unresolved congestion
OpenTrunking 2-150
up-arrow command 1-15
user
adding to database 2-56
configuring 2-56
deleting from database 2-57
modifying 2-58
password expiration time 2-59
setting role 2-60
showing 2-60
user access rights
relationship to other products 1-18
user datagram protocol 2-87, 2-97
using this manual xvi
utilization type
threshold alert 2-173

V

view
logs 2-183, 2-187, 2-190, 2-191

W

web site, McDATA xvi, xviii
web-based interface 1-2
work area 2-123
world-wide name members
adding 2-126
deleting 2-129
wrap count 2-140, 2-141
WWN
port binding 2-70
show 2-193

WWN members
adding 2-126
deleting 2-129

Z

zone
adding 2-126
default state 2-131
deleting 2-130
members
adding by port 2-125
adding by WWN 2-126
deleting by port 2-128
deleting by WWN 2-129
renaming 2-130
Zone Flex Pars
zoning state 2-104
zone members
clearing 2-127
domain ID
adding 2-125
deleting 2-128
zone set
activating to fabric 2-123, 2-124
clearing 2-127
deactivating 2-128
renaming 2-130
replacing 2-131
temporary copy 2-123
zone sets and zones
displaying 2-124
zoning
configuring 2-123
FICON CUP 2-21, 2-22
show FICON CUP 2-201
Zone Flex Pars state 2-104
zoning configuration
active, display 2-132
pending, display 2-133